

# **Manual of Petroleum Measurement Standards Chapter 11—Physical Properties Data**

**Section 2, Part 4—Temperature Correction for the Volume  
of NGL and LPG  
Tables 23E, 24E, 53E, 54E, 59E, and 60E**

**ASTM Technical Publication [Stock No. PETROLTBL-TP27]  
GPA Technical Publication TP-27**

FIRST EDITION, SEPTEMBER 2007





# **Manual of Petroleum Measurement Standards Chapter 11—Physical Properties Data**

**Section 2, Part 4—Temperature Correction for the Volume  
of NGL and LPG  
Tables 23E, 24E, 53E, 54E, 59E, and 60E**

**ASTM Technical Publication [Stock No. PETROLTBL-TP27]  
GPA Technical Publication TP-27**

**Measurement Coordination**

FIRST EDITION, SEPTEMBER 2007

**Prepared for**

**American Petroleum Institute  
1220 L Street, NW  
Washington, D.C. 20005**

**ASTM International  
100 Barr Harbor Drive  
West Conshohocken, PA 19428**

**Gas Processors Association  
6526 E. 60th Street  
Tulsa, OK 74145**



## Foreword

For custody transfer purposes, natural gas liquid (NGL) and liquefied petroleum gas (LPG) volumes are generally stated at a fixed base temperature and saturation pressure. As most volume transfers occur at temperatures and pressures other than standard conditions, these volumes are adjusted to standard conditions through the use of correction factors.

This document presents a new method to calculate temperature correction factors. With the publication of this document, previous API, ASTM and GPA documents containing NGL and LPG temperature correction factors should no longer be used. The document is specifically titled as being suitable for NGL and LPG liquids. Light hydrocarbon mixtures containing significant quantities of methane, carbon dioxide and nitrogen which have density ranges which overlap those contained in these tables can be encountered. However, the two-fluid correlation which is the basis of these tables was not calibrated for such mixtures.

The actual Standard represented by this report consists of the explicit implementation procedures. Sample tables and other examples created from a computerized version of these implementation procedures are presented within. However, these are for examples only and do not represent the Standard.

Nothing contained in any API publication is to be construed as granting any right, by implication or otherwise, for the manufacture, sale, or use of any method, apparatus, or product covered by letters patent. Neither should anything contained in the publication be construed as insuring anyone against liability for infringement of letters patent.

This document was produced under API standardization procedures that ensure appropriate notification and participation in the developmental process and is designated as an API standard. Questions concerning the interpretation of the content of this publication or comments and questions concerning the procedures under which this publication was developed should be directed in writing to the Director of Standards, American Petroleum Institute, 1220 L Street, N.W., Washington, D.C. 20005. Requests for permission to reproduce or translate all or any part of the material published herein should also be addressed to the director.

Generally, API standards are reviewed and revised, reaffirmed, or withdrawn at least every five years. A one-time extension of up to two years may be added to this review cycle. Status of the publication can be ascertained from the API Standards Department, telephone (202) 682-8000. A catalog of API publications and materials is published annually and updated quarterly by API, 1220 L Street, N.W., Washington, D.C. 20005.

Suggested revisions are invited and should be submitted to the Standards and Publications Department, API, 1220 L Street, NW, Washington, D.C. 20005, [standards@api.org](mailto:standards@api.org).

## API Special Notes

API publications necessarily address problems of a general nature. With respect to particular circumstances, local, state, and federal laws and regulations should be reviewed.

Neither API nor any of API's employees, subcontractors, consultants, committees, or other assignees make any warranty or representation, either express or implied, with respect to the accuracy, completeness, or usefulness of the information contained herein, or assume any liability or responsibility for any use, or the results of such use, of any information or process disclosed in this publication. Neither API nor any of API's employees, subcontractors, consultants, or other assignees represent that use of this publication would not infringe upon privately owned rights.

API publications may be used by anyone desiring to do so. This publication is an updated version of TP-25. Previous editions of this publication were numbered TP-25. Users of this standard should take efforts to ensure they are using the most current version of this publication. Every effort has been made by the Institute to assure the accuracy and reliability of the data contained in them; however, the Institute makes no representation, warranty, or guarantee in connection with this publication and hereby expressly disclaims any liability or responsibility for loss or damage resulting from its use or for the violation of any authorities having jurisdiction with which this publication may conflict.

API publications are published to facilitate the broad availability of proven, sound engineering and operating practices. These publications are not intended to obviate the need for applying sound engineering judgment regarding when and where these publications should be utilized. The formulation and publication of API publications is not intended in any way to inhibit anyone from using any other practices.

Any manufacturer marking equipment or materials in conformance with the marking requirements of an API standard is solely responsible for complying with all the applicable requirements of that standard. API does not represent, warrant, or guarantee that such products do in fact conform to the applicable API standard.

*All rights reserved. No part of this work may be reproduced, stored in a retrieval system, or transmitted by any means, electronic, mechanical, photocopying, recording, or otherwise, without prior written permission from the publisher.*

Copyright © 2007 American Petroleum Institute, Gas Processors Association

## **ASTM Note**

This publication does not purport to address all of the safety concerns, if any, associated with its use. It is the responsibility of the user of this publication to establish appropriate safety and health practices and determine the applicability of regulatory limitations prior to use.

## **GPA Disclaimer**

Neither the GPA nor any person acting on behalf of the GPA makes any warranty, guarantee, or representation, express or implied, with respect to the accuracy, completeness, or usefulness of the information contained in this report. The GPA hereby expressly disclaims any liability or responsibility for loss or damage resulting from the use of any apparatus, method, or process disclosed in this report; and for the infringement of any patent or the violation of any federal, state, or municipal law or regulation arising from the use of, any information, apparatus, method, or process disclosed in this report.

*All rights reserved. No part of this work may be reproduced, stored in a retrieval system, or transmitted by any means, electronic, mechanical, photocopying, recording, or otherwise, without prior written permission from the publisher.*

Copyright © 2007 American Petroleum Institute, Gas Processors Association

## Table of Contents

Foreword .....	ii
API Special Notes .....	iii
ASTM Note .....	iv
GPA Disclaimer .....	v
Table of Contents .....	vi
Nomenclature .....	viii
1 Introduction .....	1
2 Scope .....	2
3 Significant Digits .....	4
4 Comparison to the Previous Standard .....	4
5 Implementation Procedures .....	9
5.1 CTL (Table 24) and Relative Density (Table 23) for NGL and LPG using a 60°F Base Temperature .....	9
5.1.1 Implementation Procedure for Table 24E (60°F Basis) .....	9
5.1.1.1 Inputs and Outputs .....	9
5.1.1.2 Outline of Calculations .....	9
5.1.1.3 T24 Implementation Procedure .....	10
5.1.1.4 Examples for Section 5.1.1 (Table 24E) .....	15
5.1.2 Implementation Procedure for Table 23E (60°F Basis) .....	33
5.1.2.1 Inputs and Outputs .....	33
5.1.2.2 Outline of Calculations .....	33
5.1.2.3 T23 Implementation Procedure .....	34
5.1.2.4 Examples for Section 5.1.2 (Table 23E) .....	42
5.2 CTL (Table 54) and Density (Table 53) for NGL and LPG using a 15°C Base Temperature .....	61
5.2.1 Implementation Procedure for Table 54E (15°C Basis) .....	61
5.2.1.1 Inputs and Outputs .....	61
5.2.1.2 Outline of Calculations .....	61
5.2.1.3 T54 Implementation Procedure .....	61
5.2.1.4 Examples for Section 5.2.2 (Table 54E) .....	65
5.2.2 Implementation Procedure for Table 53E (15°C Basis) .....	83
5.2.2.1 Inputs and Outputs .....	83
5.2.2.2 Outline of Calculations .....	83
5.2.2.3 T53 Implementation Procedure .....	83
5.2.2.4 Examples for Section 5.2.2 (Table 53E) .....	85



5.3	CTL (Table 60) and Density (Table 59) for NGL and LPG using a 20°C Base Temperature .....	101
5.3.1	Implementation Procedure for Table 60E (20°C Basis) .....	101
5.3.1.1	Inputs and Outputs .....	101
5.3.1.2	Outline of Calculations .....	101
5.3.1.3	T60 Implementation Procedure.....	101
5.3.1.4	Examples for Section 5.3.1 (Table 60) .....	105
5.3.2	Implementation Procedure for Table 59E (20°C Basis) .....	123
5.3.2.1	Inputs and Outputs .....	123
5.3.2.2	Outline of Calculations .....	123
5.3.2.3	T59 Implementation Procedure.....	123
5.3.2.4	Examples for Section 5.3.2 (Table 59E).....	126
6	Sample Sections of Printed Tables .....	142
7	References .....	149

## Nomenclature

$A, B, C$	parameters in Section 5.1.2 quadratic equation
$C_{TL}$	temperature correction factor
$h_2$	scaling factor
$k_1, k_2, k_3, k_4$	parameters in saturation density equation
$T_B$	base temperature (60°F, 15°C, or 20°C)
$T_{BK}$	base temperature (288.15 K, or 293.15 K)
$T_c$	fluid critical temperature (K)
$T_{c,ref}$	reference fluid critical temperature (K)
$T_F$	observed measurement temperature (°F or °C)
$T_{r,x}$	reduced observed temperature
$T_x$	observed temperature (K)
$V_{60}/V_{Tx}$	ratio of volume at 60°F to volume at temperature $T_x$ . Is the basic definition of $C_{TL}$
$X$	interpolating factor
$Z_c$	critical compressibility factor
$\alpha, \beta, \phi$	parameters in Section 5.1.2 quadratic equation
$\delta$	interpolation variable
$\tau$	parameter in saturation density equation
$\gamma_x$	relative density at observed temperature
$\gamma_{x,high}$	relative density at the observed temperature corresponding to the upper bound for the 60° relative density
$\gamma_{x,low}$	relative density at the observed temperature corresponding to the lower bound for the 60° relative density
$\gamma_{x,mid}$	relative density at the observed temperature corresponding to the intermediate 60° relative density used in Section 5.1.2 iteration procedure
$\gamma_{x,trial}$	trial relative density at the observed temperature used in Section 5.1.2 iteration procedure
$\gamma_{TB}$	relative density at the base temperature, $T_B$
$\gamma_{60}$	relative density at a base temperature of 60°F
$\gamma_{Tx}$	relative density at the observed temperature, $T_x$
$\gamma_{60,high}$	upper bound for the observed fluid's 60° relative density
$\gamma_{60,low}$	lower bound for the observed fluid's 60° relative density
$\gamma_{60,mid}$	intermediate 60°F relative density value used in Section 5.1.2 iteration procedure
$\gamma_{60,trial}$	trial 60°F relative density value used in Section 5.1.2 iteration procedure
$\rho_c$	critical molar density (gram-mole/L)
$\rho_{60}$	density at a base temperature of 60°F (kg/m <sup>3</sup> )
$\rho_{15}$	density at a base temperature of 15°C (kg/m <sup>3</sup> )
$\rho_{20}$	density at a base temperature of 20°C (kg/m <sup>3</sup> )
$\rho^{sat}$	saturation molar density (gram-mole/L)
$\rho_{60}^{sat}$	saturation molar density at 60°F (gram-mole/L)
$\rho_T^{sat}$	saturation molar density at observed temperature (gram-mole/L)

# Temperature Correction for the Volume of NGL and LPG

## Tables 23E, 24E, 53E, 54E, 59E, and 60E

### 0 Implementation Guidelines

This Revised Standard/Technical Publication is effective upon the date of publication and supersedes the ASTM-IP 1952 Petroleum Measurement Tables, GPA 2142, GPA TP-16, Tables 33 and 34 of API MPMS Chapter 11.1-1980 Volumes XI/XI (Adjuncts to ASTM D1250-80 and IP 200/80), API MPMS Chapter 11.2.2/11.2.2M, and API/ASTM/GPA TP-25. However, due to the nature of the changes in this Revised Standard/Technical Publication and the fact that it is or may be incorporated by reference in various regulations, it is recognized that guidance concerning an implementation period may be needed in order to avoid disruptions within the industry and ensure proper application. As a result, it is recommended that this Revised Standard/Technical Publication be utilized on all new and existing applications no later than TWO YEARS after the publication date. An application, for this purpose, is defined as the point where the calculation is applied.

Once the Revised Standard/Technical Publication is implemented in a particular application, the Previous Standard/Technical Publication will no longer be used in that application.

However, the use of API standards and ASTM and GPA technical publications remains voluntary, and the decision on when to utilize a standard/technical publication is an issue that is subject to the negotiations between the parties involved in the transaction.

### 1 Introduction

For custody transfer purposes, natural gas liquid (NGL) and liquefied petroleum gas (LPG) volumes are generally stated at a fixed base temperature and saturation pressure. As most volume transfers occur at temperatures and pressures other than standard conditions, these volumes are adjusted to standard conditions through the use of correction factors. Separate factors for temperature ( $C_{TL}$ ) and pressure ( $C_{PL}$ ) are used to make these corrections. This document presents a new method to calculate temperature correction factors. Pressure correction factors are not within the scope of this document, but can be calculated using American Petroleum Institute *Manual of Petroleum Measurement Standards (MPMS)* Chapter 11.1-2004<sup>[1]</sup> (which superseded Chapter 11.2.1-1984<sup>[2]</sup> and 11.2.1M-1984<sup>[3]</sup>), Chapter 11.2.2-1986/GPA 8286-86<sup>[4]</sup> or Chapter 11.2.2M-1986/GPA 8286-86<sup>[5]</sup>, depending on product type.

Previously, most NGL and LPG temperature correction factors have been obtained from a variety of sources:

- ASTM-IP “Petroleum Measurement Tables”<sup>[6]</sup>, published in 1952. This publication is limited to a 60°F relative density range of 0.500 and higher.

- GPA Standard 2142, “Standard Factors for Volume Correction and Specific Gravity Conversion of Liquefied Petroleum Gases”<sup>[7]</sup>, published in 1957, also contains the same correction factors as the 1982 ASTM-IP document.
- GPA TP-16 “Composite Pressure and Temperature Volume Correction Factor Tables for Liquefied Petroleum Gas (LPG) and Natural Gasoline”<sup>[8]</sup>, published in 1988. It is limited to the following products: HD-5 Propane with a relative densities of 0.501, 0.505, and 0.510; iso-butane at a relative density of 0.565; normal butane at a relative density of 0.585; and natural gasoline (12-14 psia RVP) at a relative density of 0.664.
- API *MPMS* Chapter 11.1-1980/ASTM D1250-80 Volume XII, Table 33 “Specific Gravity Reduction to 60°F For Liquefied Petroleum Gases and Natural Gasoline”<sup>[9]</sup>.
- API *MPMS* Chapter 11.1-1980/ASTM D1250-80 Volume XII, Table 34 “Reduction of Volume to 60°F Against Specific Gravity 60/60°F For Liquefied Petroleum Gases”<sup>[9]</sup>.
- API/ASTM/GPA TP-25 “Temperature Correction for the Volume of Light Hydrocarbons”<sup>[10]</sup>.

With the publication of this document, the above API, ASTM and GPA documents should no longer be used for NGL and LPG temperature correction factors. Text for TP-25 as approved is included without technical change in this present document.

## 2 Scope

The actual Standard represented by this report consists of the explicit implementation procedures. Sample tables, flow charts, and specific examples created from a computerized version of these implementation procedures are presented within. The examples are to provide guides and check points to those who wish to implement a computerized procedure to represent the Standard, however these are not a part of the actual Standard.

This Standard covers a 60°F relative density range of 0.3500 to 0.6880 which nominally equates to a density at 15°C of 351.7 to 687.8 kg/m<sup>3</sup> and a density at 20°C of 331.7 to 683.6 kg/m<sup>3</sup>. The temperature range of this Standard is –50.8 to 199.4°F (–46 to 93°C). At all conditions, the pressure is assumed to be at saturation conditions (also known as bubble point or saturation vapor pressure).

The calculation method was developed from GPA RR-148 “Volume Correction Factors for Natural Gas Liquids – Phase II”<sup>[11]</sup> and API/ASTM/GPA Technical Publication, TP-25, September, 1998<sup>[10]</sup>. The implementation procedures for Tables 23 and 24 are entirely consistent with those presented in TP-25. Supporting data can be found in GPA RR-147 “Density Measurements on Natural Gas Liquids”<sup>[12]</sup>. GPA RR-133 “Volume Correction Factors for Natural Gas Liquids – Phase I”<sup>[13]</sup> should no longer be used, as GPA RR-148 completely replaced it.

The implementation procedures describe how to:

- 1) calculate the  $C_{TL}$  given an appropriate density factor at the basis temperature and an observed temperature, and
- 2) calculate the appropriate density factor at basis temperature given a relative density at an observed temperature.

The implementation procedures are presented in pairs by base temperature. First the procedures for Tables 23 and 24 at a 60°F base temperature are given. The procedure for Table 23 makes use of the procedure described in Table 24 thus Table 24 is presented first. These are followed by procedures for Tables 54 and 53 at a base temperature of 15°C which themselves make use of procedures in described in Tables 23 and 24; these in turn are followed by the procedures for Tables 60 and 59 at a base temperature of 20°C which also make use of procedures in described in Tables 23 and 24.

### 3 Significant Digits

It is intended that all future temperature correction factors be utilized with five decimal digits (e.g., 0.xxxxx or 1.xxxxx). As a result, this document contains  $C_{TL}$  values with only five decimal digits. This is a departure from both the 1952 “ASTM-IP Petroleum Measurement Tables” and GPA TP-16, which give either 3 or 4 decimal digits.

### 4 Comparison to the Previous Standard

As the 1952 ASTM-IP standard is limited to a low-end relative density of 0.50, a comparison can only be made at higher relative densities. The following figures show how the standards compare. The calculations are performed at 10°F and 5°C increments. It can be noted that the deviation plots for the 0.50 to 0.59 relative densities (500 to 590 kg/m<sup>3</sup> densities) are “ragged” in appearance, while the deviation plots for the higher relative densities are “smooth.” This can mostly be attributed to the 1952 ASTM-IP Standard’s rounding method:  $C_{TL}$  values under relative density 0.60 contain 3 decimal digits while  $C_{TL}$  values greater than 0.600 contain 4 decimal digits.

Note: Negative deviations indicate that the new table  $C_{TL}$  is lower than the old (1952) ASTM table  $C_{TL}$ . Positive deviations indicate that the new table  $C_{TL}$  is higher than the old (1952) ASTM table  $C_{TL}$ .

Chart 1:  $C_{TL}$  Deviations of New Table 24 Values  
Compared to Old Table 24 Values




Chart 2:  $C_{TL}$  Deviations of New Table 24 Values  
Compared to Old Table 24 Values




Chart 3:  $C_{TL}$  Deviations of New Table 24 Values  
Compared to Old Table 24 Values




Chart 4:  $C_{TL}$  Deviations of New Table 24 Values  
Compared to Old Table 24 Values






Chart 5:  $C_{TL}$  Deviations of New Table 54 Values Compared to Old Table 54 Values




Chart 6:  $C_{TL}$  Deviations of New Table 54 Compared to Old Table 54 Values




Chart 7:  $C_{TL}$  Deviations of New Table 54 Values Compared to Old Table 54 Values





Chart 8:  $C_{TL}$  Deviations of New Table 54 Values Compared to Old Table 54 Values



## 5 Implementation Procedures

The methods to calculate  $C_{TL}$  from Tables 24E, 54E, and 60E and relative density at the base temperature from Tables 23E, 53E and 59E follow. These methods are called implementation procedures, which are similar to the methods described and found in American Petroleum Institute *MPMS* Chapter 11.1.

All calculations are to be performed using double precision (i.e., long floating point, eight byte, or 64-bit) arithmetic. This should allow the computer program to recognize the difference between  $1.0$  and  $1.0 + \varepsilon$  for absolute values of  $\varepsilon$  on the order of  $10^{-16}$ . This also means that approximately 16 decimal digits are used for all calculations.

Examples are presented for each of the procedures described, they cover the range of the tables. Even though double precision was used for these example calculations only twelve decimal digits are printed here. If one uses these examples to test their own computer implementation of these procedures, it is suggested that at least eight of the significant digits be matched. The exceptions to this are for the variables  $\alpha$ ,  $\beta$ ,  $A$ ,  $B$ , and  $C$  of Table 23 (Section 5.1.2). These may show greater deviation, but the resulting  $\gamma_{60,trial}$  and  $\gamma_{x,trial}$  values should match within eight significant digits.

### 5.1 CTL (Table 24) and Relative Density (Table 23) for NGL and LPG using a 60°F Base Temperature

#### 5.1.1 Implementation Procedure for Table 24E (60°F Basis)

This section presents the implementation procedure T24 for the computation of Temperature Correction Factor,  $C_{TL}$ . The  $C_{TL}$  is used to calculate volumes of fluid at the base temperature from volumes at some known measurement temperature. The fluids are characterized by the specification of relative density at the base temperature, 60°F.

##### 5.1.1.1 Inputs and Outputs

Inputs: Relative density at 60°F,  $\gamma_{60}$   
Observed temperature,  $T_F$  (°F)

Output: Temperature Correction Factor,  $C_{TL}$  (from  $T_F$  to  $T_B$ )

##### 5.1.1.2 Outline of Calculations

The calculations are performed using an extended two-fluid corresponding states equation. By comparing densities at 60°F, two reference fluids are selected so that one is slightly more dense and one is slightly less dense than the observed fluid. The densities of these reference fluids are then scaled to the observed reduced temperature (reduced by the critical temperature of the fluid of interest). The Temperature Correction Factor is then computed from the reference fluid densities. See Figure 1 for a general flow chart of the calculation procedure.

### 5.1.1.3 T24 Implementation Procedure

#### T24/Step Number      Operation/Procedure at that step

T24/1: Round the relative density  $\gamma_{60}$  to the nearest 0.0001 and round the observed temperature  $T_F$  to the nearest 0.1°F.

Temperature rounding examples:  $-0.05$  rounds to  $-0.1$ ;  $-0.049$  rounds to  $0.0$ ,  $-0.051$  rounds to  $-0.1$ . Density rounding examples follow:  $0.35555$  rounds to  $0.3556$ ,  $0.40289$  rounds to  $0.4029$ .

T24/2: Convert the rounded observed temperature to units of Kelvin,  $T_x$ :

$$T_x = \frac{T_F + 459.67}{1.8}$$

T24/3: The resultant temperature  $T_x$  and relative density  $\gamma_{60}$  must fall within the following boundaries:

Temperature between 227.15 and 366.15 K, inclusive (equivalent to  $-46$  to  $93^\circ\text{C}$ , or  $-50.8$  to  $199.4^\circ\text{F}$ )

Relative density between 0.3500 and 0.6880, inclusive

If these values do not fall in these ranges, then the standard does not apply. Flag this result (possibly by returning a  $-1$  for  $C_{TL}$ ) and exit this procedure.

T24/4: Determine the two adjacent reference fluids to be used for the calculations. The rounded 60°F relative density  $\gamma_{60}$  will fit between two reference fluids' 60°F relative densities as listed in Table 1. Choose the lowest density reference fluid that has a density value greater than or equal to  $\gamma_{60}$  and refer to this fluid using the subscript "2." Also use the next lowest density reference fluid and refer to this fluid using the subscript "1."

T24/5: Using Table 1, 60°F relative densities, compute the interpolation variable,  $\delta$ :

$$\delta = \frac{\gamma_{60} - \gamma_{60,1}}{\gamma_{60,2} - \gamma_{60,1}}$$

T24/6: From Table 1 critical temperatures, calculate the fluid critical temperature,  $T_c$ :

$$T_c = T_{c,1} + \delta(T_{c,2} - T_{c,1})$$

T24/7: Compute the fluid's reduced observed temperature,  $T_{r,x}$ :

$$T_{r,x} = \frac{T_x}{T_c}$$

If the reduced temperature  $T_{r,x}$  is greater than 1.0, then the fluid is at supercritical conditions and cannot exist as a liquid. Flag this result (possibly by returning a -1 for  $C_{TL}$ ) and exit this procedure.

T24/8: Compute the reduced temperature at 60°F,  $T_{r,60}$ :

$$T_{r,60} = \frac{519.67}{1.8T_c}$$

T24/9: From Table 1 critical compressibility factors,  $Z_c$ , and critical densities,  $\rho_c$ , calculate the scaling factor,  $h_2$ :

$$h_2 = \frac{Z_{c,1} \times \rho_{c,1}}{Z_{c,2} \times \rho_{c,2}}$$

T24/10: Calculate the saturation density for both reference fluids at 60°F using the 60° reduced temperature,  $T_{r,60}$ . For each fluid, the equations to calculate the saturation density at any reduced temperature  $T_r$  are:

$$\tau = 1 - T_r$$

$$\rho^{sat} = \rho_c \left( 1 + \frac{(k_1 \times \tau^{0.35}) + (k_3 \times \tau^2) + (k_4 \times \tau^3)}{1 + (k_2 \times \tau^{0.65})} \right)$$

where the  $k_1$ ,  $k_2$ ,  $k_3$ , and  $k_4$  parameters are different for each reference fluid and are listed in Table 1. Refer to the calculated density for the first reference fluid as  $\rho_{60,1}^{sat}$  and for the second reference fluid as  $\rho_{60,2}^{sat}$ .

T24/11: Calculate the interpolating factor  $X$ :

$$X = \frac{\rho_{60,1}^{sat}}{1 + \delta \left[ \left( \frac{\rho_{60,1}^{sat}}{h_2 \times \rho_{60,2}^{sat}} \right) - 1 \right]}$$

T24/12: Obtain the saturation density for both reference fluids at reduced observed temperature  $T_{r,x}$  using the procedure in Step T24/10. Refer to the calculated density for the first reference fluid as  $\rho_{60,1}^{sat}$  and that for the second reference fluid at  $\rho_{60,2}^{sat}$ .

T24/13: Calculate the Temperature Correction Factor at the observed temperature,  $C_{TL}$ :

$$C_{TL} = \frac{\rho_{x,1}^{sat}}{X \left[ 1 + \delta \left( \frac{\rho_{x,1}^{sat}}{h_2 \times \rho_{x,2}^{sat}} - 1 \right) \right]}$$

T24/14: Round the Temperature Correction Factor  $C_{TL}$  to the nearest 0.00001. Exit this procedure.

**Table 1: Reference Fluid Parameters**

No.	Fluid Name	$\gamma_{60}$	$T_c$	$Z_c$	$\rho_c$	$k_1$	$k_2$	$k_3$	$k_4$
1	EE (68/32) <sup>(1)</sup>	0.325022	298.11	0.27998	6.250	2.54616855327	-0.058244177754	0.803398090807	-0.745720314137
2	Ethane	0.355994	305.33	0.28220	6.870	1.89113042610	-0.370305782347	-0.544867288720	0.337876634952
3	EP (65/35) <sup>(2)</sup>	0.429277	333.67	0.28060	5.615	2.20970078464	-0.294253708172	-0.405754420098	0.319443433421
4	EP (35/65) <sup>(3)</sup>	0.470381	352.46	0.27930	5.110	2.25341981320	-0.266542138024	-0.372756711655	0.384734185665
5	Propane	0.507025	369.78	0.27626	5.000	1.96568366933	-0.327662435541	-0.417979702538	0.303271602831
6	i-Butane	0.562827	407.85	0.28326	3.860	2.04748034410	-0.289734363425	-0.330345036434	0.291757103132
7	n-Butane	0.584127	425.16	0.27536	3.920	2.03734743118	-0.299059145695	-0.418883095671	0.380367738748
8	i-Pentane	0.624285	460.44	0.27026	3.247	2.06541640707	-0.238366208840	-0.161440492247	0.258681568613
9	n-Pentane	0.631054	469.65	0.27235	3.200	2.11263474494	-0.261269413560	-0.291923445075	0.308344290017
10	i-Hexane	0.657167	498.05	0.26706	2.727	2.02382197871	-0.423550090067	-1.152810982570	0.950139001678
11	n-Hexane	0.664064	507.35	0.26762	2.704	2.17134547773	-0.232997313405	-0.267019794036	0.378629524102
12	n-Heptane	0.688039	540.15	0.26312	2.315	2.19775333433	-0.275056764147	-0.447144095029	0.493770995799

Table Notes:

$\gamma_{60}$  is the fluid relative density at 60°F and saturation pressure

$T_c$  is the fluid critical temperature in Kelvin

$Z_c$  is the fluid critical compressibility factor

$\rho_c$  is the fluid critical density in gram-moles per liter


$k_1$ ,  $k_2$ ,  $k_3$ , and  $k_4$  are saturation density fitting parameters

(1) EE (68/32) denotes a 68 mole % ethane + 32 % ethylene mixture

(2) EP (65/35) denotes a 65 mole % ethane + 35 % propane mixture

(3) EP (35/65) denotes a 35 mole % ethane + 65 % propane mixture

**Figure 1. Flow Chart of Implementation Procedure for Table 24**





### 5.1.1.4 Examples for Section 5.1.1 (Table 24E)

(See Table 1 for properties of the Reference Fluids)

#### Example 24/1 – Utilize EE (68/32) and Ethane

```

Input Data
Relative density @ 60°F RD60 ... 0.350130
Observed temperature Tf, °F .... -48.0200
Computed Data – last digit is rounded
T24/1
Input Data – rounded
RD60, rounded to 0.0001 ..... 0.3501
Tf, °F, rounded to 0.1 ..... -48.0
T24/2
Tx, Kelvin ..... 228.705555555556
T24/3
Input data within range
T24/4
Reference Fluid 1 ..... EE (68/32)
Reference Fluid 2 ..... Ethane
T24/5
Delta ..... 0.809699083043
T24/6
Critical temperature Tc ..... 303.956027379569
T24/7
Reduced observed temp. Tr,x .... 0.752429742971
T24/8
Reduced temp. at 60°F Tr,60 .... 0.949826716859
T24/9
Scaling factor h2 ..... 0.902595741301
T24/10
Tau for fluid at 60°F ..... 0.050173283141
Sat den fluid 1 at 60°F ..... 11.892882208216
Sat den fluid 2 at 60°F ..... 11.673968376914
T24/11
Interpolating factor X ..... 10.770572039296
T24/12
Tau for fluid at obs. temp. .... 0.247570257029
Sat den fluid 1 at obs. temp. .. 16.490243357324
Sat den fluid 2 at obs. temp. .. 16.012272020935
T24/13
CTL ..... 1.374174158511
T24/14
CTL rounded ..... 1.37417

```

**Example 24/2 – Utilize Ethane and EP (65/35)**

Input Data  
 Relative density @ 60°F RD60 ... 0.399950  
 Observed temperature Tf, °F .... 24.9500  
 Computed Data – last digit is rounded  
 T24/1  
 Input Data – rounded  
 RD60, rounded to 0.0001 ..... 0.4000  
 Tf, °F, rounded to 0.1 ..... 25.0  
 T24/2  
 Tx, Kelvin ..... 269.261111111111  
 T24/3  
 Input data within range  
 T24/4  
 Reference Fluid 1 ..... Ethane  
 Reference Fluid 2 ..... EP (65/35)  
 T24/5  
 Delta ..... 0.600493975410  
 T24/6  
 Critical temperature Tc ..... 322.347999263131  
 T24/7  
 Reduced observed temp. Tr,x .... 0.835311873276  
 T24/8  
 Reduced temp. at 60°F Tr,60 .... 0.895633154899  
 T24/9  
 Scaling factor h2 ..... 1.230484986694  
 T24/10  
 Tau for fluid at 60°F ..... 0.104366845101  
 Sat den fluid 1 at 60°F ..... 13.268022876946  
 Sat den fluid 2 at 60°F ..... 11.625034524899  
 T24/11  
 Interpolating factor X ..... 13.871545440974  
 T24/12  
 Tau for fluid at obs. temp. .... 0.164688126724  
 Sat den fluid 1 at obs. temp. .. 14.572475327916  
 Sat den fluid 2 at obs. temp. .. 12.816926793350  
 T24/13  
 CTL ..... 1.100764647588  
 T24/14  
 CTL rounded ..... 1.10076

**Example 24/3 – Utilize EP (65/35) and EP (35/65)**

Input Data  
 Relative density @ 60°F RD60 ... 0.451530  
 Observed temperature Tf, °F .... 87.4200  
 Computed Data – last digit is rounded  
 T24/1  
 Input Data – rounded  
 RD60, rounded to 0.0001 ..... 0.4515  
 Tf, °F, rounded to 0.1 ..... 87.4  
 T24/2  
 Tx, Kelvin ..... 303.927777777778  
 T24/3  
 Input data within range  
 T24/4  
 Reference Fluid 1 ..... EP (65/35)  
 Reference Fluid 2 ..... EP (35/65)  
 T24/5  
 Delta ..... 0.5406529777812  
 T24/6  
 Critical temperature Tc ..... 343.828869453095  
 T24/7  
 Reduced observed temp. Tr,x .... 0.883950723106  
 T24/8  
 Reduced temp. at 60°F Tr,60 .... 0.839678052674  
 T24/9  
 Scaling factor h2 ..... 1.103940309258  
 T24/10  
 Tau for fluid at 60°F ..... 0.160321947326  
 Sat den fluid 1 at 60°F ..... 12.739470807395  
 Sat den fluid 2 at 60°F ..... 11.668538966703  
 T24/11  
 Interpolating factor X ..... 12.815798776833  
 T24/12  
 Tau for fluid at obs. temp. .... 0.116049276894  
 Sat den fluid 1 at obs. temp. .. 11.880371290411  
 Sat den fluid 2 at obs. temp. .. 10.885682581443  
 T24/13  
 CTL ..... 0.932749411288  
 T24/14  
 CTL rounded ..... 0.93275

**Example 24/4 – Utilize EP (35/65) and Propane**

Input Data  
 Relative density @ 60°F RD60 ... 0.490400  
 Observed temperature Tf, °F .... 184.9700  
 Computed Data – last digit is rounded  
 T24/1  
 Input Data – rounded  
 RD60, rounded to 0.0001 ..... 0.4904  
 Tf, °F, rounded to 0.1 ..... 185.0  
 T24/2  
 Tx, Kelvin ..... 358.150000000000  
 T24/3  
 Input data within range  
 T24/4  
 Reference Fluid 1 ..... EP (35/65)  
 Reference Fluid 2 ..... Propane  
 T24/5  
 Delta ..... 0.546310446458  
 T24/6  
 Critical temperature Tc ..... 361.922096932649  
 T24/7  
 Reduced observed temp. Tr,x .... 0.989577599808  
 T24/8  
 Reduced temp. at 60°F Tr,60 .... 0.797700825682  
 T24/9  
 Scaling factor h2 ..... 1.033246217331  
 T24/10  
 Tau for fluid at 60°F ..... 0.202299174318  
 Sat den fluid 1 at 60°F ..... 12.309519597134  
 Sat den fluid 2 at 60°F ..... 11.272394278161  
 T24/11  
 Interpolating factor X ..... 11.938610116810  
 T24/12  
 Tau for fluid at obs. temp. .... 0.010422400192  
 Sat den fluid 1 at obs. temp. .. 7.473276954765  
 Sat den fluid 2 at obs. temp. .. 7.023541210265  
 T24/13  
 CTL ..... 0.615949186930  
 T24/14  
 CTL rounded ..... 0.61595

**Example 24/5 – Utilize Propane and i-Butane**

Input Data  
 Relative density @ 60°F RD60 ... 0.540020  
 Observed temperature Tf, °F .... 155.0400  
 Computed Data – last digit is rounded  
 T24/1  
 Input Data – rounded  
 RD60, rounded to 0.0001 ..... 0.5400  
 Tf, °F, rounded to 0.1 ..... 155.0  
 T24/2  
 Tx, Kelvin ..... 341.483333333333  
 T24/3  
 Input data within range  
 T24/4  
 Reference Fluid 1 ..... Propane  
 Reference Fluid 2 ..... i-Butane  
 T24/5  
 Delta ..... 0.590928640551  
 T24/6  
 Critical temperature Tc ..... 392.276653345758  
 T24/7  
 Reduced observed temp. Tr,x .... 0.870516586753  
 T24/8  
 Reduced temp. at 60°F Tr,60 .... 0.735974351502  
 T24/9  
 Scaling factor h2 ..... 1.263326064155  
 T24/10  
 Tau for fluid at 60°F ..... 0.264025648498  
 Sat den fluid 1 at 60°F ..... 12.016437691588  
 Sat den fluid 2 at 60°F ..... 9.429772887863  
 T24/11  
 Interpolating factor X ..... 11.955024717591  
 T24/12  
 Tau for fluid at obs. temp. .... 0.129483413247  
 Sat den fluid 1 at obs. temp. .. 10.227566043346  
 Sat den fluid 2 at obs. temp. .. 8.025028872910  
 T24/13  
 CTL ..... 0.851071799690  
 T24/14  
 CTL rounded ..... 0.85107

**Example 24/6 – Utilize i-Butane and n-Butane**

Input Data  
 Relative density @ 60°F RD60 ... 0.569980  
 Observed temperature Tf, °F .... 3.0330  
 Computed Data – last digit is rounded  
 T24/1  
 Input Data – rounded  
 RD60, rounded to 0.0001 ..... 0.5700  
 Tf, °F, rounded to 0.1 ..... 3.0  
 T24/2  
 Tx, Kelvin ..... 257.038888888889  
 T24/3  
 Input data within range  
 T24/4  
 Reference Fluid 1 ..... i-Butane  
 Reference Fluid 2 ..... n-Butane  
 T24/5  
 Delta ..... 0.336760563380  
 T24/6  
 Critical temperature Tc ..... 413.679325352113  
 T24/7  
 Reduced observed temp. Tr,x .... 0.621348163025  
 T24/8  
 Reduced temp. at 60°F Tr,60 .... 0.697896988954  
 T24/9  
 Scaling factor h2 ..... 1.012944464538  
 T24/10  
 Tau for fluid at 60°F ..... 0.302103011046  
 Sat den fluid 1 at 60°F ..... 9.757836502218  
 Sat den fluid 2 at 60°F ..... 9.883346486657  
 T24/11  
 Interpolating factor X ..... 9.841741258063  
 T24/12  
 Tau for fluid at obs. temp. .... 0.378651836975  
 Sat den fluid 1 at obs. temp. .. 10.367065629858  
 Sat den fluid 2 at obs. temp. .. 10.496815949474  
 T24/13  
 CTL ..... 1.062314380669  
 T24/14  
 CTL rounded ..... 1.06231

**Example 24/7 – Utilize n-Butane and i-Pentane**

Input Data  
 Relative density @ 60°F RD60 ... 0.599970  
 Observed temperature Tf, °F .... 110.0400  
 Computed Data – last digit is rounded  
 T24/1  
 Input Data – rounded  
 RD60, rounded to 0.0001 ..... 0.6000  
 Tf, °F, rounded to 0.1 ..... 110.0  
 T24/2  
 Tx, Kelvin ..... 316.483333333333  
 T24/3  
 Input data within range  
 T24/4  
 Reference Fluid 1 ..... n-Butane  
 Reference Fluid 2 ..... i-Pentane  
 T24/5  
 Delta ..... 0.395263708352  
 T24/6  
 Critical temperature Tc ..... 439.104903630659  
 T24/7  
 Reduced observed temp. Tr,x .... 0.720746524843  
 T24/8  
 Reduced temp. at 60°F Tr,60 .... 0.657486521258  
 T24/9  
 Scaling factor h2 ..... 1.230050265162  
 T24/10  
 Tau for fluid at 60°F ..... 0.342513478742  
 Sat den fluid 1 at 60°F ..... 10.214309417120  
 Sat den fluid 2 at 60°F ..... 8.446076234558  
 T24/11  
 Interpolating factor X ..... 10.282689503192  
 T24/12  
 Tau for fluid at obs. temp. .... 0.279253475157  
 Sat den fluid 1 at obs. temp. .. 9.687510842155  
 Sat den fluid 2 at obs. temp. .. 8.011335247961  
 T24/13  
 CTL ..... 0.948465346003  
 T24/14  
 CTL rounded ..... 0.94847

**Example 24/8 – Utilize i-Pentane and n-Pentane**

```

Input Data
Relative density @ 60°F RD60 ... 0.625020
Observed temperature Tf, °F .... 169.9700
  Computed Data – last digit is rounded
T24/1
  Input Data – rounded
RD60, rounded to 0.0001 ..... 0.6250
Tf, °F, rounded to 0.1 ..... 170.0
T24/2
Tx, Kelvin ..... 349.816666666667
T24/3
Input data within range
T24/4
Reference Fluid 1 ..... i-Pentane
Reference Fluid 2 ..... n-Pentane
T24/5
Delta ..... 0.105628600975
T24/6
Critical temperature Tc ..... 461.412839414980
T24/7
Reduced observed temp. Tr,x .... 0.758142463288
T24/8
Reduced temp. at 60°F Tr,60 .... 0.625699007253
T24/9
Scaling factor h2 ..... 1.006900839912
T24/10
Tau for fluid at 60°F ..... 0.374300992747
Sat den fluid 1 at 60°F ..... 8.652500418110
Sat den fluid 2 at 60°F ..... 8.668052899178
T24/11
Interpolating factor X ..... 8.660400031891
T24/12
Tau for fluid at obs. temp. .... 0.241857536712
Sat den fluid 1 at obs. temp. .. 7.734059015744
Sat den fluid 2 at obs. temp. .. 7.744880148272
T24/13
CTL ..... 0.893815224960
T24/14
CTL rounded ..... 0.89382

```



**Example 24/9 – Utilize n-Pentane and i-Hexane**

Input Data  
 Relative density @ 60°F RD60 ... 0.640040  
 Observed temperature Tf, °F .... -12.0200  
 Computed Data – last digit is rounded  
 T24/1  
 Input Data – rounded  
 RD60, rounded to 0.0001 ..... 0.6400  
 Tf, °F, rounded to 0.1 ..... -12.0  
 T24/2  
 Tx, Kelvin ..... 248.705555555556  
 T24/3  
 Input data within range  
 T24/4  
 Reference Fluid 1 ..... n-Pentane  
 Reference Fluid 2 ..... i-Hexane  
 T24/5  
 Delta ..... 0.342587982997  
 T24/6  
 Critical temperature Tc ..... 479.379498717114  
 T24/7  
 Reduced observed temp. Tr,x .... 0.518807241906  
 T24/8  
 Reduced temp. at 60°F Tr,60 .... 0.602248440595  
 T24/9  
 Scaling factor h2 ..... 1.196694721271  
 T24/10  
 Tau for fluid at 60°F ..... 0.397751559405  
 Sat den fluid 1 at 60°F ..... 8.816158414827  
 Sat den fluid 2 at 60°F ..... 7.499847998980  
 T24/11  
 Interpolating factor X ..... 8.869948165069  
 T24/12  
 Tau for fluid at obs. temp. .... 0.481192758094  
 Sat den fluid 1 at obs. temp. .. 9.321161815695  
 Sat den fluid 2 at obs. temp. .. 7.929963121410  
 T24/13  
 CTL ..... 1.057304685863  
 T24/14  
 CTL rounded ..... 1.05730

**Example 24/10 – Utilize i-Hexane and n-Hexane**

Input Data  
 Relative density @ 60°F RD60 ... 0.660033  
 Observed temperature Tf, °F .... 177.0450  
 Computed Data – last digit is rounded  
 T24/1  
 Input Data – rounded  
 RD60, rounded to 0.0001 ..... 0.6600  
 Tf, °F, rounded to 0.1 ..... 177.0  
 T24/2  
 Tx, Kelvin ..... 353.705555555556  
 T24/3  
 Input data within range  
 T24/4  
 Reference Fluid 1 ..... i-Hexane  
 Reference Fluid 2 ..... n-Hexane  
 T24/5  
 Delta ..... 0.410758300710  
 T24/6  
 Critical temperature Tc ..... 501.870052196607  
 T24/7  
 Reduced observed temp. Tr,x .... 0.704775178370  
 T24/8  
 Reduced temp. at 60°F Tr,60 .... 0.575259580228  
 T24/9  
 Scaling factor h2 ..... 1.006395599121  
 T24/10  
 Tau for fluid at 60°F ..... 0.424740419772  
 Sat den fluid 1 at 60°F ..... 7.641170665754  
 Sat den fluid 2 at 60°F ..... 7.665708531720  
 T24/11  
 Interpolating factor X ..... 7.671217510578  
 T24/12  
 Tau for fluid at obs. temp. .... 0.295224821630  
 Sat den fluid 1 at obs. temp. .. 6.925133823039  
 Sat den fluid 2 at obs. temp. .. 6.945363609083  
 T24/13  
 CTL ..... 0.906185214223  
 T24/14  
 CTL rounded ..... 0.90619

**Example 24/11 – Utilize n-Hexane and n-Heptane**

Input Data  
 Relative density @ 60°F RD60 ... 0.670042  
 Observed temperature Tf, °F .... 181.0300  
 Computed Data – last digit is rounded  
 T24/1  
 Input Data – rounded  
 RD60, rounded to 0.0001 ..... 0.6700  
 Tf, °F, rounded to 0.1 ..... 181.0  
 T24/2  
 Tx, Kelvin ..... 355.927777777778  
 T24/3  
 Input data within range  
 T24/4  
 Reference Fluid 1 ..... n-Hexane  
 Reference Fluid 2 ..... n-Heptane  
 T24/5  
 Delta ..... 0.247591240876  
 T24/6  
 Critical temperature Tc ..... 515.470992700730  
 T24/7  
 Reduced observed temp. Tr,x .... 0.690490411328  
 T24/8  
 Reduced temp. at 60°F Tr,60 .... 0.560081090195  
 T24/9  
 Scaling factor h2 ..... 1.188010824747  
 T24/10  
 Tau for fluid at 60°F ..... 0.439918909805  
 Sat den fluid 1 at 60°F ..... 7.744857153990  
 Sat den fluid 2 at 60°F ..... 6.743069361289  
 T24/11  
 Interpolating factor X ..... 7.809053198722  
 T24/12  
 Tau for fluid at obs. temp. .... 0.309509588672  
 Sat den fluid 1 at obs. temp. .. 7.030188106398  
 Sat den fluid 2 at obs. temp. .. 6.111938115029  
 T24/13  
 CTL ..... 0.907404360428  
 T24/14  
 CTL rounded ..... 0.90740

**Example 24/12 – Reduced temperature  $T_{r,x}$  greater than 1**

Input Data  
 Relative density @ 60°F RD60 ... 0.350180  
 Observed temperature  $T_f$ , °F .... 195.0250  
 Computed Data – last digit is rounded  
 T24/1  
 Input Data – rounded  
 RD60, rounded to 0.0001 ..... 0.3502  
 $T_f$ , °F, rounded to 0.1 ..... 195.0  
 T24/2  
 $T_x$ , Kelvin ..... 363.705555555556  
 T24/3  
 Input data within range  
 T24/4  
 Reference Fluid 1 ..... EE (68/32)  
 Reference Fluid 2 ..... Ethane  
 T24/5  
 Delta ..... 0.812927805760  
 T24/6  
 Critical temperature  $T_c$  ..... 303.979338757587  
 T24/7  
 Reduced observed temp.  $T_{r,x}$  .... 1.196481172181  
 Reduced temperature  $T_{r,x}$  greater than 1.0, no solution

**Example 24/13 –  $T_f < \text{lower range limit}$** 

Input Data  
Relative density @ 60°F RD60 ... 0.500000  
Observed temperature  $T_f$ , °F .... -50.8500  
Computed Data – last digit is rounded  
T24/1  
Input Data – rounded  
RD60, rounded to 0.0001 ..... 0.5000  
 $T_f$ , °F, rounded to 0.1 ..... -50.9  
T24/2  
 $T_x$ , Kelvin ..... 227.094444444444  
T24/3  
 $T_x$  less than 227.15, no solution

**Example 24/14 – RD60 < lower range limit**

Input Data  
 Relative density @ 60°F RD60 ... 0.349940  
 Observed temperature Tf, °F .... 40.0000  
 Computed Data – last digit is rounded  
 T24/1  
 Input Data – rounded  
 RD60, rounded to 0.0001 ..... 0.3499  
 Tf, °F, rounded to 0.1 ..... 40.0  
 T24/2  
 Tx, Kelvin ..... 277.594444444444  
 T24/3  
 RD60 is less than 0.3500, no solution

**Example 24/15 –  $T_f >$  upper range limit**

Input Data  
Relative density @ 60°F RD60 ... 0.450000  
Observed temperature  $T_f$ , °F .... 199.4600  
Computed Data – last digit is rounded  
T24/1  
Input Data – rounded  
RD60, rounded to 0.0001 ..... 0.4500  
 $T_f$ , °F, rounded to 0.1 ..... 199.5  
T24/2  
 $T_x$ , Kelvin ..... 366.205555555556  
T24/3  
 $T_x$  greater than 366.15, no solution

**Example 24/16 – RD60 > upper range limit**

Input Data  
 Relative density @ 60°F RD60 ... 0.688070  
 Observed temperature Tf, °F .... 0.0000  
 Computed Data – last digit is rounded  
 T24/1  
 Input Data – rounded  
 RD60, rounded to 0.0001 ..... 0.6881  
 Tf, °F, rounded to 0.1 ..... 0.0  
 T24/2  
 Tx, Kelvin ..... 255.372222222222  
 T24/3  
 RD60 is greater than 0.6880, no solution



**Example 24/17 – Tf & RD60 = upper range limits**

Input Data  
 Relative density @ 60°F RD60 ... 0.688000  
 Observed temperature Tf, °F .... 199.4400  
 Computed Data – last digit is rounded  
 T24/1  
 Input Data – rounded  
 RD60, rounded to 0.0001 ..... 0.6880  
 Tf, °F, rounded to 0.1 ..... 199.4  
 T24/2  
 Tx, Kelvin ..... 366.150000000000  
 T24/3  
 Input data within range  
 T24/4  
 Reference Fluid 1 ..... n-Hexane  
 Reference Fluid 2 ..... n-Heptane  
 T24/5  
 Delta ..... 0.998373305527  
 T24/6  
 Critical temperature Tc ..... 540.096644421272  
 T24/7  
 Reduced observed temp. Tr,x .... 0.677934224887  
 T24/8  
 Reduced temp. at 60°F Tr,60 .... 0.534544249696  
 T24/9  
 Scaling factor h2 ..... 1.188010824747  
 T24/10  
 Tau for fluid at 60°F ..... 0.465455750304  
 Sat den fluid 1 at 60°F ..... 7.876480858049  
 Sat den fluid 2 at 60°F ..... 6.859355371549  
 T24/11  
 Interpolating factor X ..... 8.148529834765  
 T24/12  
 Tau for fluid at obs. temp. .... 0.322065775113  
 Sat den fluid 1 at obs. temp. .. 7.103375621618  
 Sat den fluid 2 at obs. temp. .. 6.176601533604  
 T24/13  
 CTL ..... 0.900466171184  
 T24/14  
 CTL rounded ..... 0.90047

**Example 24/18 – Tf & RD60 = lower range limits**

```

Input Data
Relative density @ 60°F RD60 ... 0.350000
Observed temperature Tf, °F .... -50.8000
  Computed Data – last digit is rounded
T24/1
  Input Data – rounded
RD60, rounded to 0.0001 ..... 0.3500
Tf, °F, rounded to 0.1 ..... -50.8
T24/2
Tx, Kelvin ..... 227.150000000000
T24/3
Input data within range
T24/4
Reference Fluid 1 ..... EE (68/32)
Reference Fluid 2 ..... Ethane
T24/5
Delta ..... 0.806470360325
T24/6
Critical temperature Tc ..... 303.932716001550
T24/7
Reduced observed temp. Tr,x .... 0.747369361839
T24/8
Reduced temp. at 60°F Tr,60 .... 0.949899567752
T24/9
Scaling factor h2 ..... 0.902595741301
T24/10
Tau for fluid at 60°F ..... 0.050100432248
Sat den fluid 1 at 60°F ..... 11.889940226938
Sat den fluid 2 at 60°F ..... 11.671295077352
T24/11
Interpolating factor X ..... 10.772124448866
T24/12
Tau for fluid at obs. temp. .... 0.252630638161
Sat den fluid 1 at obs. temp. .. 16.573069193167
Sat den fluid 2 at obs. temp. .. 16.091771523334
T24/13
CTL ..... 1.381375977418
T24/14
CTL rounded ..... 1.38138

```

### 5.1.2 Implementation Procedure for Table 23E (60°F Basis)

This section presents the implementation procedure T23 for calculating the relative densities of NGLs and LPGs at a base conditions of 60°F from known temperatures and densities.

In the past, a hydrometer correction option was allowed so as to be able to correct for the expansion of the glass comprising a hydrometer stem. The hydrometer correction previously took the following form:

Observed densities determined by a glass hydrometer require correction for the effect of temperature on the instrument. Readings from most density meters do not. If the density was determined with a glass hydrometer, then a correction for the expansion or contraction of the glass must be made. Call the rounded observed relative density the uncorrected relative density  $\gamma_x^*$ . Calculate the corrected relative density,  $\gamma_x$ , from:

$$\gamma_x = [1 - 0.00001278(T_F - 60) - 0.0000000062(T_F - 60)^2] \gamma_x^*$$

The value of  $\gamma_x$  was not rounded prior to use<sup>[10]</sup>.

Density readings must be corrected for the effect of temperature on the instrument prior to entering the density into the following implementation procedure.

#### 5.1.2.1 Inputs and Outputs

Inputs: Relative density at observed temperature,  $\gamma_x$   
Observed temperature,  $T_F$  (°F)

Output: Relative density at 60°F,  $\gamma_{60}$

#### 5.1.2.2 Outline of Calculations

The calculations are performed using an extended two-fluid corresponding states equation. Two reference fluids are found that are slightly denser and slightly less dense than the observed fluid by comparing their densities at the observed temperature. Iteration must be performed to determine the value of the fluid's relative density at 60°F such that when the Temperature Correction Factor is applied, the observed relative density is obtained. The “guessed” value for the fluid's relative density at 60°F is constrained to lie between the relative densities at 60°F of these two reference fluids (as upper and lower bounds). As the iterations progress, these upper and lower bounds are “brought together” based upon intermediate calculations.

See Figure 2 for a general flow chart of the calculation procedure.

### 5.1.2.3 T23 Implementation Procedure

#### T23/Step Number      Operation/Procedure at that step

T23/1: Round the relative density  $\gamma_x$  to the nearest 0.0001 and round the observed temperature  $T_F$  to the nearest 0.1°F.

Temperature rounding examples follow: -0.05 rounds to -0.1; -0.049 rounds to 0.0, -0.051 rounds to -0.1. Density rounding examples follow: 0.35555 rounds to 0.3556, 0.40289 rounds to 0.4029.

T23/2: Convert the rounded observed temperature to units of Kelvin,  $T_x$ :

$$T_x = \frac{T_F + 459.67}{1.8}$$

T23/3: Check the values of temperature and relative density to ensure that they are in the proper range. The observed temperature  $T_x$  and relative density  $\gamma_x$  must fall within the following boundaries:

Temperature between 227.15 and 366.15 K, inclusive (equivalent to -46 to 93°C, or -50.8 to 199.4°F)

Relative density between 0.2100 and 0.7400 inclusive.

If these values do not fall in these ranges, then the standard does not apply. Flag this result (possibly by returning a -1 for  $\gamma_{60}$ ) and exit this procedure.

T23/4: Reference fluids must be chosen to perform the density calculations. As written here, this is done in two separate steps: T23/4 to compute the density for each reference fluid at the observed temperature and T23/5 to determine which two reference fluids are to be used. However, Steps 4 and 5 could be combined into a single step (e.g., using a binary search technique).

The reference fluids' densities are to be calculated at the observed temperature,  $T_x$ . Use the reference fluids' parameter values from Table 1. First, use each reference fluid's critical temperature,  $T_{c,ref}$ , to compute its reduced observed temperature,  $T_{r,x}$ :

$$T_{r,x} = \frac{T_x}{T_{c,ref}}$$

If  $T_{r,x} \leq 1$ , calculate the saturation density for this reference fluid at this reduced temperature  $T_{r,x}$ . Use the procedure as described in Section 5.1.1.3 Step T24/10. Refer to this calculated density for the reference fluid as  $\rho_{x,ref}^{sat}$ . Repeat this for 60°F using the reduced temperature  $T_{r,60}$ :

$$T_{r,60} = \frac{519.67}{1.8T_{c,ref}}$$

Refer to this calculated density as  $\rho_{60,ref}^{sat}$ . Finally, calculate its relative density at the observation temperature,  $\gamma_{x,ref}$ , as:

$$\gamma_{x,ref} = \gamma_{60,ref} \left( \frac{\rho_{x,ref}^{sat}}{\rho_{60,ref}^{sat}} \right)$$

where  $\gamma_{60,ref}$  is the reference fluid's relative density at 60°F

If  $T_{r,x} > 1$ , this reference fluid will not be a liquid at this observed temperature and no value of  $\gamma_{x,ref}$  can be calculated. It is suggested that this type of “no value” case be flagged by returning a  $-1$  value for  $\gamma_{x,ref}$ .

T23/5: Determine the two adjacent reference fluids to be used for the calculations. Choose the lowest density reference fluid that has a density value greater than  $\gamma_x$  and refer to this fluid using the subscript “2”. Also use the next lowest density reference fluid and refer to this fluid using the subscript “1” (even though this reference fluid may not exist as a liquid at the observation temperature). If  $\gamma_x$  is below that for “EE 68/32” (the least dense reference fluid), then set “EE 68/32” as fluid “1” and “ethane” as fluid “2”. If  $\gamma_x$  is above that for “n-heptane” (the most dense reference fluid), then set “n-hexane” as fluid “1” and “n-heptane” as fluid “2”.

T23/6: Initialize the bounds on the iteration for the observed fluid's 60°F relative density. For most cases, the observed fluid's 60°F relative density should be between the two reference fluids “1” and “2”,  $\gamma_{60,1}$  and  $\gamma_{60,2}$ .

Initialize the upper bound for the observed fluid's 60°F relative density,  $\gamma_{60,high}$ , as:

$$\gamma_{60,high} = \gamma_{60,2}$$

and the corresponding relative density at the observed temperature,  $\gamma_{x,high}$ , as:

$$\gamma_{x,high} = \gamma_{x,2}$$

However, if the relative density  $\gamma_x$  is greater than the reference fluid “2” relative density at the observed temperature  $\gamma_{x,2}$ , then no answer exists. If this is the case, then  $\gamma_{x,60}$  should be flagged (perhaps by being set to  $-1$ ) and exit this procedure.

Initialize the lower bound for the observed fluid's 60°F relative density,  $\gamma_{60,low}$ , as:

$$\gamma_{60,low} = \gamma_{60,1}$$

and the corresponding relative density at the observed temperature,  $\gamma_{x,low}$ , as:

$$\gamma_{x,low} = \gamma_{x,1}$$

However, if reference fluid “1” is not a liquid at the observed temperature (i.e.,  $T_{r,x} > 1$  for the reference fluid), then set the lower boundary convergence 60°F relative density by the following equation:

$$\gamma_{60,low} = \left[ \frac{T_x - T_{c,1}}{T_{c,2} - T_{c,1}} \right] (\gamma_{60,2} - \gamma_{60,1}) + \gamma_{60,1}$$

Note that this equation was derived from equations in Section 5.1 at a reduced temperature of 1.0.

If  $\gamma_{60,low}$  is less than 0.3500, then set it equal to 0.3500.

If  $\gamma_{60,low}$  has been reset using the preceding technique then recalculate the corresponding  $\gamma_{x,low}$  value. Use the procedure in Section 5.1.1.3 Steps T24/4 through T24/13 to calculate its Temperature Correction Factor, CTL. Skip Step 24/14 to avoid rounding the output CTL. The relative density at the observed temperature will be:

$$\gamma_{x,low} = C_{TL} \times \gamma_{60,low}$$

At this point, upper and lower convergence bounds have been set. After one more check, the iterative process to determine a 60°F relative density  $\gamma_{60}$  can begin. If the observed relative density  $\gamma_x$  is less than the lower limit  $\gamma_{x,low}$ , then no answer exists. If this is the case, then  $\gamma_{60}$  should be flagged (perhaps by being set to -1) and exit this procedure.

T23/7: Calculate an intermediate 60°F relative density value,  $\gamma_{60,mid}$  If a value for  $\gamma_{60,low}$  exists, then calculate  $\gamma_{60,mid}$  from:

$$\delta = \frac{\gamma_x - \gamma_{x,low}}{\gamma_{x,high} - \gamma_{x,low}}$$

If  $\delta$  is less than 0.001 then set it equal to 0.001; if  $\delta$  is greater than 0.999 then set it equal to 0.999. Calculate the intermediate 60°F relative density value:

$$\gamma_{60,mid} = \gamma_{60,low} + \delta (\gamma_{60,high} - \gamma_{60,low})$$

However, if a value for  $\gamma_{x,low}$  does not exist, then calculate  $\gamma_{60,mid}$  from:

$$\gamma_{60,mid} = \frac{\gamma_{60,high} + \gamma_{60,low}}{2}$$

Calculate the Temperature Correction Factor,  $C_{TL}$ , using this value of  $\gamma_{60,mid}$  and  $T_x$ , unrounded, and the procedure from Section 5.1.1.3 Steps T24/5 to T24/13. (Do not round this  $C_{TL}$  value.) The relative density,  $\gamma_{x,mid}$ , at observed temperature,  $T_x$ , will be:

$$\gamma_{x,mid} = C_{TL} \times \gamma_{60,mid}$$

T23/8: Check for convergence of the 60°F relative density. The calculations will be considered converged if either occurs:

- If  $\gamma_x$  is between  $\gamma_{x,low}$  and  $\gamma_{x,mid}$  and the difference between  $\gamma_{60,low}$  and  $\gamma_{60,mid}$  is less than 0.00000001 ( $10^{-8}$ ).
- If  $\gamma_x$  is between  $\gamma_{x,high}$  and  $\gamma_{x,mid}$  and the difference between  $\gamma_{60,high}$  and  $\gamma_{60,mid}$  is less than 0.00000001 ( $10^{-8}$ ).

If convergence has been achieved, set:

$$\gamma_{60} = \gamma_{60,mid}$$

and skip to Step T23/12.

T23/9: There are three pairs of relative density values:  $(\gamma_{x,low}, \gamma_{60,low})$ ,  $(\gamma_{x,mid}, \gamma_{60,mid})$  and  $(\gamma_{x,high}, \gamma_{60,high})$ . A quadratic equation can be fit through these three points. This quadratic equation should be a good approximation to the actual relationship between  $\gamma_x$  and  $\gamma_{60}$ . Using the value of the observed relative density  $\gamma_x$  in the quadratic equation should give a very good estimate to  $\gamma_{60}$ .

Calculate the parameters for the quadratic equation by:

$$\alpha = (\gamma_{60,high} - \gamma_{60,low})$$

$$\beta = \gamma_{x,high}^2 - \gamma_{x,low}^2$$

$$\phi = \frac{\gamma_{x,high} - \gamma_{x,low}}{\gamma_{x,mid} - \gamma_{x,low}}$$

$$A = \frac{\alpha - \phi(\gamma_{60,mid} - \gamma_{60,low})}{\beta - \phi(\gamma_{x,mid}^2 - \gamma_{x,low}^2)}$$

$$B = \frac{\alpha - A\beta}{\gamma_{x,high} - \gamma_{x,low}}$$

$$C = \gamma_{60,low} - B\gamma_{x,low} - A\gamma_{x,low}^2$$

Using these values of  $A$ ,  $B$ , and  $C$ , calculate the associated value  $\gamma_{60,trial}$  using:

$$\gamma_{60,trial} = A\gamma_x^2 + B\gamma_x + C$$

This value of  $\gamma_{60,trial}$  may have to be adjusted if it goes outside of the range of  $\gamma_{60,low}$  or  $\gamma_{60,high}$ . If  $\gamma_{60,trial} < \gamma_{60,low}$ , then reset the value as:

$$\gamma_{60,trial} = \gamma_{60,low} + \frac{(\gamma_{60,mid} - \gamma_{60,low})(\gamma_x - \gamma_{x,low})}{(\gamma_{x,mid} - \gamma_{x,low})}$$

If  $\gamma_{60,trial} > \gamma_{60,high}$  then reset the value as:

$$\gamma_{60,trial} = \gamma_{60,mid} + \frac{(\gamma_{60,high} - \gamma_{60,mid})(\gamma_x - \gamma_{x,mid})}{(\gamma_{x,high} - \gamma_{x,mid})}$$

Finally, calculate the Temperature Correction Factor,  $C_{TL}$ , using the value of  $\gamma_{60,trial}$  and the procedure from Section 5.1.1.3 Steps T24/4 to T24/13. Skip Step 24/14 to avoid rounding the output  $C_{TL}$ . The relative density at observed temperature,  $\gamma_{x,trial}$ , will be:

$$\gamma_{x,trial} = C_{TL} \times \gamma_{60,trial}$$

T23/10: Check for convergence of the 60°F relative density. The calculations will be considered converged if the absolute difference between  $\gamma_{x,trial}$  and  $\gamma_x$  is less than 0.00000001 ( $10^{-8}$ ). If converged, set:

$$\gamma_{60} = \gamma_{60,trial}$$

and skip to Step T23/12.

T23/11: The calculation has not yet converged, so the iteration bounds must be updated.

If  $\gamma_{x,trial} > \gamma_x$  then reset the upper bounds to:

$$\gamma_{x,high} = \gamma_{x,trial}$$

$$\gamma_{60,high} = \gamma_{60,trial}$$



Also, if  $\gamma_{x,mid} < \gamma_x$  then reset the lower bounds to:

$$\gamma_{x,low} = \gamma_{x,mid}$$

$$\gamma_{60,low} = \gamma_{60,mid}$$

Or if  $\gamma_{x,trial} < \gamma_x$  then reset the lower bounds to:

$$\gamma_{x,low} = \gamma_{x,trial}$$

$$\gamma_{60,low} = \gamma_{60,trial}$$

Also, if  $\gamma_{x,mid} > \gamma_x$  then reset the upper bounds to:

$$\gamma_{x,high} = \gamma_{x,mid}$$


$$\gamma_{60,high} = \gamma_{60,mid}$$

Return to Step T23/7 and continue iterations. Do at most 10 iterations. If 10 iterations are reached, then no solution can be found. Flag this result (possibly by returning a  $-1$  for  $\gamma_{60}$ ) and exit this procedure.


Note: At this time, all known cases have been found to require less than 10 iterations.

T23/12: Round the 60°F relative density value  $\gamma_{60}$  to the nearest 0.0001. If the value is less than 0.3500 or greater than 0.6880, then the result is outside the scope of this standard. Flag result (possibly by returning a  $-1$  for  $\gamma_{60}$ ). Exit this procedure.

**Figure 2. Flow Chart of Implementation Procedure for Table 23**



**Figure 2. Continued: Flow Chart of Implementation Procedure for Table 23**



### 5.1.2.4 Examples for Section 5.1.2 (Table 23E)

(See Table 1 for properties of the Reference Fluids)

#### Example 23/1 – Utilize i-Pentane and n-Pentane

```

Input Data
Relative density @ obs. temp. ... 0.67432
Observed temperature Tf, °F .... -23.33
Computed Data – last digit is rounded
T23/1
Input Data – rounded
RDtf, observed rel. density .... 0.6743
Tf, °F ..... -23.3
T23/2
Tx, Kelvin ..... 242.427777777778
T23/3
RDtf and Tf are within range, continue
T23/4
RDtf for Fluid 1 ..... 0.668992076725
RDtf for Fluid 2 ..... 0.674300900334
T23/5
Reference Fluid 1 ..... i-Pentane
Reference Fluid 2 ..... n-Pentane
Tr, x for Fluid 1 ..... 0.526513286808
Tr, x for Fluid 2 ..... 0.516188177958
Tr, 60 for Fluid 1 ..... 0.627021013716
Tr, 60 for Fluid 2 ..... 0.614724913352
T23/6
Upper boundary RD60, high ..... 0.631054000000
Upper boundary RDtf, high ..... 0.674300900334
Lower boundary RD60, low ..... 0.624285000000
Lower boundary RDtf, low ..... 0.668992076725

Iteration steps
Pass 1
T23/7
Delta ..... 0.999000000000
RD60, mid ..... 0.631047231000
CTL ..... 1.068534241176
RDtf, mid ..... 0.674295574123
T23/8
Continue
T23/9
Alpha ..... 0.006769000000
Beta ..... 0.007131305470
Phi ..... 1.001004282842
A ..... -0.784857658731
B ..... 2.329340853270
C ..... -0.582762216726
RD60, Trial ..... 0.631052855782
CTL, Trial ..... 1.068531730459
RDtf, Trial ..... 0.674300000000
T23/10
Converged
T23/11 not needed, convergence already achieved
T23/12
RD60 (RD60, Trial rounded) ..... 0.6311

```

**Example 23/2 – Steps 9 & 11, Adjust RD60Trial, reset hi+low/hi boundaries**

Input Data  
 Relative density @ obs. temp. ... 0.24573  
 Observed temperature Tf, °F .... 189.98  
 Computed Data – last digit is rounded

T23/1  
 Input Data – rounded  
 RDtf, observed rel. density .... 0.2457  
 Tf, °F ..... 190.0  
 T23/2  
 Tx, Kelvin ..... 360.927777777778  
 T23/3  
 RDtf and Tf are within range, continue  
 T23/4  
 RDtf for Fluid 1 ..... -0.470381000000  
 RDtf for Fluid 2 ..... 0.341646473673  
 T23/5  
 Reference Fluid 1 ..... EP (35/65)  
 Reference Fluid 2 ..... Propane  
 Tr, x for Fluid 1 ..... 1.024024790835  
 Tr, x for Fluid 2 ..... 0.976060840981  
 Tr, 60 for Fluid 1 ..... 0.819115801951  
 Tr, 60 for Fluid 2 ..... 0.780749514726  
 T23/6  
 Upper boundary RD60, high ..... 0.507025000000  
 Upper boundary RDtf, high ..... 0.341646473673  
 Lower boundary RD60, low ..... 0.488296314601  
 Lower boundary RDtf, low ..... 0.209990106855

Iteration steps	Pass 1	Pass 2	Pass 3	Pass 4
T23/7				
Del ta	0.271235596182	0.601796434584	0.126556348248	0.004138210954
RD60, mid	0.493376200751	0.489664201999	0.488882034911	0.488850690456
CTL	0.587375829009	0.529645485907	0.504021249568	0.502607558267
RDtf, mid	0.289797254929	0.259348434199	0.246406934127	0.245700051887
T23/8	Conti nue	Conti nue	Conti nue	Conti nue
T23/9				
Al pha	0.018728685399	0.002273006817	8.95498051064e-04	3.14747042172e-05
Beta	0.072626467996	0.028442228403	0.007860987453	3.49330713583e-04
Phi	1.649681388134	1.202204934943	5.820815799273	237.456099384553
A	1.515978266954	1.061284960315	1.166129963841	1.088675802961
B	-0.694014759007	-0.470388528249	-0.529337816619	-0.491403133721
C	0.567184205356	0.540274994825	0.548511356689	0.543866723826
RD60, Tri al	0.488182097917	0.488768703948	0.488850560207	0.488850688195
RD60, Tri al adj usted				
RD60, Tri al	0.490569321418	not changed	not changed	not changed
CTL, Tri al	0.549012993292	0.498645735699	0.502601576844	0.502607454450
RDtf, Tri al	0.269328931569	0.243722429967	0.245697062401	0.245700000000
T23/10	Conti nue	Conti nue	Conti nue	Converged
T23/11				
Reset boundari es				
RDtf, hi gh	0.269328931569	0.259348434199	0.246406934127	
RD60, hi gh	0.490569321418	0.489664201999	0.488882034911	
RDtf, low	not changed	0.243722429967	0.245697062401	
RD60, low	not changed	0.488768703948	0.488850560207	
T23/12				
RD60 (RD60, Tri al rounded)				0.4889

**Example 23/3 – T23/11, Reset upper boundary only**

```

Input Data
Relative density @ obs. temp. ... 0.50004
Observed temperature Tf, °F .... 190.04
  Computed Data – last digit is rounded
T23/1
  Input Data – rounded
  RDtf, observed rel. density .... 0.5000
  Tf, °F ..... 190.0
T23/2
Tx, Kelvin ..... 360.927777777778
T23/3
RDtf and Tf are within range, continue
T23/4
RDtf for Fluid 1 ..... 0.488812742534
RDtf for Fluid 2 ..... 0.543932948655
T23/5
Reference Fluid 1 ..... n-Butane
Reference Fluid 2 ..... i-Pentane
Tr, x for Fluid 1 ..... 0.848922235812
Tr, x for Fluid 2 ..... 0.783875809612
Tr, 60 for Fluid 1 ..... 0.679051546607
Tr, 60 for Fluid 2 ..... 0.627021013716
T23/6
Upper boundary RD60, high ..... 0.624285000000
Upper boundary RDtf, high ..... 0.543932948655
Lower boundary RD60, low ..... 0.584127000000
Lower boundary RDtf, low ..... 0.488812742534

Iteration steps
T23/7
Delta ..... 0.202961096368
RD60, mid ..... 0.592277511708
CTL ..... 0.845587965896
RDtf, mid ..... 0.500822736371
T23/8
  Continue
T23/9
Alpha ..... 0.040158000000
Beta ..... 0.056925155369
Phi ..... 4.589528260128
A ..... 1.157707890490
B ..... -0.467064681900
C ..... 0.535813879101
RD60, Trial ..... 0.591708510774
CTL, Trial ..... 0.845012937594
RDtf, Trial ..... 0.500001346888
T23/10
  Continue
T23/11
Reset boundaries
RDtf, high ..... 0.500001346888
RD60, high ..... 0.591708510774
T23/12
RD60 (RD60, Trial rounded) ..... 0.5917

```

**Example 23/4 – Calculated RD60 equals 0.3500, T23/11 lo/hi, T23/8 detects**

```

Input Data
Relative density @ obs. temp. ... 0.22238
Observed temperature Tf, °F .... 87.25
  Computed Data – last digit is rounded
T23/1
  Input Data – rounded
RDtf, observed rel. density .... 0.2224
Tf, °F ..... 87.3
T23/2
Tx, Kelvin ..... 303.872222222222
T23/3
RDtf and Tf are within range, continue
T23/4
RDtf for Fluid 1 ..... -0.325022000000
RDtf for Fluid 2 ..... 0.267719237662
T23/5
Reference Fluid 1 ..... EE (68/32)
Reference Fluid 2 ..... Ethane
Tr, x for Fluid 1 ..... 1.019329181249
Tr, x for Fluid 2 ..... 0.995225566509
Tr, 60 for Fluid 1 ..... 0.968453106422
Tr, 60 for Fluid 2 ..... 0.945552535144
T23/6
Upper boundary RD60, high ..... 0.355994000000
Upper boundary RDtf, high ..... 0.267719237662
Lower boundary RD60, low ..... 0.350000000000
Lower boundary RDtf, low ..... 0.222390762498

Iteration steps
T23/7
Delta ..... 0.001000000000
RD60, mid ..... 0.350005994000
CTL ..... 0.635875915052
RDtf, mid ..... 0.222560381708
T23/8
  Continue
T23/9
Alpha ..... 0.005994000000
Beta ..... 0.022215938970
Phi ..... 267.236683329960
A ..... 2.145687234871
B ..... -0.919388011785
C ..... 0.448342750031
RD60, Trial ..... 0.350000323256
CTL, Trial ..... 0.635427908123
RDtf, Trial ..... 0.222399973249
T23/10
  Continue
T23/11
Reset boundaries
RDtf, high ..... 0.222560381708
RD60, high ..... 0.350005994000
RDtf, low ..... 0.222399973249
RD60, low ..... 0.350000323256
T23/12
RD60 (RD60, Trial rounded) ..... 0.3500

```

**Example 23/5 – T23/6, RDtf < lower boundary**

```

Input Data
Relative density @ obs. temp. ... 0.34006
Observed temperature Tf, °F .... 64.63
  Computed Data – last digit is rounded
T23/1
  Input Data – rounded
RDtf, observed rel. density .... 0.3401
Tf, °F ..... 64.6
T23/2
Tx, Kelvin ..... 291.261111111111
T23/3
RDtf and Tf are within range, continue
T23/4
RDtf for Fluid 1 ..... 0.310026832478
RDtf for Fluid 2 ..... 0.346752475914
T23/5
Reference Fluid 1 ..... EE (68/32)
Reference Fluid 2 ..... Ethane
Tr, x for Fluid 1 ..... 0.977025631851
Tr, x for Fluid 2 ..... 0.953922349953
Tr, 60 for Fluid 1 ..... 0.968453106422
Tr, 60 for Fluid 2 ..... 0.945552535144
T23/6
Upper boundary RD60, high ..... 0.355994000000
Upper boundary RDtf, high ..... 0.346752475914
Lower boundary RD60, low ..... 0.350000000000
Lower boundary RDtf, low ..... 0.340112938057
RDtf observed is less than lower boundary RDtf, no solution

```



**Example 23/6 – T23/6, RDtf > upper boundary**

```

Input Data
Relative density @ obs. temp. ... 0.72858
Observed temperature Tf, °F .... -27.53
  Computed Data – last digit is rounded
T23/1
  Input Data – rounded
RDtf, observed rel. density .... 0.7286
Tf, °F ..... -27.5
T23/2
Tx, Kelvin ..... 240.094444444444
T23/3
RDtf and Tf are within range, continue
T23/4
RDtf for Fluid 1 ..... 0.706219967989
RDtf for Fluid 2 ..... 0.728360741594
T23/5
Reference Fluid 1 ..... n-Hexane
Reference Fluid 2 ..... n-Heptane
Tr,x for Fluid 1 ..... 0.473232373006
Tr,x for Fluid 2 ..... 0.444495870489
Tr,60 for Fluid 1 ..... 0.569046132957
Tr,60 for Fluid 2 ..... 0.534491447849
T23/6
RDtf observed is greater than Fluid 2 RDtf, no solution

```

**Example 23/7 – Test binary search routine at low end**

```

Input Data
Relative density @ obs. temp. ... 0.45572
Observed temperature Tf, °F .... -24.67
Computed Data – last digit is rounded
T23/1
Input Data – rounded
RDtf, observed rel. density .... 0.4557
Tf, °F ..... -24.7
T23/2
Tx, Kelvin ..... 241.650000000000
T23/3
RDtf and Tf are within range, continue
T23/4
RDtf for Fluid 1 ..... 0.455790716298
RDtf for Fluid 2 ..... 0.462651655172
T23/5
Reference Fluid 1 ..... EE (68/32)
Reference Fluid 2 ..... Ethane
Tr,x for Fluid 1 ..... 0.810606822985
Tr,x for Fluid 2 ..... 0.791438771166
Tr,60 for Fluid 1 ..... 0.968453106422
Tr,60 for Fluid 2 ..... 0.945552535144
T23/6
Upper boundary RD60, high ..... 0.355994000000
Upper boundary RDtf, high ..... 0.462651655172
Lower boundary RD60, low ..... 0.350000000000
Lower boundary RDtf, low ..... 0.459877928850
RDtf observed is less than lower boundary RDtf, no solution

```

**Example 23/8 – T23/6 RDtf near RDlowTf, T23/11 reset lower/upper boundaries**

```

Input Data
Relative density @ obs. temp. ... 0.25776
Observed temperature Tf, °F .... 179.28
Computed Data – last digit is rounded
T23/1
Input Data – rounded
RDtf, observed rel. density .... 0.2578
Tf, °F ..... 179.3
T23/2
Tx, Kelvin ..... 354.983333333333
T23/3
RDtf and Tf are within range, continue
T23/4
RDtf for Fluid 1 ..... -0.470381000000
RDtf for Fluid 2 ..... 0.367118287562
T23/5
Reference Fluid 1 ..... EP (35/65)
Reference Fluid 2 ..... Propane
Tr, x for Fluid 1 ..... 1.007159204827
Tr, x for Fluid 2 ..... 0.959985216435
Tr, 60 for Fluid 1 ..... 0.819115801951
Tr, 60 for Fluid 2 ..... 0.780749514726
T23/6
Upper boundary RD60, high ..... 0.507025000000
Upper boundary RDtf, high ..... 0.367118287562
Lower boundary RD60, low ..... 0.475719627406
Lower boundary RDtf, low ..... 0.203205649078

Iteration steps
T23/7
Del ta ..... 0.333069807351
RD60, mid ..... 0.486146501825
CTL ..... 0.636706579940
RDtf, mid ..... 0.309532676527
T23/8
T23/9
Al pha ..... 0.031305372594
Beta ..... 0.093483301245
Phi ..... 1.541589588429
A ..... 1.613666311213
B ..... -0.729324366880
C ..... 0.557290084813
RD60, Tri al ..... 0.476515881554
CTL, Tri al ..... 0.513269870440
RDtf, Tri al ..... 0.244581244788
T23/10
T23/11
Reset boundaries
RDtf, high ..... 0.309532676527
RD60, high ..... 0.486146501825
RDtf, low ..... 0.244581244788
RD60, low ..... 0.476515881554
T23/12
RD60 (RD60, Tri al rounded) ..... 0.4774

Pass 1
Pass 2
Pass 3

```

**Example 23/9 – T23/11, reset upper/lower using Ethane & EP**

```

Input Data
Relative density @ obs. temp. ... 0.39548
Observed temperature Tf, °F .... 59.78
Computed Data – last digit is rounded
T23/1
Input Data – rounded
RDtf, observed rel. density .... 0.3955
Tf, °F ..... 59.8
T23/2
Tx, Kelvin ..... 288.594444444444
T23/3
RDtf and Tf are within range, continue
T23/4
RDtf for Fluid 1 ..... 0.356376967243
RDtf for Fluid 2 ..... 0.429505267826
T23/5
Reference Fluid 1 ..... Ethane
Reference Fluid 2 ..... EP (65/35)
Tr, x for Fluid 1 ..... 0.945188630152
Tr, x for Fluid 2 ..... 0.864909774461
Tr, 60 for Fluid 1 ..... 0.945552535144
Tr, 60 for Fluid 2 ..... 0.865242771467
T23/6
Upper boundary RD60, high ..... 0.429277000000
Upper boundary RDtf, high ..... 0.429505267826
Lower boundary RD60, low ..... 0.355994000000
Lower boundary RDtf, low ..... 0.356376967243

Iteration steps
T23/7
Delta ..... 0.534991685093
RD60, mid ..... 0.395199795659
CTL ..... 1.000681275169
RDtf, mid ..... 0.395469035466
T23/8
Continue
T23/9
Alpha ..... 0.073283000000
Beta ..... 0.057470232309
Phi ..... 1.870668498940
A ..... -0.023321269027
B ..... 1.020443223123
C ..... -0.004706553990
RD60, Trial ..... 0.395230822023
CTL, Trial ..... 1.000681092487
RDtf, Trial ..... 0.395500010767
T23/10
Continue
T23/11
Reset boundaries
RDtf, high ..... 0.395500010767
RD60, high ..... 0.395230822023
RDtf, low ..... 0.395469035466
RD60, low ..... 0.395199795659
T23/12
RD60 (RD60, Trial rounded) ..... 0.3952

```

**Example 23/10 – T23/9 & 11, Adjust RD60 Trial, reset hi+low/hi boundaries**

Input Data  
 Relative density @ obs. temp. ... 0.21056  
 Observed temperature Tf, °F .... 87.46  
 Computed Data – last digit is rounded

T23/1  
 Input Data – rounded  
 RDtf, observed rel. density .... 0.2106  
 Tf, °F ..... 87.5  
 T23/2  
 Tx, Kelvin ..... 303.983333333333  
 T23/3  
 RDtf and Tf are within range, continue  
 T23/4  
 RDtf for Fluid 1 ..... -0.325022000000  
 RDtf for Fluid 2 ..... 0.266017434379  
 T23/5  
 Reference Fluid 1 ..... EE (68/32)  
 Reference Fluid 2 ..... Ethane  
 Tr, x for Fluid 1 ..... 1.019701899746  
 Tr, x for Fluid 2 ..... 0.995589471501  
 Tr, 60 for Fluid 1 ..... 0.968453106422  
 Tr, 60 for Fluid 2 ..... 0.945552535144  
 T23/6  
 Upper boundary RD60, high ..... 0.355994000000  
 Upper boundary RDtf, high ..... 0.266017434379  
 Lower boundary RD60, low ..... 0.350217135734  
 Lower boundary RDtf, low ..... 0.201957415331

Iteration steps	Pass 1	Pass 2	Pass 3	Pass 4
T23/7				
Delta	0.134913863553	0.442156617893	0.285572535939	0.045507746482
RD60, mid	0.350996514811	0.350313978649	0.350250911268	0.350238857349
CTL	0.663001877090	0.618306878199	0.605460325548	0.601336301107
RDtf, mid	0.232711348172	0.216601542528	0.212063030760	0.210611338982
T23/8	Continue	Continue	Continue	Continue
T23/9				
Alpha	0.005776864266	2.19024009057e-04	8.82768152069e-05	1.26286194163e-05
Beta	0.029978477786	0.008277157180	0.003568550978	6.47744349018e-04
Phi	2.082986243708	1.334762574159	2.175177227878	18.901668137223
A	1.946686690732	0.936748950385	0.877145829125	0.793585193044
B	-0.820821476963	-0.385471575544	-0.362105293706	-0.327124761330
C	0.436589003610	0.389858988966	0.387594169917	0.383933874925
RD60, Trial	0.350064149476	0.350225701834	0.350238282649	0.350238776362
RD60, Trial adjusted				
RD60, Trial	0.350436159743	not changed	not changed	not changed
CTL, Trial	0.632080457699	0.594476787322	0.601105752483	0.601304054034
RDtf, Trial	0.221503848245	0.208201050064	0.210530246440	0.210599996106
T23/10	Continue	Continue	Continue	Converged
T23/11				
Reset boundaries				
RDtf, high	0.221503848245	0.216601542528	0.212063030760	
RD60, high	0.350436159743	0.350313978649	0.350250911268	
RDtf, low	not changed	0.208201050064	0.210530246440	
RD60, low	not changed	0.350225701834	0.350238282649	
T23/12				
RD60 (RD60, Trial rounded)				0.3502

**Example 23/11 – T23/11, Reset upper boundary only**

```

Input Data
Relative density @ obs. temp. ... 0.45003
Observed temperature Tf, °F .... 199.43
Computed Data – last digit is rounded
T23/1
Input Data – rounded
RDtf, observed rel. density .... 0.4500
Tf, °F ..... 199.4
T23/2
Tx, Kelvin ..... 366.150000000000
T23/3
RDtf and Tf are within range, continue
T23/4
RDtf for Fluid 1 ..... 0.445396160533
RDtf for Fluid 2 ..... 0.480129616454
T23/5
Reference Fluid 1 ..... i-Butane
Reference Fluid 2 ..... n-Butane
Tr, x for Fluid 1 ..... 0.897756528135
Tr, x for Fluid 2 ..... 0.861205193339
Tr, 60 for Fluid 1 ..... 0.707871902797
Tr, 60 for Fluid 2 ..... 0.679051546607
T23/6
Upper boundary RD60, high ..... 0.584127000000
Upper boundary RDtf, high ..... 0.480129616454
Lower boundary RD60, low ..... 0.562827000000
Lower boundary RDtf, low ..... 0.445396160533

Iteration steps
T23/7
Delta ..... 0.132547693417
RD60, mid ..... 0.565650265870
CTL ..... 0.796107835259
RDtf, mid ..... 0.450318608675
T23/8
Continue
T23/9
Alpha ..... 0.021300000000
Beta ..... 0.032146708779
Phi ..... 7.056134451304
A ..... 1.331470032321
B ..... -0.619068238574
C ..... 0.574423600922
RD60, Trial ..... 0.565465575109
CTL, Trial ..... 0.795804772113
RDtf, Trial ..... 0.450000203137
T23/10
Continue
T23/11
Reset boundaries
RDtf, high ..... 0.450000203137
RD60, high ..... 0.565465575109
T23/12
RD60 (RD60, Trial rounded) ..... 0.5655
Pass 2
0.999000000000
0.565462936534
0.795800434708
0.449995650705
Continue
0.002638575109
0.004122443006
1.000989768898
1.412580442222
-0.691719762248
0.590691810831
0.565465457370
0.795804578573
0.450000000000
Converged

```

**Example 23/12 – T23/10 detects solution in one pass, using i-Hexane**

```

Input Data
Relative density @ obs. temp. ... 0.60133
Observed temperature Tf, °F .... 177.17
  Computed Data – last digit is rounded
T23/1
  Input Data – rounded
  RDtf, observed rel. density .... 0.6013
  Tf, °F ..... 177.2
T23/2
Tx, Kelvin ..... 353.816666666667
T23/3
RDtf and Tf are within range, continue
T23/4
RDtf for Fluid 1 ..... 0.594442903364
RDtf for Fluid 2 ..... 0.602928497317
T23/5
Reference Fluid 1 ..... i-Hexane
Reference Fluid 2 ..... n-Hexane
Tr, x for Fluid 1 ..... 0.710403908577
Tr, x for Fluid 2 ..... 0.697381820571
Tr, 60 for Fluid 1 ..... 0.579671831253
Tr, 60 for Fluid 2 ..... 0.569046132957
T23/6
Upper boundary RD60, high ..... 0.664064000000
Upper boundary RDtf, high ..... 0.602928497317
Lower boundary RD60, low ..... 0.657167000000
Lower boundary RDtf, low ..... 0.594442903364

Iteration steps                                Pass 1
T23/7
Delta ..... 0.808086820333
RD60, mid ..... 0.662740374800
CTL ..... 0.907329937112
RDtf, mid ..... 0.601324182589
T23/8
T23/9
Al pha ..... 0.006897000000
Beta ..... 0.010160407517
Phi ..... 1.233141931306
A ..... 1.780418160509
B ..... -1.319032483022
C ..... 0.812123726312
RD60, Trial ..... 0.662720493291
CTL, Trial ..... 0.907320672201
RDtf, Trial ..... 0.601300003454
T23/10
T23/11 not needed, convergence already achieved
T23/12
RD60 (RD60, Trial rounded) ..... 0.6627

```

**Example 23/13 – Calculated RD60 equals 0.6880**

```

Input Data
Relative density @ obs. temp. ... 0.73592
Observed temperature Tf, °F .... -44.13
  Computed Data – last digit is rounded
T23/1
  Input Data – rounded
RDtf, observed rel. density .... 0.7359
Tf, °F ..... -44.1
T23/2
Tx, Kelvin ..... 230.872222222222
T23/3
RDtf and Tf are within range, continue
T23/4
RDtf for Fluid 1 ..... 0.714077137643
RDtf for Fluid 2 ..... 0.735959630678
T23/5
Reference Fluid 1 ..... n-Hexane
Reference Fluid 2 ..... n-Heptane
Tr, x for Fluid 1 ..... 0.455055133975
Tr, x for Fluid 2 ..... 0.427422423812
Tr, 60 for Fluid 1 ..... 0.569046132957
Tr, 60 for Fluid 2 ..... 0.534491447849
T23/6
Upper boundary RD60, high ..... 0.688039000000
Upper boundary RDtf, high ..... 0.735959630678
Lower boundary RD60, low ..... 0.664064000000
Lower boundary RDtf, low ..... 0.714077137643

Iteration steps                                Pass 1
T23/7
Delta ..... 0.997274959562
RD60, mid ..... 0.687973667156
CTL ..... 1.069661466437
RDtf, mid ..... 0.735898921680
T23/8                                          Continue
T23/9
Alpha ..... 0.023975000000
Beta ..... 0.031730419484
Phi ..... 1.002782036454
A ..... -0.891797542956
B ..... 2.388763933252
C ..... -0.586964652669
RD60, Trial ..... 0.687974827662
CTL, Trial ..... 1.069661229476
RDtf, Trial ..... 0.735900000006
T23/10                                          Converged
T23/11 not needed, convergence already achieved
T23/12
RD60 (RD60, Trial rounded) ..... 0.6880

```



**Example 23/14 – Rd = lower RD limit**

```

Input Data
Relative density @ obs. temp. ... 0.21
Observed temperature Tf, °F .... 189.4
Computed Data – last digit is rounded
T23/1
Input Data – rounded
RDtf, observed rel. density .... 0.2100
Tf, °F ..... 189.4
T23/2
Tx, Kelvin ..... 360.594444444444
T23/3
RDtf and Tf are within range, continue
T23/4
RDtf for Fluid 1 ..... -0.470381000000
RDtf for Fluid 2 ..... 0.343306875586
T23/5
Reference Fluid 1 ..... EP (35/65)
Reference Fluid 2 ..... Propane
Tr, x for Fluid 1 ..... 1.023079057040
Tr, x for Fluid 2 ..... 0.975159404090
Tr, 60 for Fluid 1 ..... 0.819115801951
Tr, 60 for Fluid 2 ..... 0.780749514726
T23/6
Upper boundary RD60, high ..... 0.507025000000
Upper boundary RDtf, high ..... 0.343306875586
Lower boundary RD60, low ..... 0.487591079805
Lower boundary RDtf, low ..... 0.209600629464

Iteration steps
T23/7
Del ta ..... 0.002986925048
RD60, mid ..... 0.487649127468
CTL ..... 0.462843318636
RDTF, mid ..... 0.225705140487
T23/8
T23/9
Continue
Continue
Continue
Converged
Al pha ..... 0.019433920195
Beta ..... 0.073927186953
Phi ..... 8.302409550559
A ..... 1.205283669609
B ..... -0.521062500820
C ..... 0.543855074908
RD60, Trial ..... 0.487584959566
RD60, Trial adjusted ..... 0.487592519310
RD60, Trial ..... not changed
CTL, Trial ..... 0.432128227318
RDTF, Trial ..... 0.210701880813
T23/10
T23/11
Continue
Continue
Reset boundaries
RDtf, high ..... 0.214007257783
RD60, high ..... 0.210701880813
RD60, high ..... 0.487591107206
T23/12
RD60 (RD60, Trial rounded) ..... 0.4876

```

**Example 23/15 – T23/3, RDtf < lower range limit**

```
Input Data
Relative density @ obs. temp. ... 0.20993
Observed temperature Tf, °F .... 187.94
Computed Data – last digit is rounded
T23/1
Input Data – rounded
RDtf, observed rel. density .... 0.2099
Tf, °F ..... 187.9
T23/2
Tx, Kelvin ..... 359.761111111111
T23/3
RDtf in is less than 0.2100, no solution
```

**Example 23/16 – T23/3, RDtf > upper range limit**

```
Input Data
Relative density @ obs. temp. ... 0.74005
Observed temperature Tf, °F .... -28.48
Computed Data – last digit is rounded
T23/1
Input Data – rounded
RDtf, observed rel. density .... 0.7401
Tf, °F ..... -28.5
T23/2
Tx, Kelvin ..... 239.538888888889
T23/3
RDtf in is greater than 0.7400, no solution
```

**Example 23/17 – RDtf = upper range limit, fails T23/6**

```

Input Data
Relative density @ obs. temp. ... 0.74
Observed temperature Tf, °F .... -50
  Computed Data – last digit is rounded
T23/1
  Input Data – rounded
RDtf, observed rel. density .... 0.7400
Tf, °F ..... -50.0
T23/2
Tx, Kelvin ..... 227.594444444444
T23/3
RDtf and Tf are within range, continue
T23/4
RDtf for Fluid 1 ..... 0.716864897522
RDtf for Fluid 2 ..... 0.738661816297
T23/5
Reference Fluid 1 ..... n-Hexane
Reference Fluid 2 ..... n-Heptane
Tr, x for Fluid 1 ..... 0.448594549018
Tr, x for Fluid 2 ..... 0.421354150596
Tr, 60 for Fluid 1 ..... 0.569046132957
Tr, 60 for Fluid 2 ..... 0.534491447849
T23/6
RDtf observed is greater than Fluid 2 RDtf, no solution

```

**Example 23/18 – T23/3, Tf = lower range limit**

```

Input Data
Relative density @ obs. temp. ... 0.5
Observed temperature Tf, °F .... -50.8
Computed Data – last digit is rounded
T23/1
Input Data – rounded
RDtf, observed rel. density .... 0.5000
Tf, °F ..... -50.8
T23/2
Tx, Kelvin ..... 227.150000000000
T23/3
RDtf and Tf are within range, continue
T23/4
RDtf for Fluid 1 ..... 0.485962637468
RDtf for Fluid 2 ..... 0.528232774666
T23/5
Reference Fluid 1 ..... Ethane
Reference Fluid 2 ..... EP (65/35)
Tr, x for Fluid 1 ..... 0.743949169751
Tr, x for Fluid 2 ..... 0.680762429946
Tr, 60 for Fluid 1 ..... 0.945552535144
Tr, 60 for Fluid 2 ..... 0.865242771467
T23/6
Upper boundary RD60, high ..... 0.429277000000
Upper boundary RDtf, high ..... 0.528232774666
Lower boundary RD60, low ..... 0.355994000000
Lower boundary RDtf, low ..... 0.485962637468

Iteration steps
T23/7
Del ta ..... 0.332086987697      0.764261437411      0.996676046418
RD60, mid ..... 0.380330330719      0.389044267951      0.389195295035
CTL ..... 1.301530344004      1.284969011460      1.284702066298
RDtf, mid ..... 0.495011466176      0.499909828404      0.499999999725
T23/8
T23/9
Al pha ..... 0.073283000000      0.011401775368      1.51530764763e-04
Beta ..... 0.042870179217      0.006504743146      9.04641913088e-05
Phi ..... 4.671337977889      1.332539455216      1.003338101716
A ..... -28.769572088869      -19.740869990631      -16.984940231986
B ..... 30.911650589439      21.419561059033      18.658299106732
C ..... -7.871700166414      -5.385367233142      -4.693719199874
RD60, Tri al ..... 0.391732106088      0.389195798716      0.389195295495
CTL, Tri al ..... 1.280310496169      1.284701177082      1.284702065485
RDtf, Tri al ..... 0.501538727110      0.500000300726      0.500000000000
T23/10
T23/11
Reset boundaries
RDtf, high ..... 0.501538727110      0.500000300726
RD60, high ..... 0.391732106088      0.389195798716
RDtf, low ..... 0.495011466176      0.499909828404
RD60, low ..... 0.380330330719      0.389044267951
T23/12
RD60 (RD60, Tri al rounded) ..... 0.3892

```

**Example 23/19 – T23/3, Tf < lower range limit**

```
Input Data
Relative density @ obs. temp. ... 0.5
Observed temperature Tf, °F .... -50.9
Computed Data – last digit is rounded
T23/1
Input Data – rounded
RDtf, observed rel. density .... 0.5000
Tf, °F ..... -50.9
T23/2
Tx, Kelvin ..... 227.094444444444
T23/3
Tx less than 227.15, no solution
```

## 5.2 CTL (Table 54) and Density (Table 53) for NGL and LPG using a 15°C Base Temperature

### 5.2.1 Implementation Procedure for Table 54E (15°C Basis)

This section presents the implementation procedure T54 for the computation of Temperature Correction Factor,  $C_{TL}$ . The  $C_{TL}$  is used to calculate volumes of fluid at the base temperature from volumes at some known temperature. The fluids are characterized by the specification of density at the base temperature, 15°C.

#### 5.2.1.1 Inputs and Outputs

Inputs: Density at 15°C,  $\rho_{15}$  (kg/m<sup>3</sup>)  
Observed temperature,  $T_F$  (°C)

Output: Temperature Correction Factor,  $C_{TL}$  (from  $T_F$  to  $T_B$ )

#### 5.2.1.2 Outline of Calculations

The calculations are performed using an extended two-fluid corresponding states equation. By comparing densities at 60°F, two reference fluids are selected so that one is slightly more dense and one that is slightly less dense than the observed fluid. The densities of these reference fluids are then scaled to the observed reduced temperature (reduced by the critical temperature of the fluid of interest). The Temperature Correction Factor is then computed from the reference fluid densities. See Figure 3 for a general flow chart of the calculation procedure.

#### 5.2.1.3 T54 Implementation Procedure

T54/Step Number	Operation/Procedure at that step
T54/1:	Round the density — <sub>15</sub> to the nearest 0.1 and round the observed temperature $T_F$ to the nearest 0.05°C.
T54/2:	Convert the rounded observed temperature to units of Kelvin, $T_x$ :
$T_x = T_F + 273.15$	
T54/3:	The resultant temperature $T_x$ and density — <sub>15</sub> must fall within the following boundaries:
Temperature between 227.15 and 366.15 K, inclusive (equivalent to –46 to 93°C, or –50.8 to 199.4°F) Density between 351.7 and 687.8 kg/m <sup>3</sup> inclusive	
If these values do not fall in these ranges, then the standard does not apply. Flag this result (return a –1 for $C_{TL}$ ) and exit this procedure.	

Note: The density boundaries tested in this step slightly exceed the boundaries used within the T24 implementation procedure (0.3500 to 0.6880 relative density at 60°F) that act as the true limits for this method.

T54/4: Convert the 15°C density to relative density, relative to the density of water at 60°F

$$\gamma_{TB} = \frac{\rho_{15}}{999.016}$$

T54/5: Use the procedure described in Section 5.1.2 for Table 23 to compute a relative density at 60°F from the known relative density at 15°C. Enter the procedure at Step T23/4 so as to avoid additional rounding of the input values. Inputs to implementation procedure T23 are the values of  $T_{BK}$  and  $\gamma_{TB}$ , where  $T_{BK}$  is the base temperature 15°C in Kelvin (288.15 K) and  $\gamma_{TB}$  is the density at the base temperature 15°C. Implementation procedure T23 is exited after Step T23/11 so as not to round the output values. The converged output from Step T23/11 is  $\gamma_{60}$ .

T54/6: The resultant density  $\gamma_{60}$ , if it were rounded to the nearest 0.0001, must fall within 0.3500 and 0.6880 inclusive. Test  $\gamma_{60}$  to ensure it is within the following boundaries:

Relative density greater than or equal to 0.34995 and less than 0.68805

If the relative density does not fall in this range, then the standard does not apply.  
Flag this result (return a -1 for  $C_{TL}$ ) and exit this procedure.

T54/7: Use the procedure described in Section 5.1.1 for Table 24 to compute the Temperature Correction Factor ( $C_{TL1}$ ) from 60°F to the observed temperature,  $T_x$ . This step provides the factor used to reduce an observed volume at  $T_x$  to a volume at 60°F when the relative density at 60°F,  $\gamma_{60}$ , is known. Enter implementation procedure T24 with  $T_x$  and  $\gamma_{60}$  at Step T24/4 to avoid double rounding of the inputs. On exit skip Step T24/14 to avoid rounding the output,  $C_{TL1}$ .

By definition:

$$C_{TL1} = \frac{V_{60}}{V_{Tx}} = \frac{\gamma_{Tx}}{\gamma_{60}}$$

T54/8: Use the procedure described in Section 5.1.1 for Table 24 to compute the Temperature Correction Factor ( $C_{TL2}$ ) from 60°F to the new base temperature 15°C. This step provides the factor used to reduce an observed volume at 15°C to a volume at 60°F if the relative density at 60°F,  $\gamma_{60}$ , is known. Enter implementation procedure T24 at Step T24/4 to avoid double rounding of the inputs. The inputs are  $T_{BK}$  and  $\gamma_{60}$ , where  $T_{BK}$  is the base temperature 15°C in Kelvin (288.15 K). On exit skip Step T24/14 to avoid rounding of the output  $C_{TL2}$ .



By definition:

$$C_{TL2} = \frac{V_{60}}{V_{15}} = \frac{\gamma_{TB}}{\gamma_{60}}$$

T54/9: Compute the desired  $C_{TL}$  to reduce volume from the observed temperature,  $T_F$ , to the base condition of 15°C. The defining formulas show that the calculation is made by computing the ratio  $C_{TL1}/C_{TL2}$ .


$$\frac{C_{TL1}}{C_{TL2}} = \frac{\left( \frac{V_{60}}{V_{Tx}} \right)}{\left( \frac{V_{60}}{V_{15}} \right)} = \frac{V_{15}}{V_{Tx}}$$

$$C_{TL} = \frac{V_{15}}{V_{Tx}} = \frac{\gamma_{Tx}}{\gamma_{15}}$$

T54/10: Perform error check to ascertain that only positive  $C_{TL}$  is used. If  $C_{TL}$  is less than or equal to 0, set an error flag (such as  $C_{TL} = -1$ ) and quit.

T54/11: Round the Temperature Correction Factor  $C_{TL}$  to the nearest 0.00001.

**Figure 3. Flow Chart of Implementation Procedure for Table 54**



### 5.2.1.4 Examples for Section 5.2.2 (Table 54E)

(See Table 1 for properties of the Reference Fluids)

#### Example 54/1 – Utilize EE (68/32) and Ethane

Input Data to Implementation Procedure T54  
 Density (kg/m<sup>3</sup>) @ 15°C (Den15) . 352.59  
 Observed temperature Tf, °C .... -45.020  
 Computed Data – last digit is rounded  
 T54/1  
 Input Data – rounded  
 Den15, rounded to 0.1 ..... 352.6  
 Tf, °C, rounded to 0.05 ..... -45.00  
 T54/2  
 Tx, Kelvin ..... 228.15  
 T54/3  
 Tx and Den15 are within range, continue  
 T54/4  
 Den15 relative to 60°F water ... 0.352947300143  
 T54/5, Call Table 23 procedure to obtain relative density at 60°F  
 RD60 from Table 23 ..... 0.350947981104  
 T54/6  
 RD60 is within range, continue  
 T54/7, Call Table 24 Procedure with Tx and RD60  
 Reference Fluid 1 ..... EE (68/32)  
 Reference Fluid 2 ..... Ethane  
 CTL1, Tx to 60°F ..... 1.374246650548  
 T54/8, Call Table 24 Procedure with 15°C and RD60  
 Reference Fluid 1 ..... EE (68/32)  
 Reference Fluid 2 ..... Ethane  
 CTL2, 15°C to 60°F ..... 1.005696910034  
 T54/9 CTL = CTL1/CTL2  
 CTL, Tx to 15°C ..... 1.366462039245  
 T54/10  
 CTL is positive, continue  
 T54/11 CTL rounded  
 CTL (rounded) ..... 1.36646

**Example 54/2 – Utilize Ethane and EP (65/35)**

Input Data to Implementation Procedure T54

Density ( $\text{kg/m}^3$ ) @  $15^\circ\text{C}$  (Den15) . 399.55

Observed temperature  $T_f$ ,  $^\circ\text{C}$  .... -3.920

Computed Data – last digit is rounded

T54/1

Input Data – rounded

Den15, rounded to 0.1 ..... 399.6

$T_f$ ,  $^\circ\text{C}$ , rounded to 0.05 ..... -3.90

T54/2

$T_x$ , Kelvin ..... 269.25

T54/3

$T_x$  and Den15 are within range, continue

T54/4

Den15 relative to  $60^\circ\text{F}$  water ... 0.399993593696

T54/5, Call Table 23 procedure to obtain relative density at  $60^\circ\text{F}$

RD60 from Table 23 ..... 0.398679750427

T54/6

RD60 is within range, continue

T54/7, Call Table 24 Procedure with  $T_x$  and RD60

Reference Fluid 1 ..... Ethane

Reference Fluid 2 ..... EP (65/35)

CTL1,  $T_x$  to  $60^\circ\text{F}$  ..... 1.101743247711

T54/8, Call Table 24 Procedure with  $15^\circ\text{C}$  and RD60

Reference Fluid 1 ..... Ethane

Reference Fluid 2 ..... EP (65/35)

CTL2,  $15^\circ\text{C}$  to  $60^\circ\text{F}$  ..... 1.003295485330

T54/9 CTL = CTL1/CTL2

CTL,  $T_x$  to  $15^\circ\text{C}$  ..... 1.098124394877

T54/10

CTL is positive, continue

T54/11 CTL rounded

CTL (rounded) ..... 1.09812

**Example 54/3 – Utilize EP (65/35) and EP (35/65)**

Input Data to Implementation Procedure T54

Density (kg/m<sup>3</sup>) @ 15°C (Den15) . 451.09

Observed temperature Tf, °C .... 30.774

Computed Data – last digit is rounded

T54/1

Input Data – rounded

Den15, rounded to 0.1 ..... 451.1

Tf, °C, rounded to 0.05 ..... 30.75

T54/2

Tx, Kelvin ..... 303.90

T54/3

Tx and Den15 are within range, continue

T54/4

Den15 relative to 60°F water ... 0.451544319610

T54/5, Call Table 23 procedure to obtain relative density at 60°F

RD60 from Table 23 ..... 0.450522856945

T54/6

RD60 is within range, continue

T54/7, Call Table 24 Procedure with Tx and RD60

Reference Fluid 1 ..... EP (65/35)

Reference Fluid 2 ..... EP (35/65)

CTL1, Tx to 60°F ..... 0.932384171290

T54/8, Call Table 24 Procedure with 15°C and RD60

Reference Fluid 1 ..... EP (65/35)

Reference Fluid 2 ..... EP (35/65)

CTL2, 15°C to 60°F ..... 1.002267286478

T54/9 CTL = CTL1/CTL2

CTL, Tx to 15°C ..... 0.930274971427

T54/10

CTL is positive, continue

T54/11 CTL rounded

CTL (rounded) ..... 0.93027

**Example 54/4 – Utilize EP (35/65) and Propane**

Input Data to Implementation Procedure T54

Density (kg/m<sup>3</sup>) @ 15°C (Den15) . 489.92

Observed temperature Tf, °C .... 84.975

Computed Data – last digit is rounded

T54/1

Input Data – rounded

Den15, rounded to 0.1 ..... 489.9

Tf, °C, rounded to 0.05 ..... 85.00

T54/2

Tx, Kelvin ..... 358.15

T54/3

Tx and Den15 are within range, continue

T54/4

Den15 relative to 60°F water ... 0.490382536416

T54/5, Call Table 23 procedure to obtain relative density at 60°F

RD60 from Table 23 ..... 0.489511777456

T54/6

RD60 is within range, continue

T54/7, Call Table 24 Procedure with Tx and RD60

Reference Fluid 1 ..... EP (35/65)

Reference Fluid 2 ..... Propane

CTL1, Tx to 60°F ..... 0.608584025858

T54/8, Call Table 24 Procedure with 15°C and RD60

Reference Fluid 1 ..... EP (35/65)

Reference Fluid 2 ..... Propane

CTL2, 15°C to 60°F ..... 1.001778832207

T54/9 CTL = CTL1/CTL2

CTL, Tx to 15°C ..... 0.607503379281

T54/10

CTL is positive, continue

T54/11 CTL rounded

CTL (rounded) ..... 0.60750

**Example 54/5 – Utilize Propane and i-Butane**

Input Data to Implementation Procedure T54

Density (kg/m<sup>3</sup>) @ 15°C (Den15) . 539.49

Observed temperature Tf, °C .... 68.360

Computed Data – last digit is rounded

T54/1

Input Data – rounded

Den15, rounded to 0.1 ..... 539.5

Tf, °C, rounded to 0.05 ..... 68.35

T54/2

Tx, Kelvin ..... 341.50

T54/3

Tx and Den15 are within range, continue

T54/4

Den15 relative to 60°F water ... 0.540031390889

T54/5, Call Table 23 procedure to obtain relative density at 60°F

RD60 from Table 23 ..... 0.539309445177

T54/6

RD60 is within range, continue

T54/7, Call Table 24 Procedure with Tx and RD60

Reference Fluid 1 ..... Propane

Reference Fluid 2 ..... i-Butane

CTL1, Tx to 60°F ..... 0.850308225942

T54/8, Call Table 24 Procedure with 15°C and RD60

Reference Fluid 1 ..... Propane

Reference Fluid 2 ..... i-Butane

CTL2, 15°C to 60°F ..... 1.001338650108

T54/9 CTL = CTL1/CTL2

CTL, Tx to 15°C ..... 0.849171482446

T54/10

CTL is positive, continue

T54/11 CTL rounded

CTL (rounded) ..... 0.84917

**Example 54/6 – Utilize i-Butane and n-Butane**

Input Data to Implementation Procedure T54

Density (kg/m<sup>3</sup>) @ 15°C (Den15) . 569.42

Observed temperature Tf, °C .... -16.090

Computed Data – last digit is rounded

T54/1

Input Data – rounded

Den15, rounded to 0.1 ..... 569.4

Tf, °C, rounded to 0.05 ..... -16.10

T54/2

Tx, Kelvin ..... 257.05

T54/3

Tx and Den15 are within range, continue

T54/4

Den15 relative to 60°F water ... 0.569960841468

T54/5, Call Table 23 procedure to obtain relative density at 60°F

RD60 from Table 23 ..... 0.569305082960

T54/6

RD60 is within range, continue

T54/7, Call Table 24 Procedure with Tx and RD60

Reference Fluid 1 ..... i-Butane

Reference Fluid 2 ..... n-Butane

CTL1, Tx to 60°F ..... 1.062511014737

T54/8, Call Table 24 Procedure with 15°C and RD60

Reference Fluid 1 ..... i-Butane

Reference Fluid 2 ..... n-Butane

CTL2, 15°C to 60°F ..... 1.001151857830

T54/9 CTL = CTL1/CTL2

CTL, Tx to 15°C ..... 1.061288561198

T54/10

CTL is positive, continue

T54/11 CTL rounded

CTL (rounded) ..... 1.06129



**Example 54/7 – Utilize n-Butane and i-Pentane**

Input Data to Implementation Procedure T54

Density ( $\text{kg/m}^3$ ) @  $15^\circ\text{C}$  (Den15) . 599.37

Observed temperature  $T_f$ ,  $^\circ\text{C}$  .... 43.360

Computed Data – last digit is rounded

T54/1

Input Data – rounded

Den15, rounded to 0.1 ..... 599.4

$T_f$ ,  $^\circ\text{C}$ , rounded to 0.05 ..... 43.35

T54/2

$T_x$ , Kelvin ..... 316.50

T54/3

$T_x$  and Den15 are within range, continue

T54/4

Den15 relative to  $60^\circ\text{F}$  water ... 0.599990390544

T54/5, Call Table 23 procedure to obtain relative density at  $60^\circ\text{F}$

RD60 from Table 23 ..... 0.599396660576

T54/6

RD60 is within range, continue

T54/7, Call Table 24 Procedure with  $T_x$  and RD60

Reference Fluid 1 ..... n-Butane

Reference Fluid 2 ..... i-Pentane

CTL1,  $T_x$  to  $60^\circ\text{F}$  ..... 0.948276855780

T54/8, Call Table 24 Procedure with  $15^\circ\text{C}$  and RD60

Reference Fluid 1 ..... n-Butane

Reference Fluid 2 ..... i-Pentane

CTL2,  $15^\circ\text{C}$  to  $60^\circ\text{F}$  ..... 1.000990546173

T54/9 CTL = CTL1/CTL2

CTL,  $T_x$  to  $15^\circ\text{C}$  ..... 0.947338473281

T54/10

CTL is positive, continue

T54/11 CTL rounded

CTL (rounded) ..... 0.94734

**Example 54/8 – Utilize i-Pentane and n-Pentane**

Input Data to Implementation Procedure T54

Density (kg/m<sup>3</sup>) @ 15°C (Den15) . 624.42

Observed temperature Tf, °C .... 76.650

Computed Data – last digit is rounded

T54/1

Input Data – rounded

Den15, rounded to 0.1 ..... 624.4

Tf, °C, rounded to 0.05 ..... 76.65

T54/2

Tx, Kelvin ..... 349.80

T54/3

Tx and Den15 are within range, continue

T54/4

Den15 relative to 60°F water ... 0.625015014775

T54/5, Call Table 23 procedure to obtain relative density at 60°F

RD60 from Table 23 ..... 0.624458073820

T54/6

RD60 is within range, continue

T54/7, Call Table 24 Procedure with Tx and RD60

Reference Fluid 1 ..... i-Pentane

Reference Fluid 2 ..... n-Pentane

CTL1, Tx to 60°F ..... 0.893460003018

T54/8, Call Table 24 Procedure with 15°C and RD60

Reference Fluid 1 ..... i-Pentane

Reference Fluid 2 ..... n-Pentane

CTL2, 15°C to 60°F ..... 1.000891878859

T54/9 CTL = CTL1/CTL2

CTL, Tx to 15°C ..... 0.892663854998

T54/10

CTL is positive, continue

T54/11 CTL rounded

CTL (rounded) ..... 0.89266

**Example 54/9 – Utilize n-Pentane and i-Hexane**

Input Data to Implementation Procedure T54

Density (kg/m<sup>3</sup>) @ 15°C (Den15) . 639.41

Observed temperature Tf, °C .... -24.460

Computed Data – last digit is rounded

T54/1

Input Data – rounded

Den15, rounded to 0.1 ..... 639.4

Tf, °C, rounded to 0.05 ..... -24.45

T54/2

Tx, Kelvin ..... 248.70

T54/3

Tx and Den15 are within range, continue

T54/4

Den15 relative to 60°F water ... 0.640029789313

T54/5, Call Table 23 procedure to obtain relative density at 60°F

RD60 from Table 23 ..... 0.639504496457

T54/6

RD60 is within range, continue

T54/7, Call Table 24 Procedure with Tx and RD60

Reference Fluid 1 ..... n-Pentane

Reference Fluid 2 ..... i-Hexane

CTL1, Tx to 60°F ..... 1.057426821739

T54/8, Call Table 24 Procedure with 15°C and RD60

Reference Fluid 1 ..... n-Pentane

Reference Fluid 2 ..... i-Hexane

CTL2, 15°C to 60°F ..... 1.000821406041

T54/9 CTL = CTL1/CTL2

CTL, Tx to 15°C ..... 1.056558957827

T54/10

CTL is positive, continue

T54/11 CTL rounded

CTL (rounded) ..... 1.05656

**Example 54/10 – Utilize i-Hexane and n-Hexane**

Input Data to Implementation Procedure T54

Density ( $\text{kg/m}^3$ ) @  $15^\circ\text{C}$  (Den15) . 659.38

Observed temperature  $T_f$ ,  $^\circ\text{C}$  .... 80.580

Computed Data – last digit is rounded

T54/1

Input Data – rounded

Den15, rounded to 0.1 ..... 659.4

$T_f$ ,  $^\circ\text{C}$ , rounded to 0.05 ..... 80.60

T54/2

$T_x$ , Kelvin ..... 353.75

T54/3

$T_x$  and Den15 are within range, continue

T54/4

Den15 relative to  $60^\circ\text{F}$  water ... 0.660049488697

T54/5, Call Table 23 procedure to obtain relative density at  $60^\circ\text{F}$

RD60 from Table 23 ..... 0.659551831579

T54/6

RD60 is within range, continue

T54/7, Call Table 24 Procedure with  $T_x$  and RD60

Reference Fluid 1 ..... i-Hexane

Reference Fluid 2 ..... n-Hexane

CTL1,  $T_x$  to  $60^\circ\text{F}$  ..... 0.905892081483

T54/8, Call Table 24 Procedure with  $15^\circ\text{C}$  and RD60

Reference Fluid 1 ..... i-Hexane

Reference Fluid 2 ..... n-Hexane

CTL2,  $15^\circ\text{C}$  to  $60^\circ\text{F}$  ..... 1.000754538301

T54/9 CTL = CTL1/CTL2

CTL,  $T_x$  to  $15^\circ\text{C}$  ..... 0.905209066572

T54/10

CTL is positive, continue

T54/11 CTL rounded

CTL (rounded) ..... 0.90521

**Example 54/11 – Utilize n-Hexane and n-Heptane**

Input Data to Implementation Procedure T54

Density (kg/m<sup>3</sup>) @ 15°C (Den15) . 669.38

Observed temperature Tf, °C .... 82.790

Computed Data – last digit is rounded

T54/1

Input Data – rounded

Den15, rounded to 0.1 ..... 669.4

Tf, °C, rounded to 0.05 ..... 82.80

T54/2

Tx, Kelvin ..... 355.95

T54/3

Tx and Den15 are within range, continue

T54/4

Den15 relative to 60°F water ... 0.670059338389

T54/5, Call Table 23 procedure to obtain relative density at 60°F

RD60 from Table 23 ..... 0.669573371528

T54/6

RD60 is within range, continue

T54/7, Call Table 24 Procedure with Tx and RD60

Reference Fluid 1 ..... n-Hexane

Reference Fluid 2 ..... n-Heptane

CTL1, Tx to 60°F ..... 0.907185481500

T54/8, Call Table 24 Procedure with 15°C and RD60

Reference Fluid 1 ..... n-Hexane

Reference Fluid 2 ..... n-Heptane

CTL2, 15°C to 60°F ..... 1.000725785828

T54/9 CTL = CTL1/CTL2

CTL, Tx to 15°C ..... 0.906527536662

T54/10

CTL is positive, continue

T54/11 CTL rounded

CTL (rounded) ..... 0.90653

**Example 54/12 – Reduced temperature  $T_{r,x}$  greater than 1**

Input Data to Implementation Procedure T54

Density ( $\text{kg/m}^3$ ) @  $15^\circ\text{C}$  (Den15) . 399.83

Observed temperature  $T_f$ ,  $^\circ\text{C}$  .... 90.570

Computed Data – last digit is rounded

T54/1

Input Data – rounded

Den15, rounded to 0.1 ..... 399.8

$T_f$ ,  $^\circ\text{C}$ , rounded to 0.05 ..... 90.55

T54/2

$T_x$ , Kelvin ..... 363.70

T54/3

$T_x$  and Den15 are within range, continue

T54/4

Den15 relative to  $60^\circ\text{F}$  water ... 0.400193790690

T54/5, Call Table 23 procedure to obtain relative density at  $60^\circ\text{F}$

RD60 from Table 23 ..... 0.398881468881

T54/6

RD60 is within range, continue

T54/7, Call Table 24 Procedure with  $T_x$  and RD60

Reference Fluid 1 ..... Ethane

Reference Fluid 2 ..... EP (65/35)

Reduced temperature  $T_{r,x}$  greater than 1.0, no solution

CTL1,  $T_x$  to  $60^\circ\text{F}$  ..... -1.0

Value from Table 24 not valid, no solution

**Example 54/13 –  $T_f < \text{lower range limit}$** 

Input Data to Implementation Procedure T54

Density ( $\text{kg/m}^3$ ) @  $15^\circ\text{C}$  (Den15) . 449.56

Observed temperature  $T_f$ ,  $^\circ\text{C}$  ....  $-46.030$

Computed Data – last digit is rounded

T54/1

Input Data – rounded

Den15, rounded to 0.1 ..... 449.6

$T_f$ ,  $^\circ\text{C}$ , rounded to 0.05 .....  $-46.05$

T54/2

$T_x$ , Kelvin ..... 227.10

T54/3

$T_x$  less than 227.15, no solution

**Example 54/14 – Den15 < lower range limit**

Input Data to Implementation Procedure T54

Density (kg/m<sup>3</sup>) @ 15°C (Den15) . 349.59

Observed temperature Tf, °C .... 4.440

Computed Data – last digit is rounded

T54/1

Input Data – rounded

Den15, rounded to 0.1 ..... 349.6

Tf, °C, rounded to 0.05 ..... 4.45

T54/2

Tx, Kelvin ..... 277.60

T54/3

Density is less than 351.7, no solution



**Example 54/15 –  $T_f >$  upper range limit**

Input Data to Implementation Procedure T54

Density ( $\text{kg/m}^3$ ) @  $15^\circ\text{C}$  (Den15) . 449.56

Observed temperature  $T_f$ ,  $^\circ\text{C}$  .... 93.030

Computed Data – last digit is rounded

T54/1

Input Data – rounded

Den15, rounded to 0.1 ..... 449.6

$T_f$ ,  $^\circ\text{C}$ , rounded to 0.05 ..... 93.05

T54/2

$T_x$ , Kelvin ..... 366.20

T54/3

$T_x$  greater than 366.15, no solution

**Example 54/16 – Den15 > upper range limit**

Input Data to Implementation Procedure T54

Density (kg/m<sup>3</sup>) @ 15°C (Den15) . 687.85

Observed temperature Tf, °C .... -17.780

Computed Data – last digit is rounded

T54/1

Input Data – rounded

Den15, rounded to 0.1 ..... 687.9

Tf, °C, rounded to 0.05 ..... -17.80

T54/2

Tx, Kelvin ..... 255.35

T54/3

Den15 is greater than 687.8, no solution

**Example 54/17 – Tf & Den15 = upper range limits**

Input Data to Implementation Procedure T54

Density (kg/m<sup>3</sup>) @ 15°C (Den15) . 687.84

Observed temperature Tf, °C .... 93.020

Computed Data – last digit is rounded

T54/1

Input Data – rounded

Den15, rounded to 0.1 ..... 687.8

Tf, °C, rounded to 0.05 ..... 93.00

T54/2

Tx, Kelvin ..... 366.15

T54/3

Tx and Den15 are within range, continue

T54/4

Den15 relative to 60°F water ... 0.688477461822

T54/5, Call Table 23 procedure to obtain relative density at 60°F

RD60 from Table 23 ..... 0.688010661267

T54/6

RD60 is within range, continue

T54/7, Call Table 24 Procedure with Tx and RD60

Reference Fluid 1 ..... n-Hexane

Reference Fluid 2 ..... n-Heptane

CTL1, Tx to 60°F ..... 0.900470590102

T54/8, Call Table 24 Procedure with 15°C and RD60

Reference Fluid 1 ..... n-Hexane

Reference Fluid 2 ..... n-Heptane

CTL2, 15°C to 60°F ..... 1.000678478666

T54/9 CTL = CTL1/CTL2

CTL, Tx to 15°C ..... 0.899860054252

T54/10

CTL is positive, continue

T54/11 CTL rounded

CTL (rounded) ..... 0.89986

**Example 54/18 – Tf & Den15 = lower range limits**

Input Data to Implementation Procedure T54

Density (kg/m<sup>3</sup>) @ 15°C (Den15) . 351.67

Observed temperature Tf, °C .... -46.020

Computed Data – last digit is rounded

T54/1

Input Data – rounded

Den15, rounded to 0.1 ..... 351.7

Tf, °C, rounded to 0.05 ..... -46.00

T54/2

Tx, Kelvin ..... 227.15

T54/3

Tx and Den15 are within range, continue

T54/4

Den15 relative to 60°F water ... 0.352046413671

T54/5, Call Table 23 procedure to obtain relative density at 60°F

RD60 from Table 23 ..... 0.350027377993

T54/6

RD60 is within range, continue

T54/7, Call Table 24 Procedure with Tx and RD60

Reference Fluid 1 ..... EE (68/32)

Reference Fluid 2 ..... Ethane

CTL1, Tx to 60°F ..... 1.381296917892

T54/8, Call Table 24 Procedure with 15°C and RD60

Reference Fluid 1 ..... EE (68/32)

Reference Fluid 2 ..... Ethane

CTL2, 15°C to 60°F ..... 1.005768222160

T54/9 CTL = CTL1/CTL2

CTL, Tx to 15°C ..... 1.373374985865

T54/10

CTL is positive, continue

T54/11 CTL rounded

CTL (rounded) ..... 1.37337

### 5.2.2 Implementation Procedure for Table 53E (15°C Basis)

This section presents the implementation procedure T53 for calculating the densities of NGLs and LPGs at a base conditions of 15°C from known measurement temperatures and densities.

Density readings must be corrected for the effect of temperature on the instrument prior to entering the density into the following implementation procedure.

#### 5.2.2.1 Inputs and Outputs

Inputs: Density at observed temperature,  $\rho_x$  (kg/m<sup>3</sup>)  
Observed temperature,  $T_F$  (°C)

Output: Density at 15°C,  $\rho_{15}$  (kg/m<sup>3</sup>)

#### 5.2.2.2 Outline of Calculations

The calculations are done using an extended two-fluid corresponding states equation. Two reference fluids are found that are slightly denser and slightly less dense than the observed fluid by comparing their densities at the observed temperature. Iteration must be performed to determine the value of the fluid's relative density at 60°F such that when the Temperature Correction Factor is applied, the observed relative density is obtained. The "guessed" value for the fluid's relative density at 60°F is constrained to lie between the relative densities at 60°F of these two reference fluids (as upper and lower bounds). As the iterations progress, these upper and lower bounds are "brought together" based upon intermediate calculations. The relative density at 15°C is then computed from the 60°F relative density by using scaling factors between the properties of the two reference fluids.

See Figure 4 for a general flow chart of the calculation procedure.

#### 5.2.2.3 T53 Implementation Procedure

<u>T53/Step Number</u>	<u>Operation/Procedure at that step</u>
T53/1:	Round the density $\rho_x$ to the nearest 0.1 and round the observed temperature $T_F$ to the nearest 0.05°C.
T53/2:	Convert the rounded observed temperature to units of Kelvin, $T_x$ :
	$T_x = T_F + 273.15$
T53/3:	Convert the density, $\rho_x$ , to relative density, $\gamma_x$ , relative to the density of water at 60°F:
	$\gamma_x = \frac{\rho_x}{999.016}$

T53/4: Check the values of temperature and relative density to ensure that they are in the proper range. The observed temperature  $T_x$  and relative density  $\gamma_x$  must fall within the following boundaries:

Temperature between 227.15 and 366.15 K, inclusive (equivalent to  $-46$  to  $93^\circ\text{C}$ , or  $-50.8$  to  $199.4^\circ\text{F}$ )

Relative density, if it were rounded to the nearest 0.0001, must fall within 0.2100 and 0.7400 inclusive. Test  $\gamma_x$  to ensure it is within the following boundaries:

Relative density greater than or equal to 0.20995 and less than 0.74005

If these values do not fall in these ranges, then the standard does not apply. Flag this result (possibly by returning  $-1$  for the density) and exit this procedure.

T53/5: Compute the relative density at  $60^\circ\text{F}$ ,  $\gamma_{60}$ , from the temperature and the relative density at the measurement condition,  $\gamma_x$ . Use the procedure described in Section 5.2.1 for Table 23 to perform this step. Enter the procedure with  $\gamma_x$  and  $T_x$  at Step T23/4 so as to avoid additional rounding of the input values. Exit after Step T23/11 to avoid rounding the result.

T53/6: Compute the relative density at  $15^\circ\text{C}$ ,  $\gamma_{15}$ , from the relative density at  $60^\circ\text{F}$ . This is performed by using the procedure described in Section 5.1.1 for Table 24. Enter implementation procedure T24 with  $\gamma_{60}$  and  $T_x = 288.15$  (e.g.  $273.15 + 15.00$ ). Enter at Step T24/4 to avoid double rounding of the inputs. The  $C_{TL}$  for the conversion between  $\gamma_{60}$  and  $\gamma_{15}$  will be returned without rounding from Step T24/13. Compute  $\gamma_{15}$ :

$$\gamma_{15} = C_{TL} \times \gamma_{60}$$


T53/7: Insure that only valid values came from Steps T53/5 and T53/6. If the  $\gamma_{60}$  obtained from Section 5.2.1 for Table 23 is greater than  $-1$ , then proceed. If not, set the fluid density at  $15^\circ\text{C}$  to some flag value such as  $-1$  and quit. If the  $C_{TL}$  from Step T53/6 is negative, then set the fluid density at  $15^\circ\text{C}$  to the error flag condition and exit this procedure.

T53/8: Calculate the fluid density at  $15^\circ\text{C}$  from the relative density at  $15^\circ\text{C}$ .

$$\rho_{15} = \gamma_{15} \times 999.016$$

T53/9: Round the fluid density,  $\rho_{15}$ , to the nearest 0.1. Exit this procedure.

**Figure 4. Flow Chart of Implementation Procedure for Table 53**



### 5.2.2.4 Examples for Section 5.2.2 (Table 53E)

(See Table 1 for properties of the Reference Fluids)

#### Example 53/1 – Utilize EP (65/35) & EP (35/65)

Input Data to Implementation Procedure T53

Density @ obs. temp. ( $\text{kg/m}^3$ ) ... 532.57

Observed Temperature  $T_f$  ( $^{\circ}\text{C}$ ) ...  $-44.120$

Computed Data – last digit is rounded

T53/1

Input Data – rounded

Density, rounded to 0.1 ..... 532.6

Temperature rounded to 0.05 ....  $-44.10$

T53/2

$T_x$ , Kelvin ..... 229.05

T53/3

Density relative to 60° water .. 0.533124594601

T53/4

$T_x$  and relative density are within range, continue

T53/5, Call Table 23 procedure to obtain relative density at 60°F

RD60 from Table 23 ..... 0.440515294609

T53/6, Call Table 24 Procedure to obtain CTL from 60°F to 15°C

CTL from Table 24 ..... 1.002432483838

Relative density at 15°C ..... 0.441586840944

T53/7, Values returned from Tables 23 & 24 valid, continue

T53/8

Density at 15 °C ( $\text{kg/m}^3$ ) ..... 441.152319492337

T53/9

Density at 15°C (rounded) ..... 441.2



**Example 53/2 – Utilize n-Pentane & i-Hexane**

Input Data to Implementation Procedure T53

Density @ obs. temp. ( $\text{kg/m}^3$ ) ... 673.66

Observed Temperature  $T_f$  ( $^{\circ}\text{C}$ ) ... -23.330

Computed Data – last digit is rounded

T53/1

Input Data – rounded

Density, rounded to 0.1 ..... 673.7

Temperature rounded to 0.05 .... -23.35

T53/2

$T_x$ , Kelvin ..... 249.80

T53/3

Density relative to 60° water .. 0.674363573757

T53/4

$T_x$  and relative density are within range, continue

T53/5, Call Table 23 procedure to obtain relative density at 60°F

RD60 from Table 23 ..... 0.638538685930

T53/6, Call Table 24 Procedure to obtain CTL from 60°F to 15°C

CTL from Table 24 ..... 1.000825081981

Relative density at 15°C ..... 0.639065532694

T53/7, Values returned from Tables 23 & 24 valid, continue

T53/8

Density at 15 °C ( $\text{kg/m}^3$ ) ..... 638.436692209971

T53/9

Density at 15°C (rounded) ..... 638.4

**Example 53/3 – Utilize EP (35/65) & Propane**

Input Data to Implementation Procedure T53  
 Density @ obs. temp. (kg/m<sup>3</sup>) ... 245.49  
 Observed Temperature Tf (°C) ... 87.770  
 Computed Data – last digit is rounded  
 T53/1  
 Input Data – rounded  
 Density, rounded to 0.1 ..... 245.5  
 Temperature rounded to 0.05 .... 87.75  
 T53/2  
 Tx, Kelvin ..... 360.90  
 T53/3  
 Density relative to 60° water .. 0.245741809941  
 T53/4  
 Tx and relative density are within range, continue  
 T53/5, Call Table 23 procedure to obtain relative density at 60°F  
 RD60 from Table 23 ..... 0.488795025411  
 T53/6, Call Table 24 Procedure to obtain CTL from 60°F to 15°C  
 CTL from Table 24 ..... 1.001786178364  
 Relative density at 15°C ..... 0.489668100510  
 T53/7, Values returned from Tables 23 & 24 valid, continue  
 T53/8  
 Density at 15 °C (kg/m<sup>3</sup>) ..... 489.186267098922  
 T53/9  
 Density at 15°C (rounded) ..... 489.2

**Example 53/4 – Utilize n-Butane & i-Pentane**

Input Data to Implementation Procedure T53  
 Density @ obs. temp. (kg/m<sup>3</sup>) ... 499.55  
 Observed Temperature Tf (°C) ... 87.820  
 Computed Data – last digit is rounded  
 T53/1  
 Input Data – rounded  
 Density, rounded to 0.1 ..... 499.6  
 Temperature rounded to 0.05 .... 87.80  
 T53/2  
 Tx, Kelvin ..... 360.95  
 T53/3  
 Density relative to 60° water .. 0.500092090617  
 T53/4  
 Tx and relative density are within range, continue  
 T53/5, Call Table 23 procedure to obtain relative density at 60°F  
 RD60 from Table 23 ..... 0.591794896225  
 T53/6, Call Table 24 Procedure to obtain CTL from 60°F to 15°C  
 CTL from Table 24 ..... 1.001026475488  
 Relative density at 15°C ..... 0.592402359180  
 T53/7, Values returned from Tables 23 & 24 valid, continue  
 T53/8  
 Density at 15 °C (kg/m<sup>3</sup>) ..... 591.819435258795  
 T53/9  
 Density at 15°C (rounded) ..... 591.8

**Example 53/5 – Utilize Ethane & EP (65/35)**

Input Data to Implementation Procedure T53  
 Density @ obs. temp. (kg/m<sup>3</sup>) ... 395.09  
 Observed Temperature Tf (°C) ... 15.430  
 Computed Data – last digit is rounded  
 T53/1  
 Input Data – rounded  
 Density, rounded to 0.1 ..... 395.1  
 Temperature rounded to 0.05 .... 15.45  
 T53/2  
 Tx, Kelvin ..... 288.60  
 T53/3  
 Density relative to 60° water .. 0.395489161335  
 T53/4  
 Tx and relative density are within range, continue  
 T53/5, Call Table 23 procedure to obtain relative density at 60°F  
 RD60 from Table 23 ..... 0.395233433716  
 T53/6, Call Table 24 Procedure to obtain CTL from 60°F to 15°C  
 CTL from Table 24 ..... 1.003392579214  
 Relative density at 15°C ..... 0.396574294447  
 T53/7, Values returned from Tables 23 & 24 valid, continue  
 T53/8  
 Density at 15 °C (kg/m<sup>3</sup>) ..... 396.184065341566  
 T53/9  
 Density at 15°C (rounded) ..... 396.2

**Example 53/6 – Utilize i-Butane & n-Butane**

Input Data to Implementation Procedure T53  
 Density @ obs. temp. ( $\text{kg/m}^3$ ) ... 449.59  
 Observed Temperature  $T_f$  ( $^{\circ}\text{C}$ ) ... 93.020  
 Computed Data – last digit is rounded  
 T53/1  
 Input Data – rounded  
 Density, rounded to 0.1 ..... 449.6  
 Temperature rounded to 0.05 .... 93.00  
 T53/2  
 $T_x$ , Kelvin ..... 366.15  
 T53/3  
 Density relative to 60° water .. 0.450042842157  
 T53/4  
 $T_x$  and relative density are within range, continue  
 T53/5, Call Table 23 procedure to obtain relative density at 60°F  
 RD60 from Table 23 ..... 0.565490291365  
 T53/6, Call Table 24 Procedure to obtain CTL from 60°F to 15°C  
 CTL from Table 24 ..... 1.001176265550  
 Relative density at 15°C ..... 0.566155458114  
 T53/7, Values returned from Tables 23 & 24 valid, continue  
 T53/8  
 Density at 15 °C ( $\text{kg/m}^3$ ) ..... 565.598361142720  
 T53/9  
 Density at 15°C (rounded) ..... 565.6

**Example 53/7 – Utilize i-Hexane & n-Hexane**

```

Input Data to Implementation Procedure T53
Density @ obs. temp. (kg/m3) ... 600.74
Observed Temperature Tf (°C) ... 80.650
  Computed Data – last digit is rounded
T53/1
  Input Data – rounded
Density, rounded to 0.1 ..... 600.7
Temperature rounded to 0.05 .... 80.65
T53/2
Tx, Kelvin ..... 353.80
T53/3
Density relative to 60° water .. 0.601291671004
T53/4
Tx and relative density are within range, continue
T53/5, Call Table 23 procedure to obtain relative density at 60°F
RD60 from Table 23 ..... 0.662699711760
T53/6, Call Table 24 Procedure to obtain CTL from 60°F to 15°C
CTL from Table 24 ..... 1.000745797303
Relative density at 15°C ..... 0.663193951418
T53/7, Values returned from Tables 23 & 24 valid, continue
T53/8
Density at 15 °C (kg/m3) ..... 662.541368569934
T53/9
Density at 15°C (rounded) ..... 662.5

```

**Example 53/8 – Calculated RD60 near 0.6880 using n-Hexane & n-Heptane**

Input Data to Implementation Procedure T53  
 Density @ obs. temp. (kg/m<sup>3</sup>) ... 736.80  
 Observed Temperature Tf (°C) ... -44.230  
 Computed Data – last digit is rounded  
 T53/1  
 Input Data – rounded  
 Density, rounded to 0.1 ..... 736.8  
 Temperature rounded to 0.05 .... -44.25  
 T53/2  
 Tx, Kelvin ..... 228.90  
 T53/3  
 Density relative to 60° water .. 0.737525725314  
 T53/4  
 Tx and relative density are within range, continue  
 T53/5, Call Table 23 procedure to obtain relative density at 60°F  
 RD60 from Table 23 ..... 0.687974688885  
 T53/6, Call Table 24 Procedure to obtain CTL from 60°F to 15°C  
 CTL from Table 24 ..... 1.000678561307  
 Relative density at 15°C ..... 0.688441521889  
 T53/7, Values returned from Tables 23 & 24 valid, continue  
 T53/8  
 Density at 15 °C (kg/m<sup>3</sup>) ..... 687.764095431267  
 T53/9  
 Density at 15°C (rounded) ..... 687.8

**Example 53/9 – Calculated RD60 near 0.3500 using EE (68/32) & Ethane**

Input Data to Implementation Procedure T53  
 Density @ obs. temp. (kg/m<sup>3</sup>) ... 224.56  
 Observed Temperature Tf (°C) ... 30.680  
 Computed Data – last digit is rounded  
 T53/1  
 Input Data – rounded  
 Density, rounded to 0.1 ..... 224.6  
 Temperature rounded to 0.05 .... 30.70  
 T53/2  
 Tx, Kelvin ..... 303.85  
 T53/3  
 Density relative to 60° water .. 0.224821224084  
 T53/4  
 Tx and relative density are within range, continue  
 T53/5, Call Table 23 procedure to obtain relative density at 60°F  
 RD60 from Table 23 ..... 0.350001829424  
 T53/6, Call Table 24 Procedure to obtain CTL from 60°F to 15°C  
 CTL from Table 24 ..... 1.005770230278  
 Relative density at 15°C ..... 0.352021420577  
 T53/7, Values returned from Tables 23 & 24 valid, continue  
 T53/8  
 Density at 15 °C (kg/m<sup>3</sup>) ..... 351.675031499270  
 T53/9  
 Density at 15°C (rounded) ..... 351.7



**Example 53/10 – T23/6, RD<sub>tf</sub> < lower boundary using EE (68/32) & Ethane**

```
Input Data to Implementation Procedure T53
Density @ obs. temp. (kg/m3) ... 339.63
Observed Temperature Tf (°C) ... 18.130
  Computed Data – last digit is rounded
T53/1
  Input Data – rounded
Density, rounded to 0.1 ..... 339.6
Temperature rounded to 0.05 .... 18.15
T53/2
Tx, Kelvin ..... 291.30
T53/3
Density relative to 60° water .. 0.339934495544
T53/4
Tx and relative density are within range, continue
T53/5, Call Table 23 procedure to obtain relative density at 60°F
RD60 from Table 23 ..... -1.0
Input data is outside range of Table 23, no solution
```

**Example 53/11 – T23/6, RDtf > upper boundary using n-Hexane & n-Heptane**

```

      Input Data to Implementation Procedure T53
Density @ obs. temp. (kg/m3) ... 727.86
Observed Temperature Tf (°C) ... -33.070
      Computed Data – last digit is rounded
T53/1
      Input Data – rounded
Density, rounded to 0.1 ..... 727.9
Temperature rounded to 0.05 .... -33.05
T53/2
Tx, Kelvin ..... 240.10
T53/3
Density relative to 60° water .. 0.728616959088
T53/4
Tx and relative density are within range, continue
T53/5, Call Table 23 procedure to obtain relative density at 60°F
RD60 from Table 23 ..... -1.0
Input data is outside range of Table 23, no solution

```

**Example 53/12 – Density < input range limit**

Input Data to Implementation Procedure T53

Density @ obs. temp. (kg/m<sup>3</sup>) ... 209.74

Observed Temperature Tf (°C) ... 11.530

Computed Data – last digit is rounded

T53/1

Input Data – rounded

Density, rounded to 0.1 ..... 209.7

Temperature rounded to 0.05 .... 11.55

T53/2

Tx, Kelvin ..... 284.70

T53/3

Density relative to 60° water .. 0.209906548043

T53/4

Relative density is less than 0.2100, no solution

**Example 53/13 – Input density > input range limit**

Input Data to Implementation Procedure T53

Density @ obs. temp. (kg/m<sup>3</sup>) ... 739.32

Observed Temperature Tf (°C) ... 11.530

Computed Data – last digit is rounded

T53/1

Input Data – rounded

Density, rounded to 0.1 ..... 739.3

Temperature rounded to 0.05 .... 11.55

T53/2

Tx, Kelvin ..... 284.70

T53/3

Density relative to 60° water .. 0.740028187737

T53/4

Relative density is greater than 0.7400, no solution

**Example 53/14 – Input temperature < input range limit**

Input Data to Implementation Procedure T53  
Density @ obs. temp. (kg/m<sup>3</sup>) ... 645.62  
Observed Temperature Tf (°C) ... -46.030  
Computed Data – last digit is rounded  
T53/1  
Input Data – rounded  
Density, rounded to 0.1 ..... 645.6  
Temperature rounded to 0.05 .... -46.05  
T53/2  
Tx, Kelvin ..... 227.10  
T53/3  
Density relative to 60° water .. 0.646235896122  
T53/4  
Tx less than 227.15, no solution

**Example 53/15 – Input temperature > input range limit**

Input Data to Implementation Procedure T53

Density @ obs. temp. (kg/m<sup>3</sup>) ... 645.62

Observed Temperature Tf (°C) ... 93.070

Computed Data – last digit is rounded

T53/1

Input Data – rounded

Density, rounded to 0.1 ..... 645.6

Temperature rounded to 0.05 .... 93.05

T53/2

Tx, Kelvin ..... 366.20

T53/3

Density relative to 60° water .. 0.646235896122

T53/4

Tx greater than 366.15, no solution

### 5.3 CTL (Table 60) and Density (Table 59) for NGL and LPG using a 20°C Base Temperature

#### 5.3.1 Implementation Procedure for Table 60E (20°C Basis)

This section presents the implementation procedure T60 for the computation of Temperature Correction Factors,  $C_{TL}$ s. The  $C_{TL}$ s are used to calculate volumes of fluid at the base temperature from volumes at some known temperature. The fluids are characterized by the specification of density at the base temperature, 20°C.

##### 5.3.1.1 Inputs and Outputs

Inputs: Density at 20°C,  $\rho_{20}$  (kg/m<sup>3</sup>)  
Observed temperature,  $T_F$  (°C)

Output: Temperature Correction Factor,  $C_{TL}$  (from  $T_F$  to  $T_B$ )

##### 5.3.1.2 Outline of Calculations

The calculations are performed using an extended two-fluid corresponding states equation. By comparing densities at 60°F, two reference fluids are selected so that one is slightly more dense and one that is slightly less dense than the observed fluid. The densities of these reference fluids are then scaled to the observed reduced temperature (reduced by the critical temperature of the fluid of interest). The Temperature Correction Factor is then computed from the reference fluid densities. See Figure 5 for a general flow chart of the calculation procedure.

##### 5.3.1.3 T60 Implementation Procedure

<u>T60/Step Number</u>	<u>Operation/Procedure at that step</u>
T60/1:	Round the density $\rho_{20}$ to the nearest 0.1 and round the observed temperature $T_F$ to the nearest 0.05°C.
T60/2:	Convert the rounded observed temperature to units of Kelvin, $T_x$ :
$T_x = T_F + 273.15$	
T60/3:	The resultant temperature $T_x$ and $\rho_{20}$ must fall within the following boundaries:
	Temperature between 227.15 and 366.15 K, inclusive (equivalent to -46 to 93°C, or -50.8 to 199.4°F)
	Density between 331.7 and 683.6 kg/m <sup>3</sup> inclusive
If these values do not fall in these ranges, then the standard does not apply. Flag this result (possibly by returning a -1 for $C_{TL}$ ) and exit this procedure.	

Note: The density boundaries tested in this step slightly exceed the boundaries used within the T24 implementation procedure (0.3500 to 0.6880 relative density at 60°F) that act as the true limits for this method.

T60/4: Convert the 20°C density to relative density, relative to the density of water at 60°F:

$$\gamma_{TB} = \frac{\rho_{20}}{999.016}$$

T60/5: Use the procedure described in Section 5.1.2 for Table 23 to compute a relative density at 60°F from the known relative density at 20°C. Enter the procedure at Step T23/4 so as to avoid additional rounding of the input values. Inputs to Procedure T23 are the values of  $T_{BK}$  and  $\gamma_{TB}$ , where  $T_{BK}$  is the base temperature 20°C in Kelvin (293.15 K) and  $\gamma_{TB}$  is the density at the base temperature 20°C. Implementation procedure T23 is exited after Step T23/11 so as not to round the output values. The converged output from Step T23/11 is  $\gamma_{60}$ .

T60/6: The resultant density  $\gamma_{60}$ , if it were rounded to the nearest 0.0001, must fall within 0.3500 and 0.6880 inclusive. Test  $\gamma_{60}$  to ensure it is within the following boundaries:

Relative density greater than or equal to 0.34995 and less than 0.68805

If the relative density does not fall in this range, then the standard does not apply. Flag this result (return a -1 for  $C_{TL}$ ) and exit this procedure.

T60/7: Use the procedure described in Section 5.1.1 for Table 24 to compute the Temperature Correction Factor ( $C_{TL1}$ ) from 60°F to the observed temperature,  $T_x$ . This step provides the factor used to reduce an observed volume at  $T_x$  to a volume at 60°F when the relative density at 60°F,  $\gamma_{60}$ , is known. Enter implementation procedure T24 with  $T_x$  and  $\gamma_{60}$  at Step T24/4 to avoid double rounding of the inputs. On exit skip Step T24/14 to avoid rounding the output  $C_{TL1}$ .

By definition:

$$C_{TL1} = \frac{V_{60}}{V_{Tx}} = \frac{\gamma_{Tx}}{\gamma_{60}}$$

T60/8: Use the procedure described in Section 5.1.1 for Table 24 to compute the Temperature Correction Factor ( $C_{TL2}$ ) from 60°F to the new base temperature 20°C. This step provides the factor used to reduce an observed volume at 20°C to a volume at 60°F when the relative density at 60°F,  $\gamma_{60}$ , is known. Enter implementation procedure T24 at Step T24/4 to avoid double rounding of the inputs. The inputs are  $T_{BK}$  and  $\gamma_{60}$ , where  $T_{BK}$  is the base temperature 20°C in Kelvin (293.15 K). On exit skip Step T24/14 to avoid double rounding of the output  $C_{TL1}$ .

By definition:



$$C_{TL2} = \frac{V_{60}}{V_{20}} = \frac{\gamma_{TB}}{\gamma_{60}}$$

T60/9: Compute the desired  $C_{TL}$  to reduce volume from the observed temperature,  $T_x$ , to the base condition of 20°C. The defining formulas show that the calculation is made by computing the ratio  $C_{TL1}/C_{TL2}$ .


$$\frac{C_{TL1}}{C_{TL2}} = \frac{\left( \frac{V_{60}}{V_{Tx}} \right)}{\left( \frac{V_{60}}{V_{20}} \right)} = \frac{V_{20}}{V_{Tx}}$$

$$C_{TL1} = \frac{V_{20}}{V_{Tx}} = \frac{\rho_{Tx}}{\rho_{20}}$$

T60/10: Perform error check to ascertain that only positive  $C_{TL}$  is used. If  $C_{TL}$  is less than or equal to 0, set an error flag (such as  $C_{TL} = -1$ ) and exit this procedure.

T60/11: Round the Temperature Correction Factor  $C_{TL}$  to the nearest 0.00001. Exit this procedure.

**Figure 5. Flow Chart of Implementation Procedure for Table 60**



### 5.3.1.4 Examples for Section 5.3.1 (Table 60)

(See Table 1 for properties of the Reference Fluids)

#### Example 60/1 – Utilize EE (68/32) and Ethane

Input Data to Implementation Procedure T60  
 Density (kg/m<sup>3</sup>) @ 20°C (Den20) . 332.69  
 Observed temperature Tf, °C .... -5.020  
 Computed Data – last digit is rounded  
 T60/1  
 Input Data – rounded  
 Den20, rounded to 0.1 ..... 332.7  
 Tf, °C, rounded to 0.05 ..... -5.00  
 T60/2  
 Tx, Kelvin ..... 268.15  
 T60/3  
 Tx and Den20 are within range, continue  
 T60/4  
 Den20 relative to 60°F water ... 0.333027699256  
 T60/5, Call Table 23 procedure  
 RD60 from Table 23 ..... 0.350810339452  
 T60/6  
 RD60 is within range, continue  
 T60/7, Call Table 24 Procedure with Tx and RD60  
 Reference Fluid 1 ..... EE (68/32)  
 Reference Fluid 2 ..... Ethane  
 CTL1, Tx to 60°F ..... 1.164305432161  
 T60/8, Call Table 24 Procedure with 20°C and RD60  
 Reference Fluid 1 ..... EE (68/32)  
 Reference Fluid 2 ..... Ethane  
 CTL2, 20°C to 60°F ..... 0.949309823927  
 T60/9 CTL = CTL1/CTL2  
 CTL, Tx to 20°C ..... 1.226475701416  
 T60/10  
 CTL is positive, continue  
 T60/11 CTL rounded  
 CTL (rounded) ..... 1.22648

**Example 60/2 – Utilize Ethane and EP (65/35)**

Input Data to Implementation Procedure T60  
 Density (kg/m<sup>3</sup>) @ 20°C (Den20) . 399.55  
 Observed temperature Tf, °C .... -3.920  
 Computed Data – last digit is rounded  
 T60/1  
 Input Data – rounded  
 Den20, rounded to 0.1 ..... 399.6  
 Tf, °C, rounded to 0.05 ..... -3.90  
 T60/2  
 Tx, Kelvin ..... 269.25  
 T60/3  
 Tx and Den20 are within range, continue  
 T60/4  
 Den20 relative to 60°F water ... 0.399993593696  
 T60/5, Call Table 23 procedure  
 RD60 from Table 23 ..... 0.410257484971  
 T60/6  
 RD60 is within range, continue  
 T60/7, Call Table 24 Procedure with Tx and RD60  
 Reference Fluid 1 ..... Ethane  
 Reference Fluid 2 ..... EP (65/35)  
 CTL1, Tx to 60°F ..... 1.094238548593  
 T60/8, Call Table 24 Procedure with 20°C and RD60  
 Reference Fluid 1 ..... Ethane  
 Reference Fluid 2 ..... EP (65/35)  
 CTL2, 20°C to 60°F ..... 0.974981830112  
 T60/9 CTL = CTL1/CTL2  
 CTL, Tx to 20°C ..... 1.122316862527  
 T60/10  
 CTL is positive, continue  
 T60/11 CTL rounded  
 CTL (rounded) ..... 1.12232

**Example 60/3 – Utilize EP (65/35) and EP (35/65)**

Input Data to Implementation Procedure T60  
 Density (kg/m<sup>3</sup>) @ 20°C (Den20) . 451.09  
 Observed temperature Tf, °C .... 30.774  
 Computed Data – last digit is rounded  
 T60/1  
 Input Data – rounded  
 Den20, rounded to 0.1 ..... 451.1  
 Tf, °C, rounded to 0.05 ..... 30.75  
 T60/2  
 Tx, Kelvin ..... 303.90  
 T60/3  
 Tx and Den20 are within range, continue  
 T60/4  
 Den20 relative to 60°F water ... 0.451544319610  
 T60/5, Call Table 23 procedure  
 RD60 from Table 23 ..... 0.459584427423  
 T60/6  
 RD60 is within range, continue  
 T60/7, Call Table 24 Procedure with Tx and RD60  
 Reference Fluid 1 ..... EP (65/35)  
 Reference Fluid 2 ..... EP (35/65)  
 CTL1, Tx to 60°F ..... 0.936730755171  
 T60/8, Call Table 24 Procedure with 20°C and RD60  
 Reference Fluid 1 ..... EP (65/35)  
 Reference Fluid 2 ..... EP (35/65)  
 CTL2, 20°C to 60°F ..... 0.982505700078  
 T60/9 CTL = CTL1/CTL2  
 CTL, Tx to 20°C ..... 0.953409995582  
 T60/10  
 CTL is positive, continue  
 T60/11 CTL rounded  
 CTL (rounded) ..... 0.95341

**Example 60/4 – Utilize EP (35/65) and Propane**

Input Data to Implementation Procedure T60  
 Density (kg/m<sup>3</sup>) @ 20°C (Den20) . 489.92  
 Observed temperature Tf, °C .... 84.975  
 Computed Data – last digit is rounded  
 T60/1  
 Input Data – rounded  
 Den20, rounded to 0.1 ..... 489.9  
 Tf, °C, rounded to 0.05 ..... 85.00  
 T60/2  
 Tx, Kelvin ..... 358.15  
 T60/3  
 Tx and Den20 are within range, continue  
 T60/4  
 Den20 relative to 60°F water ... 0.490382536416  
 T60/5, Call Table 23 procedure  
 RD60 from Table 23 ..... 0.497272599314  
 T60/6  
 RD60 is within range, continue  
 T60/7, Call Table 24 Procedure with Tx and RD60  
 Reference Fluid 1 ..... EP (35/65)  
 Reference Fluid 2 ..... Propane  
 CTL1, Tx to 60°F ..... 0.659050245916  
 T60/8, Call Table 24 Procedure with 20°C and RD60  
 Reference Fluid 1 ..... EP (35/65)  
 Reference Fluid 2 ..... Propane  
 CTL2, 20°C to 60°F ..... 0.986144294080  
 T60/9 CTL = CTL1/CTL2  
 CTL, Tx to 20°C ..... 0.668310154886  
 T60/10  
 CTL is positive, continue  
 T60/11 CTL rounded  
 CTL (rounded) ..... 0.66831

**Example 60/5 – Utilize Propane and i-Butane**

Input Data to Implementation Procedure T60  
 Density ( $\text{kg/m}^3$ ) @  $20^\circ\text{C}$  (Den20) . 539.49  
 Observed temperature  $T_f$ ,  $^\circ\text{C}$  .... 68.360  
 Computed Data – last digit is rounded  
 T60/1  
 Input Data – rounded  
 Den20, rounded to 0.1 ..... 539.5  
 $T_f$ ,  $^\circ\text{C}$ , rounded to 0.05 ..... 68.35  
 T60/2  
 $T_x$ , Kelvin ..... 341.50  
 T60/3  
 $T_x$  and Den20 are within range, continue  
 T60/4  
 Den20 relative to  $60^\circ\text{F}$  water ... 0.540031390889  
 T60/5, Call Table 23 procedure  
 RD60 from Table 23 ..... 0.545748636061  
 T60/6  
 RD60 is within range, continue  
 T60/7, Call Table 24 Procedure with  $T_x$  and RD60  
 Reference Fluid 1 ..... Propane  
 Reference Fluid 2 ..... i-Butane  
 CTL1,  $T_x$  to  $60^\circ\text{F}$  ..... 0.856605931918  
 T60/8, Call Table 24 Procedure with  $20^\circ\text{C}$  and RD60  
 Reference Fluid 1 ..... Propane  
 Reference Fluid 2 ..... i-Butane  
 CTL2,  $20^\circ\text{C}$  to  $60^\circ\text{F}$  ..... 0.989524032138  
 T60/9 CTL = CTL1/CTL2  
 CTL,  $T_x$  to  $20^\circ\text{C}$  ..... 0.865674712384  
 T60/10  
 CTL is positive, continue  
 T60/11 CTL rounded  
 CTL (rounded) ..... 0.86567

**Example 60/6 – Utilize i-Butane and n-Butane**

Input Data to Implementation Procedure T60  
 Density (kg/m<sup>3</sup>) @ 20°C (Den20) . 569.42  
 Observed temperature Tf, °C .... -16.090  
 Computed Data – last digit is rounded  
 T60/1  
 Input Data – rounded  
 Den20, rounded to 0.1 ..... 569.4  
 Tf, °C, rounded to 0.05 ..... -16.10  
 T60/2  
 Tx, Kelvin ..... 257.05  
 T60/3  
 Tx and Den20 are within range, continue  
 T60/4  
 Den20 relative to 60°F water ... 0.569960841468  
 T60/5, Call Table 23 procedure  
 RD60 from Table 23 ..... 0.575142670956  
 T60/6  
 RD60 is within range, continue  
 T60/7, Call Table 24 Procedure with Tx and RD60  
 Reference Fluid 1 ..... i-Butane  
 Reference Fluid 2 ..... n-Butane  
 CTL1, Tx to 60°F ..... 1.060732897657  
 T60/8, Call Table 24 Procedure with 20°C and RD60  
 Reference Fluid 1 ..... i-Butane  
 Reference Fluid 2 ..... n-Butane  
 CTL2, 20°C to 60°F ..... 0.990990359414  
 T60/9 CTL = CTL1/CTL2  
 CTL, Tx to 20°C ..... 1.070376606170  
 T60/10  
 CTL is positive, continue  
 T60/11 CTL rounded  
 CTL (rounded) ..... 1.07038



**Example 60/7 – Utilize n-Butane and i-Pentane**

Input Data to Implementation Procedure T60  
 Density ( $\text{kg/m}^3$ ) @ 20°C (Den20) . 599.37  
 Observed temperature Tf, °C .... 43.360  
 Computed Data – last digit is rounded  
 T60/1  
 Input Data – rounded  
 Den20, rounded to 0.1 ..... 599.4  
 Tf, °C, rounded to 0.05 ..... 43.35  
 T60/2  
 Tx, Kelvin ..... 316.50  
 T60/3  
 Tx and Den20 are within range, continue  
 T60/4  
 Den20 relative to 60°F water ... 0.599990390544  
 T60/5, Call Table 23 procedure  
 RD60 from Table 23 ..... 0.604700215005  
 T60/6  
 RD60 is within range, continue  
 T60/7, Call Table 24 Procedure with Tx and RD60  
 Reference Fluid 1 ..... n-Butane  
 Reference Fluid 2 ..... i-Pentane  
 CTL1, Tx to 60°F ..... 0.949609422686  
 T60/8, Call Table 24 Procedure with 20°C and RD60  
 Reference Fluid 1 ..... n-Butane  
 Reference Fluid 2 ..... i-Pentane  
 CTL2, 20°C to 60°F ..... 0.992211317977  
 T60/9 CTL = CTL1/CTL2  
 CTL, Tx to 20°C ..... 0.957063687423  
 T60/10  
 CTL is positive, continue  
 T60/11 CTL rounded  
 CTL (rounded) ..... 0.95706

**Example 60/8 – Utilize i-Pentane and n-Pentane**

Input Data to Implementation Procedure T60  
 Density (kg/m<sup>3</sup>) @ 20°C (Den20) . 624.42  
 Observed temperature Tf, °C .... 76.650  
 Computed Data – last digit is rounded  
 T60/1  
 Input Data – rounded  
 Den20, rounded to 0.1 ..... 624.4  
 Tf, °C, rounded to 0.05 ..... 76.65  
 T60/2  
 Tx, Kelvin ..... 349.80  
 T60/3  
 Tx and Den20 are within range, continue  
 T60/4  
 Den20 relative to 60°F water ... 0.625015014775  
 T60/5, Call Table 23 procedure  
 RD60 from Table 23 ..... 0.629388813227  
 T60/6  
 RD60 is within range, continue  
 T60/7, Call Table 24 Procedure with Tx and RD60  
 Reference Fluid 1 ..... i-Pentane  
 Reference Fluid 2 ..... n-Pentane  
 CTL1, Tx to 60°F ..... 0.896907512500  
 T60/8, Call Table 24 Procedure with 20°C and RD60  
 Reference Fluid 1 ..... i-Pentane  
 Reference Fluid 2 ..... n-Pentane  
 CTL2, 20°C to 60°F ..... 0.993050721018  
 T60/9 CTL = CTL1/CTL2  
 CTL, Tx to 20°C ..... 0.903183990019  
 T60/10  
 CTL is positive, continue  
 T60/11 CTL rounded  
 CTL (rounded) ..... 0.90318

**Example 60/9 – Utilize n-Pentane and i-Hexane**

Input Data to Implementation Procedure T60  
 Density (kg/m<sup>3</sup>) @ 20°C (Den20) . 639.41  
 Observed temperature Tf, °C .... -24.460  
 Computed Data – last digit is rounded  
 T60/1  
 Input Data – rounded  
 Den20, rounded to 0.1 ..... 639.4  
 Tf, °C, rounded to 0.05 ..... -24.45  
 T60/2  
 Tx, Kelvin ..... 248.70  
 T60/3  
 Tx and Den20 are within range, continue  
 T60/4  
 Den20 relative to 60°F water ... 0.640029789313  
 T60/5, Call Table 23 procedure  
 RD60 from Table 23 ..... 0.644192277735  
 T60/6  
 RD60 is within range, continue  
 T60/7, Call Table 24 Procedure with Tx and RD60  
 Reference Fluid 1 ..... n-Pentane  
 Reference Fluid 2 ..... i-Hexane  
 CTL1, Tx to 60°F ..... 1.056377254246  
 T60/8, Call Table 24 Procedure with 20°C and RD60  
 Reference Fluid 1 ..... n-Pentane  
 Reference Fluid 2 ..... i-Hexane  
 CTL2, 20°C to 60°F ..... 0.993538437998  
 T60/9 CTL = CTL1/CTL2  
 CTL, Tx to 20°C ..... 1.063247493850  
 T60/10  
 CTL is positive, continue  
 T60/11 CTL rounded  
 CTL (rounded) ..... 1.06325

**Example 60/10 – Utilize i-Hexane and n-Hexane**

Input Data to Implementation Procedure T60  
 Density (kg/m<sup>3</sup>) @ 20°C (Den20) . 659.38  
 Observed temperature Tf, °C .... 80.580  
 Computed Data – last digit is rounded  
 T60/1  
 Input Data – rounded  
 Den20, rounded to 0.1 ..... 659.4  
 Tf, °C, rounded to 0.05 ..... 80.60  
 T60/2  
 Tx, Kelvin ..... 353.75  
 T60/3  
 Tx and Den20 are within range, continue  
 T60/4  
 Den20 relative to 60°F water ... 0.660049488697  
 T60/5, Call Table 23 procedure  
 RD60 from Table 23 ..... 0.664004852143  
 T60/6  
 RD60 is within range, continue  
 T60/7, Call Table 24 Procedure with Tx and RD60  
 Reference Fluid 1 ..... i-Hexane  
 Reference Fluid 2 ..... n-Hexane  
 CTL1, Tx to 60°F ..... 0.908011926489  
 T60/8, Call Table 24 Procedure with 20°C and RD60  
 Reference Fluid 1 ..... i-Hexane  
 Reference Fluid 2 ..... n-Hexane  
 CTL2, 20°C to 60°F ..... 0.994043170870  
 T60/9 CTL = CTL1/CTL2  
 CTL, Tx to 20°C ..... 0.913453211186  
 T60/10  
 CTL is positive, continue  
 T60/11 CTL rounded  
 CTL (rounded) ..... 0.91345

**Example 60/11 – Utilize n-Hexane and n-Heptane**

Input Data to Implementation Procedure T60  
 Density (kg/m<sup>3</sup>) @ 20°C (Den20) . 669.38  
 Observed temperature Tf, °C .... 82.790  
 Computed Data – last digit is rounded  
 T60/1  
 Input Data – rounded  
 Den20, rounded to 0.1 ..... 669.4  
 Tf, °C, rounded to 0.05 ..... 82.80  
 T60/2  
 Tx, Kelvin ..... 355.95  
 T60/3  
 Tx and Den20 are within range, continue  
 T60/4  
 Den20 relative to 60°F water ... 0.670059338389  
 T60/5, Call Table 23 procedure  
 RD60 from Table 23 ..... 0.673917506957  
 T60/6  
 RD60 is within range, continue  
 T60/7, Call Table 24 Procedure with Tx and RD60  
 Reference Fluid 1 ..... n-Hexane  
 Reference Fluid 2 ..... n-Heptane  
 CTL1, Tx to 60°F ..... 0.909032061079  
 T60/8, Call Table 24 Procedure with 20°C and RD60  
 Reference Fluid 1 ..... n-Hexane  
 Reference Fluid 2 ..... n-Heptane  
 CTL2, 20°C to 60°F ..... 0.994275014129  
 T60/9 CTL = CTL1/CTL2  
 CTL, Tx to 20°C ..... 0.914266222283  
 T60/10  
 CTL is positive, continue  
 T60/11 CTL rounded  
 CTL (rounded) ..... 0.91427

**Example 60/12 – Reduced temperature  $T_{r,x}$  greater than 1**

Input Data to Implementation Procedure T60

Density ( $\text{kg/m}^3$ ) @ 20°C (Den20) . 399.83

Observed temperature  $T_f$ , °C .... 90.570

Computed Data – last digit is rounded

T60/1

Input Data – rounded

Den20, rounded to 0.1 ..... 399.8

$T_f$ , °C, rounded to 0.05 ..... 90.55

T60/2

$T_x$ , Kelvin ..... 363.70

T60/3

$T_x$  and Den20 are within range, continue

T60/4

Den20 relative to 60°F water ... 0.400193790690

T60/5, Call Table 23 procedure

RD60 from Table 23 ..... 0.410447384415

T60/6

RD60 is within range, continue

T60/7, Call Table 24 Procedure with  $T_x$  and RD60

Reference Fluid 1 ..... Ethane

Reference Fluid 2 ..... EP (65/35)

Reduced temperature  $T_{r,x}$  greater than 1.0, no solution

CTL1,  $T_x$  to 60°F ..... -1.0

Value from Table 24 not valid, no solution

**Example 60/13 –  $T_f < \text{lower range limit}$** 

Input Data to Implementation Procedure T60

Density ( $\text{kg/m}^3$ ) @ 20°C (Den20) . 449.56

Observed temperature  $T_f$ , °C .... -46.030

Computed Data – last digit is rounded

T60/1

Input Data – rounded

Den20, rounded to 0.1 ..... 449.6

$T_f$ , °C, rounded to 0.05 ..... -46.05

T60/2

$T_x$ , Kelvin ..... 227.10

T60/3

$T_x$  less than 227.15, no solution

**Example 60/14 – Den20 < lower range limit**

Input Data to Implementation Procedure T60

Density (kg/m<sup>3</sup>) @ 20°C (Den20) . 331.59

Observed temperature Tf, °C .... 64.440

Computed Data – last digit is rounded

T60/1

Input Data – rounded

Den20, rounded to 0.1 ..... 331.6

Tf, °C, rounded to 0.05 ..... 64.45

T60/2

Tx, Kelvin ..... 337.60

T60/3

Density is less than 331.7, no solution



**Example 60/15 –  $T_f >$  upper range limit**

Input Data to Implementation Procedure T60

Density ( $\text{kg/m}^3$ ) @ 20°C (Den20) . 449.56

Observed temperature  $T_f$ , °C .... 93.030

Computed Data – last digit is rounded

T60/1

Input Data – rounded

Den20, rounded to 0.1 ..... 449.6

$T_f$ , °C, rounded to 0.05 ..... 93.05

T60/2

$T_x$ , Kelvin ..... 366.20

T60/3

$T_x$  greater than 366.15, no solution

**Example 60/16 – Den20 > upper range limit**

Input Data to Implementation Procedure T60  
Density (kg/m<sup>3</sup>) @ 20°C (Den20) . 683.65  
Observed temperature Tf, °C .... -17.780  
    Computed Data – last digit is rounded  
T60/1  
    Input Data – rounded  
Den20, rounded to 0.1 ..... 683.7  
Tf, °C, rounded to 0.05 ..... -17.80  
T60/2  
Tx, Kelvin ..... 255.35  
T60/3  
Den20 is greater than 683.6, no solution

**Example 60/17 – Tf & Den20 = upper range limits**

Input Data to Implementation Procedure T60

Density (kg/m<sup>3</sup>) @ 20°C (Den20) . 683.64

Observed temperature Tf, °C .... 93.020

Computed Data – last digit is rounded

T60/1

Input Data – rounded

Den20, rounded to 0.1 ..... 683.6

Tf, °C, rounded to 0.05 ..... 93.00

T60/2

Tx, Kelvin ..... 366.15

T60/3

Tx and Den20 are within range, continue

T60/4

Den20 relative to 60°F water ... 0.684273324952

T60/5, Call Table 23 procedure

RD60 from Table 23 ..... 0.688015480920

T60/6

RD60 is within range, continue

T60/7, Call Table 24 Procedure with Tx and RD60

Reference Fluid 1 ..... n-Hexane

Reference Fluid 2 ..... n-Heptane

CTL1, Tx to 60°F ..... 0.900472587577

T60/8, Call Table 24 Procedure with 20°C and RD60

Reference Fluid 1 ..... n-Hexane

Reference Fluid 2 ..... n-Heptane

CTL2, 20°C to 60°F ..... 0.994560942200

T60/9 CTL = CTL1/CTL2

CTL, Tx to 20°C ..... 0.905397094707

T60/10

CTL is positive, continue

T60/11 CTL rounded

CTL (rounded) ..... 0.90540

**Example 60/18 – Tf & Den20 = lower range limits**

Input Data to Implementation Procedure T60  
 Density (kg/m<sup>3</sup>) @ 20°C (Den20) . 331.67  
 Observed temperature Tf, °C .... -46.020  
 Computed Data – last digit is rounded  
 T60/1  
 Input Data – rounded  
 Den20, rounded to 0.1 ..... 331.7  
 Tf, °C, rounded to 0.05 ..... -46.00  
 T60/2  
 Tx, Kelvin ..... 227.15  
 T60/3  
 Tx and Den20 are within range, continue  
 T60/4  
 Den20 relative to 60°F water ... 0.332026714287  
 T60/5, Call Table 23 procedure  
 RD60 from Table 23 ..... -1.0  
 Input data is outside range of Table 23, no solution

### 5.3.2 Implementation Procedure for Table 59E (20°C Basis)

This section presents the implementation procedure T59 for calculating the densities of NGLs and LPGs at a base conditions of 20°C from known temperatures and densities.

Density readings must be corrected for the effect of temperature on the instrument prior to entering the density into the following implementation procedure.

#### 5.3.2.1 Inputs and Outputs

Inputs: Density at observed temperature,  $\rho_x$  (kg/m<sup>3</sup>)  
Observed temperature,  $T_F$  (°C)

Output: Density at 20°C,  $\rho_{20}$  (kg/m<sup>3</sup>)

#### 5.3.2.2 Outline of Calculations

The calculations are done using an extended two-fluid corresponding states equation. Two reference fluids are found that are slightly denser and slightly less dense than the observed fluid by comparing their densities at the observed temperature. Iteration must be performed to determine the value of the fluid's relative density at 60°F such that when the Temperature Correction Factor is applied, the observed relative density is obtained. The "guessed" value for the fluid's relative density at 60°F is constrained to lie between the relative densities at 60°F of these two reference fluids (as upper and lower bounds). As the iterations progress, these upper and lower bounds are "brought together" based upon intermediate calculations. The relative density at 20°C is then computed from the 60°F relative density by using scaling factors between the properties of the two reference fluids.

See Figure 6 for a general flow chart of the calculation procedure.

#### 5.3.2.3 T59 Implementation Procedure

<u>T59/Step Number</u>	<u>Operation/Procedure at that step</u>
T59/1:	Round the density $\rho_x$ to the nearest 0.1 and round the observed temperature $T_F$ to the nearest 0.05°C.
T59/2:	Convert the rounded observed temperature to units of Kelvin, $T_x$ :
	$T_x = T_F + 273.15$
T59/3:	Convert the density, $\rho_x$ , to relative density, $\gamma_x$ , relative to the density of water at 60°F.
	$\gamma_x = \frac{\rho_x}{999.016}$

T59/4: Check the values of temperature and relative density to ensure that they are in the proper range. The observed temperature  $T_x$  and relative density  $\gamma_x$  must fall within the following boundaries:

Temperature between 227.15 and 366.15 K, inclusive (equivalent to  $-46$  to  $93^\circ\text{C}$ , or  $-50.8$  to  $199.4^\circ\text{F}$ )

Relative density, if it were rounded to the nearest 0.0001, must fall within 0.2100 and 0.7400 inclusive. Test  $\gamma_x$  to ensure it is within the following boundaries:

Relative density greater than or equal to 0.20995 and less than 0.74005

If these values do not fall in these ranges, then the standard does not apply. Flag this result (possibly by returning  $-1$  for the density) and exit this procedure.

T59/5: Compute the relative density at  $60^\circ\text{F}$ ,  $\gamma_{60}$ , from the temperature and the relative density at the measurement condition,  $\gamma_x$ . Use the procedure described in Section 5.1.2 for Table 23 to perform this step. Enter the implementation procedure with  $\gamma_x$  and  $T_x$  at Step T23/4 so as to avoid additional rounding of the input values. Exit after Step T23/11 to avoid rounding the result.

T59/6: Compute the relative density at  $20^\circ\text{C}$ ,  $\gamma_{20}$ , from the relative density at  $60^\circ\text{F}$ . This is performed by using the procedure described in Section 5.1.1 for Table 24. Enter implementation procedure T24 with  $\gamma_{60}$  and  $T_x = 293.15$  (e.g.  $273.15 + 20$ ). Enter at Step T24/4 to avoid double rounding of the inputs. The  $C_{TL}$  for the conversion between  $\gamma_{60}$  and  $\gamma_{20}$  will be returned without rounding from Step T24/13. Compute  $\gamma_{20}$ :

$$\gamma_{20} = C_{TL} \times \gamma_{60}$$


T59/7: Insure that only valid values came from Steps T59/5 and T59/6. If the  $\gamma_{60}$  obtained from Section 5.2.1 for Table 23 is greater than  $-1$ , then proceed. If not, set the fluid density at  $20^\circ\text{C}$  to some flag value such as  $-1$  and quit. If the  $C_{TL}$  from Step T59/6 is negative, then set the fluid density at  $20^\circ\text{C}$  to the error flag condition and exit this procedure.

T59/8: Calculate the fluid density at  $20^\circ\text{C}$  from the relative density at  $20^\circ\text{C}$ .

$$\rho_{20} = \gamma_{20} \times 999.016$$

T59/9: Round the fluid density,  $\rho_{20}$ , to the nearest 0.1. Exit this procedure.

**Figure 6. Flow Chart of Implementation Procedure for Table 59**



### 5.3.2.4 Examples for Section 5.3.2 (Table 59E)

(See Table 1 for properties of the Reference Fluids)

#### Example 59/1 – T23/6, RDtf < lower boundary using EP (35/65) & Propane

```

Input Data to Implementation Procedure T59
Density at obs. temp. (kg/m3) .. 210.00
Observed Temperature Tf (°C) ... -44.500
  Computed Data – last digit is rounded
T59/1
  Input Data – rounded
Density, rounded to 0.1 ..... 210.0
Temperature rounded to 0.05 .... -44.50
T59/2
Tx, Kelvin ..... 228.65
T59/3
Density relative to 60° water .. 0.210206843534
T59/4
Tx and relative density are within range, continue
T59/5, Call Table 23 procedure to obtain relative density at 60°F
RD60 from Table 23 ..... -1.0
Input data is outside range of Table 23, no solution

```



**Example 59/2 – Utilize EP (65/35) & EP (35/65)**

Input Data to Implementation Procedure T59

Density at obs. temp. ( $\text{kg/m}^3$ ) .. 532.57

Observed Temperature  $T_f$  ( $^{\circ}\text{C}$ ) ... -44.120

Computed Data – last digit is rounded

T59/1

Input Data – rounded

Density, rounded to 0.1 ..... 532.6

Temperature rounded to 0.05 .... -44.10

T59/2

$T_x$ , Kelvin ..... 229.05

T59/3

Density relative to 60° water .. 0.533124594601

T59/4

$T_x$  and relative density are within range, continue

T59/5, Call Table 23 procedure to obtain relative density at 60°F

RD60 from Table 23 ..... 0.440515294609

T59/6, Call Table 24 Procedure to obtain CTL from 60°F to 20°C

CTL from Table 24 ..... 0.979997725752

20 °C relative density ..... 0.431703986876

T59/7, Values returned from Tables 23 & 24 valid, continue

T59/8

Density at 20°C ( $\text{kg/m}^3$ ) ..... 431.279190152813

T59/9

Density at 20°C (rounded) ..... 431.3

**Example 59/3 – Utilize n-Pentane & i-Hexane**

Input Data to Implementation Procedure T59

Density at obs. temp. ( $\text{kg/m}^3$ ) .. 673.66

Observed Temperature  $T_f$  ( $^{\circ}\text{C}$ ) ... -23.330

Computed Data – last digit is rounded

T59/1

Input Data – rounded

Density, rounded to 0.1 ..... 673.7

Temperature rounded to 0.05 .... -23.35

T59/2

$T_x$ , Kelvin ..... 249.80

T59/3

Density relative to 60° water .. 0.674363573757

T59/4

$T_x$  and relative density are within range, continue

T59/5, Call Table 23 procedure to obtain relative density at 60°F

RD60 from Table 23 ..... 0.638538685930

T59/6, Call Table 24 Procedure to obtain CTL from 60°F to 20°C

CTL from Table 24 ..... 0.993367912870

20 °C relative density ..... 0.634303841729

T59/7, Values returned from Tables 23 & 24 valid, continue

T59/8

Density at 20°C ( $\text{kg/m}^3$ ) ..... 633.679686748900

T59/9

Density at 20°C (rounded) ..... 633.7

**Example 59/4 – Utilize EP (35/65) & Propane**

Input Data to Implementation Procedure T59  
 Density at obs. temp. ( $\text{kg/m}^3$ ) .. 245.49  
 Observed Temperature  $T_f$  ( $^{\circ}\text{C}$ ) ... 87.770  
 Computed Data – last digit is rounded  
 T59/1  
 Input Data – rounded  
 Density, rounded to 0.1 ..... 245.5  
 Temperature rounded to 0.05 .... 87.75  
 T59/2  
 $T_x$ , Kelvin ..... 360.90  
 T59/3  
 Density relative to 60° water .. 0.245741809941  
 T59/4  
 $T_x$  and relative density are within range, continue  
 T59/5, Call Table 23 procedure to obtain relative density at 60°F  
 RD60 from Table 23 ..... 0.488795025411  
 T59/6, Call Table 24 Procedure to obtain CTL from 60°F to 20°C  
 CTL from Table 24 ..... 0.985452958065  
 20 °C relative density ..... 0.481684503679  
 T59/7, Values returned from Tables 23 & 24 valid, continue  
 T59/8  
 Density at 20°C ( $\text{kg/m}^3$ ) ..... 481.210526127346  
 T59/9  
 Density at 20°C (rounded) ..... 481.2

**Example 59/5 – Utilize n-Butane & i-Pentane**

Input Data to Implementation Procedure T59  
 Density at obs. temp. ( $\text{kg/m}^3$ ) .. 499.55  
 Observed Temperature  $T_f$  ( $^{\circ}\text{C}$ ) ... 87.820  
 Computed Data – last digit is rounded  
 T59/1  
 Input Data – rounded  
 Density, rounded to 0.1 ..... 499.6  
 Temperature rounded to 0.05 .... 87.80  
 T59/2  
 $T_x$ , Kelvin ..... 360.95  
 T59/3  
 Density relative to 60° water .. 0.500092090617  
 T59/4  
 $T_x$  and relative density are within range, continue  
 T59/5, Call Table 23 procedure to obtain relative density at 60°F  
 RD60 from Table 23 ..... 0.591794896225  
 T59/6, Call Table 24 Procedure to obtain CTL from 60°F to 20°C  
 CTL from Table 24 ..... 0.991727237885  
 20 °C relative density ..... 0.586899117828  
 T59/7, Values returned from Tables 23 & 24 valid, continue  
 T59/8  
 Density at 20°C ( $\text{kg/m}^3$ ) ..... 586.321609095772  
 T59/9  
 Density at 20°C (rounded) ..... 586.3

**Example 59/6 – Utilize Ethane & EP (65/35)**

Input Data to Implementation Procedure T59

Density at obs. temp. ( $\text{kg/m}^3$ ) .. 395.09

Observed Temperature  $T_f$  ( $^{\circ}\text{C}$ ) ... 15.430

Computed Data – last digit is rounded

T59/1

Input Data – rounded

Density, rounded to 0.1 ..... 395.1

Temperature rounded to 0.05 .... 15.45

T59/2

$T_x$ , Kelvin ..... 288.60

T59/3

Density relative to 60° water .. 0.395489161335

T59/4

$T_x$  and relative density are within range, continue

T59/5, Call Table 23 procedure to obtain relative density at 60°F

RD60 from Table 23 ..... 0.395233433716

T59/6, Call Table 24 Procedure to obtain CTL from 60°F to 20°C

CTL from Table 24 ..... 0.971608015812

20 °C relative density ..... 0.384011972315

T59/7, Values returned from Tables 23 & 24 valid, continue

T59/8

Density at 20°C ( $\text{kg/m}^3$ ) ..... 383.634104534331

T59/9

Density at 20°C (rounded) ..... 383.6

**Example 59/7 – Utilize i-Butane & n-Butane**

Input Data to Implementation Procedure T59

Density at obs. temp. ( $\text{kg/m}^3$ ) .. 449.59

Observed Temperature  $T_f$  ( $^{\circ}\text{C}$ ) ... 93.020

Computed Data – last digit is rounded

T59/1

Input Data – rounded

Density, rounded to 0.1 ..... 449.6

Temperature rounded to 0.05 .... 93.00

T59/2

$T_x$ , Kelvin ..... 366.15

T59/3

Density relative to 60° water .. 0.450042842157

T59/4

$T_x$  and relative density are within range, continue

T59/5, Call Table 23 procedure to obtain relative density at 60°F

RD60 from Table 23 ..... 0.565490291365

T59/6, Call Table 24 Procedure to obtain CTL from 60°F to 20°C

CTL from Table 24 ..... 0.990501113383

20 °C relative density ..... 0.560118763204

T59/7, Values returned from Tables 23 & 24 valid, continue

T59/8

Density at 20°C ( $\text{kg/m}^3$ ) ..... 559.567606341195

T59/9

Density at 20°C (rounded) ..... 559.6

**Example 59/8 – Utilize i-Hexane & n-Hexane**

Input Data to Implementation Procedure T59

Density at obs. temp. ( $\text{kg/m}^3$ ) .. 600.74

Observed Temperature  $T_f$  ( $^{\circ}\text{C}$ ) ... 80.650

Computed Data – last digit is rounded

T59/1

Input Data – rounded

Density, rounded to 0.1 ..... 600.7

Temperature rounded to 0.05 .... 80.65

T59/2

$T_x$ , Kelvin ..... 353.80

T59/3

Density relative to 60° water .. 0.601291671004

T59/4

$T_x$  and relative density are within range, continue

T59/5, Call Table 23 procedure to obtain relative density at 60°F

RD60 from Table 23 ..... 0.662699711760

T59/6, Call Table 24 Procedure to obtain CTL from 60°F to 20°C

CTL from Table 24 ..... 0.994014419312

20 °C relative density ..... 0.658733069163

T59/7, Values returned from Tables 23 & 24 valid, continue

T59/8

Density at 20°C ( $\text{kg/m}^3$ ) ..... 658.084875823243

T59/9

Density at 20°C (rounded) ..... 658.1

**Example 59/9 – Calculated RD60 near 0.6880 using n-Hexane & n-Heptane**

Input Data to Implementation Procedure T59

Density at obs. temp. ( $\text{kg/m}^3$ ) .. 736.80

Observed Temperature  $T_f$  ( $^{\circ}\text{C}$ ) ... -44.230

Computed Data – last digit is rounded

T59/1

Input Data – rounded

Density, rounded to 0.1 ..... 736.8

Temperature rounded to 0.05 .... -44.25

T59/2

$T_x$ , Kelvin ..... 228.90

T59/3

Density relative to 60° water .. 0.737525725314

T59/4

$T_x$  and relative density are within range, continue

T59/5, Call Table 23 procedure to obtain relative density at 60°F

RD60 from Table 23 ..... 0.687974688885

T59/6, Call Table 24 Procedure to obtain CTL from 60°F to 20°C

CTL from Table 24 ..... 0.994560181470

20 °C relative density ..... 0.684232231424

T59/7, Values returned from Tables 23 & 24 valid, continue

T59/8

Density at 20°C ( $\text{kg/m}^3$ ) ..... 683.558946908054

T59/9

Density at 20°C (rounded) ..... 683.6



**Example 59/10 – Calculated RD60 near 0.3500 using EE (68/32) & Ethane**

Input Data to Implementation Procedure T59  
 Density at obs. temp. ( $\text{kg/m}^3$ ) .. 224.56  
 Observed Temperature  $T_f$  ( $^{\circ}\text{C}$ ) ... 30.680  
 Computed Data – last digit is rounded  
 T59/1  
 Input Data – rounded  
 Density, rounded to 0.1 ..... 224.6  
 Temperature rounded to 0.05 .... 30.70  
 T59/2  
 $T_x$ , Kelvin ..... 303.85  
 T59/3  
 Density relative to 60° water .. 0.224821224084  
 T59/4  
 $T_x$  and relative density are within range, continue  
 T59/5, Call Table 23 procedure to obtain relative density at 60°F  
 RD60 from Table 23 ..... 0.350001829424  
 T59/6, Call Table 24 Procedure to obtain CTL from 60°F to 20°C  
 CTL from Table 24 ..... 0.948659643284  
 20 °C relative density ..... 0.332032610649  
 T59/7, Values returned from Tables 23 & 24 valid, continue  
 T59/8  
 Density at 20°C ( $\text{kg/m}^3$ ) ..... 331.705890560614  
 T59/9  
 Density at 20°C (rounded) ..... 331.7

**Example 59/11 – T23/6, RDtf < lower boundary using EE (68/32) & Ethane**

Input Data to Implementation Procedure T59

Density at obs. temp. (kg/m<sup>3</sup>) .. 339.63

Observed Temperature Tf (°C) ... 18.130

Computed Data – last digit is rounded

T59/1

Input Data – rounded

Density, rounded to 0.1 ..... 339.6

Temperature rounded to 0.05 .... 18.15

T59/2

Tx, Kelvin ..... 291.30

T59/3

Density relative to 60° water .. 0.339934495544

T59/4

Tx and relative density are within range, continue

T59/5, Call Table 23 procedure to obtain relative density at 60°F

RD60 from Table 23 ..... -1.0

Input data is outside range of Table 23, no solution

**Example 59/12 – T23/6, RDtf > upper boundary using n-Hexane & n-Heptane**

Input Data to Implementation Procedure T59

Density at obs. temp. (kg/m<sup>3</sup>) .. 727.86

Observed Temperature Tf (°C) ... -33.070

Computed Data – last digit is rounded

T59/1

Input Data – rounded

Density, rounded to 0.1 ..... 727.9

Temperature rounded to 0.05 .... -33.05

T59/2

Tx, Kelvin ..... 240.10

T59/3

Density relative to 60° water .. 0.728616959088

T59/4

Tx and relative density are within range, continue

T59/5, Call Table 23 procedure to obtain relative density at 60°F

RD60 from Table 23 ..... -1.0

Input data is outside range of Table 23, no solution

**Example 59/13 – Density < input range limit**

Input Data to Implementation Procedure T59

Density at obs. temp. (kg/m<sup>3</sup>) .. 209.74

Observed Temperature Tf (°C) ... 11.530

Computed Data – last digit is rounded

T59/1

Input Data – rounded

Density, rounded to 0.1 ..... 209.7

Temperature rounded to 0.05 .... 11.55

T59/2

Tx, Kelvin ..... 284.70

T59/3

Density relative to 60° water .. 0.209906548043

T59/4

Relative density is less than 0.2100, no solution

**Example 59/14 – Input density > input range limit**

Input Data to Implementation Procedure T59

Density at obs. temp. (kg/m<sup>3</sup>) .. 739.32

Observed Temperature Tf (°C) ... 11.530

Computed Data – last digit is rounded

T59/1

Input Data – rounded

Density, rounded to 0.1 ..... 739.3

Temperature rounded to 0.05 .... 11.55

T59/2

Tx, Kelvin ..... 284.70

T59/3

Density relative to 60° water .. 0.740028187737

T59/4

Relative density is greater than 0.7400, no solution

**Example 59/15 – Input temperature < input range limit**

Input Data to Implementation Procedure T59

Density at obs. temp. (kg/m<sup>3</sup>) .. 645.62

Observed Temperature Tf (°C) ... -46.030

Computed Data – last digit is rounded

T59/1

Input Data – rounded

Density, rounded to 0.1 ..... 645.6

Temperature rounded to 0.05 .... -46.05

T59/2

Tx, Kelvin ..... 227.10

T59/3

Density relative to 60° water .. 0.646235896122

T59/4

Tx less than 227.15, no solution

**Example 59/16 – Input temperature > input range limit**

Input Data to Implementation Procedure T59

Density at obs. temp. ( $\text{kg/m}^3$ ) .. 645.62

Observed Temperature  $T_f$  ( $^{\circ}\text{C}$ ) ... 93.070

Computed Data – last digit is rounded

T59/1

Input Data – rounded

Density, rounded to 0.1 ..... 645.6

Temperature rounded to 0.05 .... 93.05

T59/2

$T_x$ , Kelvin ..... 366.20

T59/3

Density relative to 60° water .. 0.646235896122

T59/4

$T_x$  greater than 366.15, no solution

## 6 Sample Sections of Printed Tables

Sample tables based on all the implementation procedures are found on the following pages. These tables are representative of the format and appearance of the printed tables, but complete or partial sets of printed tables may be produced in any reasonable set of variable increments required. Note, these printed tables are not the Standard; the implementation procedures are the Standard.

Even though the implementation procedures are the standard, printed tables can be used. Interpolation should not be used with any printed table since the  $C_{TL}$  equations are not necessarily linear.



TABLE 23E - FOR NGL & LPG LIQUIDS  
RELATIVE DENSITY REDUCTION TO 60°F

TEMP. (°F)	OBSERVED RELATIVE DENSITY									TEMP. (°F)
	0.5000	0.5001	0.5002	0.5003	0.5004	0.5005	0.5006	0.5007	0.5008	
CORRESPONDING RELATIVE DENSITY 60/60°F										
100.0	0.5316	0.5316	0.5317	0.5318	0.5319	0.5320	0.5321	0.5322	0.5323	100.0
100.1	0.5316	0.5317	0.5318	0.5319	0.5320	0.5321	0.5322	0.5323	0.5323	100.1
100.2	0.5317	0.5318	0.5319	0.5320	0.5321	0.5322	0.5322	0.5323	0.5324	100.2
100.3	0.5318	0.5319	0.5320	0.5320	0.5321	0.5322	0.5323	0.5324	0.5325	100.3
100.4	0.5319	0.5319	0.5320	0.5321	0.5322	0.5323	0.5324	0.5325	0.5326	100.4
100.5	0.5319	0.5320	0.5321	0.5322	0.5323	0.5324	0.5325	0.5326	0.5326	100.5
100.6	0.5320	0.5321	0.5322	0.5323	0.5324	0.5324	0.5325	0.5326	0.5327	100.6
100.7	0.5321	0.5322	0.5323	0.5323	0.5324	0.5325	0.5326	0.5327	0.5328	100.7
100.8	0.5322	0.5322	0.5323	0.5324	0.5325	0.5326	0.5327	0.5328	0.5329	100.8
100.9	0.5322	0.5323	0.5324	0.5325	0.5326	0.5327	0.5328	0.5328	0.5329	100.9
101.0	0.5323	0.5324	0.5325	0.5326	0.5327	0.5327	0.5328	0.5329	0.5330	101.0
101.1	0.5324	0.5325	0.5326	0.5326	0.5327	0.5328	0.5329	0.5330	0.5331	101.1
101.2	0.5325	0.5325	0.5326	0.5327	0.5328	0.5329	0.5330	0.5331	0.5332	101.2
101.3	0.5325	0.5326	0.5327	0.5328	0.5329	0.5330	0.5331	0.5331	0.5332	101.3
101.4	0.5326	0.5327	0.5328	0.5329	0.5330	0.5330	0.5331	0.5332	0.5333	101.4
101.5	0.5327	0.5328	0.5329	0.5329	0.5330	0.5331	0.5332	0.5333	0.5334	101.5
101.6	0.5328	0.5328	0.5329	0.5330	0.5331	0.5332	0.5333	0.5334	0.5335	101.6
101.7	0.5328	0.5329	0.5330	0.5331	0.5332	0.5333	0.5334	0.5334	0.5335	101.7
101.8	0.5329	0.5330	0.5331	0.5332	0.5333	0.5333	0.5334	0.5335	0.5336	101.8
101.9	0.5330	0.5331	0.5331	0.5332	0.5333	0.5334	0.5335	0.5336	0.5337	101.9
102.0	0.5330	0.5331	0.5332	0.5333	0.5334	0.5335	0.5336	0.5337	0.5338	102.0
102.1	0.5331	0.5332	0.5333	0.5334	0.5335	0.5336	0.5336	0.5337	0.5338	102.1
102.2	0.5332	0.5333	0.5334	0.5335	0.5335	0.5336	0.5337	0.5338	0.5339	102.2
102.3	0.5333	0.5334	0.5334	0.5335	0.5336	0.5337	0.5338	0.5339	0.5340	102.3
102.4	0.5333	0.5334	0.5335	0.5336	0.5337	0.5338	0.5339	0.5340	0.5340	102.4
102.5	0.5334	0.5335	0.5336	0.5337	0.5338	0.5339	0.5339	0.5340	0.5341	102.5
102.6	0.5335	0.5336	0.5337	0.5338	0.5338	0.5339	0.5340	0.5341	0.5342	102.6
102.7	0.5336	0.5337	0.5337	0.5338	0.5339	0.5340	0.5341	0.5342	0.5343	102.7
102.8	0.5336	0.5337	0.5338	0.5339	0.5340	0.5341	0.5342	0.5343	0.5343	102.8
102.9	0.5337	0.5338	0.5339	0.5340	0.5341	0.5342	0.5342	0.5343	0.5344	102.9
103.0	0.5338	0.5339	0.5340	0.5341	0.5341	0.5342	0.5343	0.5344	0.5345	103.0
103.1	0.5339	0.5339	0.5340	0.5341	0.5342	0.5343	0.5344	0.5345	0.5346	103.1
103.2	0.5339	0.5340	0.5341	0.5342	0.5343	0.5344	0.5345	0.5345	0.5346	103.2
103.3	0.5340	0.5341	0.5342	0.5343	0.5344	0.5344	0.5345	0.5346	0.5347	103.3
103.4	0.5341	0.5342	0.5343	0.5343	0.5344	0.5345	0.5346	0.5347	0.5348	103.4
103.5	0.5342	0.5342	0.5343	0.5344	0.5345	0.5346	0.5347	0.5348	0.5349	103.5
103.6	0.5342	0.5343	0.5344	0.5345	0.5346	0.5347	0.5348	0.5348	0.5349	103.6
103.7	0.5343	0.5344	0.5345	0.5346	0.5347	0.5347	0.5348	0.5349	0.5350	103.7
103.8	0.5344	0.5345	0.5346	0.5346	0.5347	0.5348	0.5349	0.5350	0.5351	103.8
103.9	0.5345	0.5345	0.5346	0.5347	0.5348	0.5349	0.5350	0.5351	0.5352	103.9

TABLE 24E - FOR NGL & LPG LIQUIDS  
TEMPERATURE VOLUME CORRECTION TO 60°F

TEMP. (°F)	RELATIVE DENSITY 60/60 DEGREES °F								TEMP. (°F)
	0.4000	0.4001	0.4002	0.4003	0.4004	0.4005	0.4006	0.4007	
	FACTOR FOR CORRECTING VOLUME TO 60°F								
50.0	1.03140	1.03137	1.03135	1.03133	1.03130	1.03128	1.03125	1.03123	50.0
50.1	1.03110	1.03107	1.03105	1.03102	1.03100	1.03098	1.03095	1.03093	50.1
50.2	1.03079	1.03077	1.03075	1.03072	1.03070	1.03068	1.03065	1.03063	50.2
50.3	1.03049	1.03047	1.03044	1.03042	1.03040	1.03037	1.03035	1.03033	50.3
50.4	1.03019	1.03017	1.03014	1.03012	1.03010	1.03007	1.03005	1.03003	50.4
50.5	1.02989	1.02986	1.02984	1.02982	1.02979	1.02977	1.02975	1.02973	50.5
50.6	1.02958	1.02956	1.02954	1.02952	1.02949	1.02947	1.02945	1.02942	50.6
50.7	1.02928	1.02926	1.02924	1.02921	1.02919	1.02917	1.02915	1.02912	50.7
50.8	1.02898	1.02896	1.02893	1.02891	1.02889	1.02887	1.02884	1.02882	50.8
50.9	1.02867	1.02865	1.02863	1.02861	1.02859	1.02856	1.02854	1.02852	50.9
51.0	1.02837	1.02835	1.02833	1.02830	1.02828	1.02826	1.02824	1.02822	51.0
51.1	1.02807	1.02804	1.02802	1.02800	1.02798	1.02796	1.02794	1.02791	51.1
51.2	1.02776	1.02774	1.02772	1.02770	1.02768	1.02765	1.02763	1.02761	51.2
51.3	1.02746	1.02744	1.02742	1.02739	1.02737	1.02735	1.02733	1.02731	51.3
51.4	1.02715	1.02713	1.02711	1.02709	1.02707	1.02705	1.02703	1.02701	51.4
51.5	1.02685	1.02683	1.02681	1.02679	1.02676	1.02674	1.02672	1.02670	51.5
51.6	1.02654	1.02652	1.02650	1.02648	1.02646	1.02644	1.02642	1.02640	51.6
51.7	1.02624	1.02622	1.02620	1.02618	1.02616	1.02614	1.02612	1.02610	51.7
51.8	1.02593	1.02591	1.02589	1.02587	1.02585	1.02583	1.02581	1.02579	51.8
51.9	1.02563	1.02561	1.02559	1.02557	1.02555	1.02553	1.02551	1.02549	51.9
52.0	1.02532	1.02530	1.02528	1.02526	1.02524	1.02522	1.02520	1.02518	52.0
52.1	1.02501	1.02499	1.02497	1.02495	1.02494	1.02492	1.02490	1.02488	52.1
52.2	1.02471	1.02469	1.02467	1.02465	1.02463	1.02461	1.02459	1.02457	52.2
52.3	1.02440	1.02438	1.02436	1.02434	1.02432	1.02430	1.02429	1.02427	52.3
52.4	1.02409	1.02407	1.02406	1.02404	1.02402	1.02400	1.02398	1.02396	52.4
52.5	1.02379	1.02377	1.02375	1.02373	1.02371	1.02369	1.02367	1.02366	52.5
52.6	1.02348	1.02346	1.02344	1.02342	1.02340	1.02339	1.02337	1.02335	52.6
52.7	1.02317	1.02315	1.02313	1.02312	1.02310	1.02308	1.02306	1.02304	52.7
52.8	1.02286	1.02284	1.02283	1.02281	1.02279	1.02277	1.02276	1.02274	52.8
52.9	1.02255	1.02254	1.02252	1.02250	1.02248	1.02247	1.02245	1.02243	52.9
53.0	1.02225	1.02223	1.02221	1.02219	1.02218	1.02216	1.02214	1.02212	53.0
53.1	1.02194	1.02192	1.02190	1.02188	1.02187	1.02185	1.02183	1.02182	53.1
53.2	1.02163	1.02161	1.02159	1.02158	1.02156	1.02154	1.02153	1.02151	53.2
53.3	1.02132	1.02130	1.02128	1.02127	1.02125	1.02123	1.02122	1.02120	53.3
53.4	1.02101	1.02099	1.02098	1.02096	1.02094	1.02093	1.02091	1.02089	53.4
53.5	1.02070	1.02068	1.02067	1.02065	1.02063	1.02062	1.02060	1.02059	53.5
53.6	1.02039	1.02037	1.02036	1.02034	1.02032	1.02031	1.02029	1.02028	53.6
53.7	1.02008	1.02006	1.02005	1.02003	1.02002	1.02000	1.01998	1.01997	53.7
53.8	1.01977	1.01975	1.01974	1.01972	1.01971	1.01969	1.01967	1.01966	53.8
53.9	1.01946	1.01944	1.01943	1.01941	1.01940	1.01938	1.01937	1.01935	53.9

TABLE 53E – FOR NGL & LPG LIQUIDS  
DENSITY REDUCTION TO 15°C

TEMP. (°C)	OBSERVED DENSITY									TEMP. (°C)
	210.0	215.0	220.0	225.0	230.0	235.0	240.0	245.0	250.0	
	CORRESPONDING DENSITY AT 15°C									
31.0	352.6	352.6	352.7	352.9	353.2	353.5	353.9	354.5	355.2	31.0
32.0	356.8	356.8	356.9	357.0	357.2	357.5	357.8	358.1	358.5	32.0
33.0	359.6	359.6	359.7	359.7	359.9	360.1	360.3	360.7	361.1	33.0
34.0	362.1	362.2	362.2	362.3	362.4	362.6	362.9	363.3	363.7	34.0
35.0	364.7	364.7	364.7	364.8	365.0	365.2	365.5	365.9	366.3	35.0
36.0	367.2	367.2	367.3	367.4	367.5	367.8	368.1	368.4	368.9	36.0
37.0	369.7	369.8	369.8	369.9	370.1	370.3	370.6	371.0	371.5	37.0
38.0	372.3	372.3	372.4	372.5	372.7	372.9	373.2	373.6	374.1	38.0
39.0	374.8	374.9	374.9	375.1	375.2	375.5	375.8	376.2	376.7	39.0
40.0	377.4	377.4	377.5	377.6	377.8	378.0	378.4	378.8	379.3	40.0
41.0	379.9	380.0	380.1	380.2	380.4	380.6	380.9	381.4	381.9	41.0
42.0	382.5	382.5	382.6	382.7	382.9	383.2	383.5	383.9	384.5	42.0
43.0	385.1	385.1	385.2	385.3	385.5	385.8	386.1	386.5	387.0	43.0
44.0	387.6	387.7	387.7	387.9	388.1	388.3	388.7	389.1	389.6	44.0
45.0	390.2	390.2	390.3	390.4	390.6	390.9	391.2	391.7	392.2	45.0
46.0	392.7	392.8	392.9	393.0	393.2	393.5	393.8	394.3	394.8	46.0
47.0	395.3	395.4	395.4	395.6	395.8	396.0	396.4	396.8	397.4	47.0
48.0	397.9	397.9	398.0	398.1	398.4	398.6	399.0	399.4	399.9	48.0
49.0	400.4	400.5	400.6	400.7	400.9	401.2	401.5	402.0	402.5	49.0
50.0	403.0	403.1	403.1	403.3	403.5	403.8	404.1	404.6	405.1	50.0
51.0	405.6	405.6	405.7	405.9	406.1	406.3	406.7	407.1	407.7	51.0
52.0	408.1	408.2	408.3	408.4	408.6	408.9	409.3	409.7	410.2	52.0
53.0	410.7	410.8	410.9	411.0	411.2	411.5	411.8	412.3	412.8	53.0
54.0	413.3	413.3	413.4	413.6	413.8	414.1	414.4	414.9	415.4	54.0
55.0	415.8	415.9	416.0	416.1	416.4	416.6	417.0	417.4	418.0	55.0
56.0	418.4	418.5	418.6	418.7	418.9	419.2	419.6	420.0	420.5	56.0
57.0	421.0	421.0	421.1	421.3	421.5	421.8	422.1	422.6	423.1	57.0
58.0	423.6	423.6	423.7	423.9	424.1	424.4	424.7	425.1	425.7	58.0
59.0	426.1	426.2	426.3	426.4	426.7	426.9	427.3	427.7	428.2	59.0
60.0	428.7	428.8	428.9	429.0	429.2	429.5	429.9	430.2	430.7	60.0
61.0	431.1	431.1	431.2	431.3	431.5	431.7	432.0	432.4	432.8	61.0
62.0	433.2	433.3	433.4	433.5	433.7	433.9	434.2	434.6	435.0	62.0
63.0	435.4	435.5	435.5	435.7	435.8	436.1	436.4	436.7	437.1	63.0
64.0	437.6	437.6	437.7	437.8	438.0	438.2	438.5	438.9	439.3	64.0
65.0	439.8	439.8	439.9	440.0	440.2	440.4	440.7	441.0	441.4	65.0
66.0	441.9	442.0	442.1	442.2	442.3	442.6	442.8	443.2	443.6	66.0
67.0	444.1	444.1	444.2	444.3	444.5	444.7	445.0	445.3	445.8	67.0
68.0	446.3	446.3	446.4	446.5	446.7	446.9	447.2	447.5	447.9	68.0
69.0	448.4	448.5	448.6	448.7	448.8	449.0	449.3	449.7	450.1	69.0
70.0	450.6	450.7	450.7	450.8	451.0	451.2	451.5	451.8	452.2	70.0

TABLE 54E – FOR NGL & LPG LIQUIDS  
TEMPERATURE VOLUME CORRECTION TO 15°C

TEMP. (°C)	DENSITY AT 15 DEGREES °C								TEMP. (°C)
	400.00	405.00	410.00	415.00	420.00	425.00	430.00	435.00	
FACTOR FOR CORRECTING VOLUME TO 15°C									
10.0	1.02824	1.02719	1.02623	1.02535	1.02453	1.02377	1.02306	1.02220	10.0
10.5	1.02551	1.02456	1.02368	1.02288	1.02214	1.02145	1.02081	1.02003	10.5
11.0	1.02276	1.02190	1.02112	1.02040	1.01974	1.01912	1.01855	1.01785	11.0
11.5	1.01999	1.01923	1.01854	1.01791	1.01732	1.01678	1.01628	1.01566	11.5
12.0	1.01720	1.01654	1.01595	1.01540	1.01489	1.01443	1.01399	1.01346	12.0
12.5	1.01438	1.01384	1.01333	1.01287	1.01245	1.01206	1.01169	1.01125	12.5
13.0	1.01155	1.01111	1.01070	1.01033	1.00999	1.00967	1.00938	1.00902	13.0
13.5	1.00870	1.00836	1.00806	1.00777	1.00752	1.00728	1.00706	1.00679	13.5
14.0	1.00582	1.00559	1.00539	1.00520	1.00503	1.00487	1.00472	1.00454	14.0
14.5	1.00292	1.00281	1.00270	1.00261	1.00252	1.00244	1.00237	1.00227	14.5
15.0	1.00000	1.00000	1.00000	1.00000	1.00000	1.00000	1.00000	1.00000	15.0
15.5	0.99705	0.99717	0.99728	0.99737	0.99746	0.99754	0.99762	0.99771	15.5
16.0	0.99409	0.99432	0.99453	0.99473	0.99491	0.99507	0.99523	0.99541	16.0
16.5	0.99109	0.99145	0.99177	0.99207	0.99234	0.99259	0.99282	0.99310	16.5
17.0	0.98807	0.98855	0.98899	0.98938	0.98975	0.99008	0.99040	0.99077	17.0
17.5	0.98503	0.98563	0.98618	0.98668	0.98714	0.98757	0.98796	0.98843	17.5
18.0	0.98196	0.98269	0.98335	0.98396	0.98452	0.98503	0.98551	0.98608	18.0
18.5	0.97886	0.97972	0.98050	0.98122	0.98187	0.98248	0.98304	0.98371	18.5
19.0	0.97573	0.97673	0.97763	0.97846	0.97921	0.97991	0.98055	0.98133	19.0
19.5	0.97257	0.97371	0.97474	0.97567	0.97653	0.97732	0.97805	0.97893	19.5
20.0	0.96939	0.97066	0.97182	0.97287	0.97383	0.97472	0.97553	0.97652	20.0
20.5	0.96617	0.96759	0.96887	0.97004	0.97111	0.97209	0.97300	0.97409	20.5
21.0	0.96293	0.96449	0.96590	0.96719	0.96837	0.96945	0.97045	0.97165	21.0
21.5	0.95965	0.96136	0.96291	0.96432	0.96561	0.96679	0.96788	0.96919	21.5
22.0	0.95633	0.95820	0.95989	0.96142	0.96282	0.96411	0.96529	0.96671	22.0
22.5	0.95299	0.95501	0.95684	0.95850	0.96002	0.96141	0.96269	0.96422	22.5
23.0	0.94960	0.95179	0.95376	0.95556	0.95719	0.95868	0.96006	0.96171	23.0
23.5	0.94618	0.94854	0.95066	0.95258	0.95434	0.95594	0.95742	0.95919	23.5
24.0	0.94273	0.94525	0.94753	0.94959	0.95146	0.95318	0.95476	0.95665	24.0
24.5	0.93923	0.94193	0.94436	0.94656	0.94856	0.95039	0.95207	0.95408	24.5
25.0	0.93570	0.93858	0.94117	0.94351	0.94564	0.94758	0.94937	0.95150	25.0
25.5	0.93212	0.93519	0.93794	0.94043	0.94269	0.94475	0.94665	0.94891	25.5
26.0	0.92850	0.93176	0.93468	0.93732	0.93971	0.94190	0.94390	0.94629	26.0
26.5	0.92483	0.92829	0.93138	0.93417	0.93671	0.93902	0.94113	0.94365	26.5
27.0	0.92112	0.92478	0.92805	0.93100	0.93367	0.93611	0.93834	0.94100	27.0
27.5	0.91736	0.92123	0.92469	0.92780	0.93062	0.93318	0.93553	0.93832	27.5
28.0	0.91355	0.91764	0.92128	0.92456	0.92753	0.93022	0.93269	0.93562	28.0
28.5	0.90969	0.91400	0.91784	0.92129	0.92441	0.92724	0.92983	0.93290	28.5
29.0	0.90577	0.91032	0.91436	0.91798	0.92126	0.92423	0.92695	0.93016	29.0
29.5	0.90180	0.90659	0.91084	0.91464	0.91807	0.92119	0.92404	0.92740	29.5

TABLE 59E – FOR NGL & LPG LIQUIDS  
DENSITY REDUCTION TO 20°C

TEMP. (°C)	OBSERVED DENSITY									TEMP. (°C)
	210.0	215.0	220.0	225.0	230.0	235.0	240.0	245.0	250.0	
	CORRESPONDING DENSITY AT 20°C									
31.0	332.9	332.9	333.1	333.3	333.6	334.0	334.5	335.2	336.1	31.0
32.0	338.0	338.1	338.1	338.3	338.5	338.9	339.2	339.7	340.2	32.0
33.0	341.6	341.6	341.7	341.8	341.9	342.2	342.5	343.0	343.5	33.0
34.0	344.8	344.8	344.9	345.0	345.1	345.4	345.7	346.2	346.7	34.0
35.0	347.9	347.9	348.0	348.1	348.3	348.5	348.9	349.3	349.9	35.0
36.0	351.0	351.0	351.1	351.2	351.4	351.6	352.0	352.4	353.0	36.0
37.0	354.0	354.0	354.1	354.2	354.4	354.7	355.0	355.5	356.0	37.0
38.0	357.0	357.0	357.1	357.2	357.4	357.7	358.0	358.5	359.1	38.0
39.0	359.9	359.9	360.0	360.1	360.3	360.6	361.0	361.5	362.0	39.0
40.0	362.8	362.9	362.9	363.1	363.3	363.6	363.9	364.4	365.0	40.0
41.0	365.7	365.8	365.8	366.0	366.2	366.5	366.8	367.3	367.9	41.0
42.0	368.6	368.6	368.7	368.9	369.1	369.3	369.7	370.2	370.8	42.0
43.0	371.4	371.5	371.6	371.7	371.9	372.2	372.6	373.1	373.6	43.0
44.0	374.3	374.3	374.4	374.6	374.8	375.1	375.4	375.9	376.5	44.0
45.0	377.1	377.1	377.2	377.4	377.6	377.9	378.3	378.7	379.3	45.0
46.0	379.9	379.9	380.0	380.2	380.4	380.7	381.1	381.5	382.1	46.0
47.0	382.7	382.7	382.8	383.0	383.2	383.5	383.9	384.3	384.9	47.0
48.0	385.5	385.5	385.6	385.8	386.0	386.3	386.6	387.1	387.7	48.0
49.0	388.2	388.3	388.4	388.5	388.7	389.0	389.4	389.9	390.5	49.0
50.0	391.0	391.0	391.1	391.3	391.5	391.8	392.2	392.6	393.2	50.0
51.0	393.7	393.8	393.9	394.0	394.3	394.6	394.9	395.4	396.0	51.0
52.0	396.5	396.5	396.6	396.8	397.0	397.3	397.7	398.1	398.7	52.0
53.0	399.2	399.2	399.4	399.5	399.7	400.0	400.4	400.9	401.4	53.0
54.0	401.9	402.0	402.1	402.2	402.5	402.7	403.1	403.6	404.1	54.0
55.0	404.6	404.7	404.8	405.0	405.2	405.5	405.8	406.3	406.9	55.0
56.0	407.3	407.4	407.5	407.7	407.9	408.2	408.5	409.0	409.6	56.0
57.0	410.0	410.1	410.2	410.4	410.6	410.9	411.2	411.7	412.3	57.0
58.0	412.7	412.8	412.9	413.1	413.3	413.6	413.9	414.4	414.9	58.0
59.0	415.4	415.5	415.6	415.8	416.0	416.3	416.6	417.1	417.6	59.0
60.0	418.1	418.2	418.3	418.5	418.7	419.0	419.3	419.7	420.2	60.0
61.0	420.6	420.7	420.8	420.9	421.1	421.3	421.6	422.0	422.5	61.0
62.0	422.9	423.0	423.1	423.2	423.4	423.6	423.9	424.3	424.8	62.0
63.0	425.2	425.3	425.4	425.5	425.7	425.9	426.2	426.6	427.0	63.0
64.0	427.5	427.6	427.7	427.8	428.0	428.2	428.5	428.9	429.3	64.0
65.0	429.8	429.9	429.9	430.1	430.2	430.5	430.8	431.1	431.6	65.0
66.0	432.1	432.1	432.2	432.4	432.5	432.8	433.1	433.4	433.9	66.0
67.0	434.4	434.4	434.5	434.6	434.8	435.0	435.3	435.7	436.1	67.0
68.0	436.7	436.7	436.8	436.9	437.1	437.3	437.6	437.9	438.4	68.0
69.0	438.9	439.0	439.1	439.2	439.3	439.6	439.8	440.2	440.6	69.0
70.0	441.2	441.3	441.3	441.4	441.6	441.8	442.1	442.4	442.9	70.0

TABLE 60E – FOR NGL & LPG LIQUIDS  
TEMPERATURE VOLUME CORRECTION TO 20°C

TEMP. (°C)	DENSITY AT 20 DEGREES °C								TEMP. (°C)
	400.00	405.00	410.00	415.00	420.00	425.00	430.00	435.00	
	FACTOR FOR CORRECTING VOLUME TO 20°C								
10.0	1.05537	1.05348	1.05172	1.05009	1.04852	1.04671	1.04502	1.04346	10.0
10.5	1.05278	1.05096	1.04928	1.04772	1.04623	1.04449	1.04288	1.04138	10.5
11.0	1.05017	1.04844	1.04683	1.04534	1.04392	1.04226	1.04073	1.03930	11.0
11.5	1.04754	1.04589	1.04437	1.04295	1.04159	1.04002	1.03856	1.03721	11.5
12.0	1.04490	1.04333	1.04189	1.04055	1.03926	1.03777	1.03639	1.03511	12.0
12.5	1.04224	1.04076	1.03939	1.03813	1.03691	1.03551	1.03420	1.03300	12.5
13.0	1.03956	1.03817	1.03688	1.03569	1.03455	1.03323	1.03201	1.03087	13.0
13.5	1.03686	1.03556	1.03436	1.03324	1.03218	1.03094	1.02980	1.02874	13.5
14.0	1.03415	1.03294	1.03182	1.03078	1.02979	1.02864	1.02758	1.02660	14.0
14.5	1.03142	1.03030	1.02926	1.02830	1.02739	1.02633	1.02535	1.02445	14.5
15.0	1.02866	1.02764	1.02669	1.02581	1.02497	1.02401	1.02311	1.02228	15.0
15.5	1.02589	1.02496	1.02410	1.02331	1.02254	1.02167	1.02086	1.02011	15.5
16.0	1.02310	1.02227	1.02150	1.02078	1.02010	1.01932	1.01859	1.01792	16.0
16.5	1.02029	1.01955	1.01887	1.01824	1.01764	1.01695	1.01631	1.01572	16.5
17.0	1.01746	1.01682	1.01623	1.01569	1.01517	1.01457	1.01402	1.01351	17.0
17.5	1.01460	1.01407	1.01357	1.01312	1.01268	1.01218	1.01172	1.01129	17.5
18.0	1.01173	1.01130	1.01090	1.01053	1.01018	1.00977	1.00940	1.00906	18.0
18.5	1.00883	1.00850	1.00820	1.00792	1.00766	1.00735	1.00707	1.00681	18.5
19.0	1.00591	1.00569	1.00549	1.00530	1.00512	1.00492	1.00473	1.00455	19.0
19.5	1.00297	1.00286	1.00275	1.00266	1.00257	1.00247	1.00237	1.00228	19.5
20.0	1.00000	1.00000	1.00000	1.00000	1.00000	1.00000	1.00000	1.00000	20.0
20.5	0.99701	0.99712	0.99723	0.99732	0.99741	0.99752	0.99761	0.99770	20.5
21.0	0.99399	0.99422	0.99443	0.99463	0.99481	0.99502	0.99522	0.99539	21.0
21.5	0.99095	0.99130	0.99162	0.99191	0.99219	0.99251	0.99280	0.99307	21.5
22.0	0.98788	0.98835	0.98878	0.98917	0.98955	0.98998	0.99037	0.99073	22.0
22.5	0.98478	0.98538	0.98592	0.98642	0.98689	0.98743	0.98793	0.98838	22.5
23.0	0.98166	0.98238	0.98304	0.98364	0.98421	0.98487	0.98547	0.98602	23.0
23.5	0.97851	0.97936	0.98013	0.98084	0.98152	0.98228	0.98299	0.98364	23.5
24.0	0.97533	0.97631	0.97720	0.97802	0.97880	0.97968	0.98050	0.98125	24.0
24.5	0.97212	0.97323	0.97425	0.97518	0.97606	0.97707	0.97799	0.97884	24.5
25.0	0.96887	0.97012	0.97127	0.97231	0.97330	0.97443	0.97546	0.97641	25.0
25.5	0.96560	0.96699	0.96826	0.96942	0.97052	0.97177	0.97292	0.97397	25.5
26.0	0.96229	0.96383	0.96523	0.96651	0.96772	0.96910	0.97036	0.97152	26.0
26.5	0.95895	0.96064	0.96217	0.96357	0.96490	0.96640	0.96778	0.96904	26.5
27.0	0.95558	0.95741	0.95908	0.96061	0.96206	0.96369	0.96518	0.96656	27.0
27.5	0.95217	0.95416	0.95597	0.95762	0.95919	0.96095	0.96257	0.96405	27.5
28.0	0.94872	0.95087	0.95282	0.95461	0.95629	0.95820	0.95993	0.96153	28.0
28.5	0.94523	0.94755	0.94965	0.95157	0.95338	0.95542	0.95728	0.95899	28.5
29.0	0.94170	0.94419	0.94644	0.94850	0.95043	0.95261	0.95460	0.95643	29.0
29.5	0.93814	0.94080	0.94321	0.94540	0.94746	0.94979	0.95191	0.95385	29.5

## 7 References

1. Manual of Petroleum Measurement Standards, Chapter 11.1 — Temperature and Pressure Volume Correction Factors for Generalized Crude Oils, Refined Products, and Lubricating Oils, American Petroleum Institute, Washington D.C. (2004).
2. Manual of Petroleum Measurement Standards, Chapter 11.2.1 — Compressibility Factors for Hydrocarbons: 0–90° API Range, American Petroleum Institute, Washington D.C. (1984).
3. Manual of Petroleum Measurement Standards, Chapter 11.2.1M — Compressibility Factors for Hydrocarbons: 638 – 1074 Kilograms per Cubic Metre Range, American Petroleum Institute, Washington D.C. (1986).
4. Manual of Petroleum Measurement Standards, Chapter 11.2.2 — Compressibility Factors for Hydrocarbons: 0.350 – 0.637 Relative Density (60°F/60°F) and –50°F to 140°F Metering Temperature, American Petroleum Institute, Washington D.C. (1984).
5. Manual of Petroleum Measurement Standards, Chapter 11.2.2M — Compressibility Factors for Hydrocarbons: 350 – 637 Kilograms per Cubic Metre Density (15°C) and 46°C to 60°C Metering Temperature, American Petroleum Institute, Washington D.C. (1986).
6. ASTM-IP Petroleum Measurement Tables, ASTM, Philadelphia, American Edition, (1952), pp. 177-482.
7. “Standard Factors for Volume Correction and Specific Gravity Conversion of Liquefied Petroleum Gases”, GPA-2142, Gas Processors Association, Tulsa, (1957).
8. “Composite Pressure and Temperature Volume Correction Tables for Liquefied Petroleum Gas (LPG) and Natural Gasoline”, Technical Publication TP-16, Gas Processors Association, Tulsa, (1988).
9. Petroleum Measurement Tables, Volume XII, Intraconversion Between Volume Measures and Density Measures, ASTM, Philadelphia, (1982), pp. 155-164.
10. “Temperature Correction for the Volume of Light Hydrocarbons — Tables 24E and 23E”, Technical Publication TP-25, American Petroleum Institute, Washington D.C./ASTM, Philadelphia/Gas Processors Association, Tulsa, (1998).
11. J. F. Ely, “Volume Correction Factors for Natural Gas Liquids – Phase II”, Research Report RR-148, Gas Processors Association, Tulsa, (1995).
12. C. D. Holcomb, J. W. Magee, W. M. Haynes, “Density Measurements on Natural Gas Liquids”, Research Report RR-147, Gas Processors Association, Tulsa, (1995).
13. J. F. Ely, “Volume Correction Factors for Natural Gas Liquids – Phase I”, Research Report RR-133, Gas Processors Association, Tulsa, (1991).









1220 L Street, NW  
Washington, DC 20005-4070  
USA

202.682.8000

**Additional copies are available through IHS**

Phone Orders: 1-800-854-7179 (Toll-free in the U.S. and Canada)  
303-397-7956 (Local and International)

Fax Orders: 303-397-2740

Online Orders: [global.ihs.com](http://global.ihs.com)

Information about API Publications, Programs and Services  
is available on the web at [www.api.org](http://www.api.org)

Product No. H1102041